This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines

Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

+ *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.

+ *Refrain from automated querying* Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.

+ *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.

+ *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at `http://books.google.com/`

PROPERTY OF
The University of Michigan Libraries
1817
XETES SCIENTIA VERITAS

A

TREATISE

Containing the

ELEMENTARY PART

OF

FORTIFICATION,

REGULAR AND IRREGULAR.

WITH

REMARKS on the Conſtructions of the moſt celebrated Authors, particularly of Marſhal de VAUBAN and Baron COEHORN, in which the Perfection and Imperfection of their ſeveral Works are conſidered.

For the USE of the

Royal Academy of ARTILLERY at Woolwich.

Illuſtrated with Thirty-Four Copper Plates.

The FIFTH EDITION.

By JOHN MULLER,

Profeſſor of ARTILLERY and FORTIFICATION.

LONDON:

Printed for F. WINGRAVE, Succeſſor to Mr. NOURSE, in the Strand.

M,DCC,XCIX.

UG
400
.M95
1799

W. H. Corning
gt.
6-19-1923

To his GRACE

JOHN

Duke of MONTAGUE, &c.

One of his Majeſty's moſt honourable Privy-council, Great Maſter of the moſt honourable order of the Bath, *Knight of the moſt noble order of the Garter, Maſter of the King's great Wardrobe, Colonel of the Queen's royal regiment of horſe, and Maſter general of the ordnance,* &c.

May it pleaſe your Grace,

THE inſtitution of the royal academy for the inſtruction of military gentlemen, will be a laſting monument of your Grace's attention to his Majeſty's ſervice, and of your encouragement of uſeful learning.

427681

DEDICATION.

As your Grace has been pleaſed to appoint me to inſtruct the young gentlemen of the academy, and this work having been compiled for their improvement, it naturally claims your Grace's patronage; which, if I am ſo happy to obtain, will gratify the utmoſt of my wiſhes, as I have thereby an opportunity of aſſuring your Grace of the ſenſe I have of your goodneſs and generoſity, and of the gratitude with which I am moſt reſpectfully,

Your Grace's

moſt obedient

and moſt devoted

humble ſervant,

From the Royal Academy at *Woolwich, Auguſt* 27th, 1766.

John Muller.

THE PREFACE.

SINCE the invention of gunpowder, fortification has received various improvements, and many have been the books wrote upon this ſubject, which might incline one to think, that it was arrived to its utmoſt perfection; but upon an impartial ſurvey of moſt of the writers, it will be found, if I miſtake not, that many of them are deficient either in theory or practice, and others blinded by prejudice, ſo that there is much room left to exerciſe the genius and excite the induſtry of thoſe whoſe buſineſs leads them to this ſtudy; beſides, as the art of attacking received ſeveral improvements in the late wars, it ſhould follow that the art of fortifying requires likewiſe improvements in proportion.

Not a few authors have proceeded upon maxims, ſome of which are uncertain, others trifling, and they have often neglected thoſe which are ſelf-evident: this together with their adopting ſome favourite ſcheme has retarded its progreſs.

Particular care ſhould be taken, in tracing plans on paper, in order to know whether

they are practicable or not; which has been neglected by many, even by ſome of thoſe who are generally eſteemed the beſt writers.

Some think it ſufficient, that they make ſchemes with a great many outworks upon outworks, ſo as theſe works defend each other; without conſidering whether the town thus ſurrounded is ſpacious enough to hold, beſides the inhabitants, a garriſon ſufficient to defend it: or the expence it would require to maintain them, and likewiſe the neceſſary ſtores: it is true they never fail to tell you that they have ſome ſecret, which enables them to build for half the coſt that others do.

Notwithſtanding the art of fortifying irregular places is moſt uſeful, yet no author whom I know has given the leaſt hint or direction whereby to judge of the advantage or diſadvantage of the ſeveral parts of ſuch a place: all they have done conſiſts in giving ſome ſchemes of their own fancy, and telling us no work ought to be made without being defended by ſome other; not conſidering, that although the parts defend each other, there may be ſome which are much ſtronger than others.

For the true art conſiſts in making an irregular fortification every where equally ſtrong,

which they ſeemed to be ignorant of, or if they knew it, they could not diſtinguiſh the ſtrong from the weak.

The commentators on M. *Vauban*'s methods, who are ſo laviſh in his praiſes, do not mention any thing of his way of fortifying irregular places; although he underſtood it better than any one, as appears by a great many examples of this kind; neither has any of them ſhewn why he made always the exterior ſide next to a river much longer than any other, as may be ſeen in the plans of *Hunningen*, and *Sarrelouis*; yet it is unqueſtionable that a man of ſo much experience had ſome very good reaſons for what he did.

The very ſame miſtake is made with regard to M. *Coehorn*, by thoſe who praiſe him to the ſkies, on account of his treatiſe which he publiſhed before he had acquired that great experience, for which he was ſo juſtly eſteemed in his latter years; and it is an undoubted proof that he himſelf was of the ſame opinion afterwards, ſince he did not uſe any of the methods publiſhed in his book, when he fortified *Bergen-op-zoom* and part of *Manheim*: had he left us in writing that knowledge which he acquired by his great experience, it would have undoubtedly been

worthy of ſo great a man, and would have perfectly juſtified the high opinion the world conceived of him.

It will not be improper to mention *Daniel Specle*, who publiſhed a book of fortification in the year 1589 at *Straſbourg* in the *German* language, which M. *Coehorn* has chiefly followed, as may be ſeen by comparing their works; and *Dilichius*, who publiſhed his *Peribologia* in the year 1640, at *Frankfort* on the *Main*, in *German* and *Latin*, was followed by M. *Vauban*; ſince there is nothing in this author, beſides his concave flanks, but what is to be found in the other.

Theſe two *German* authors were undoubtedly the beſt in their times, and as it were the fountains from which the preſent methods are derived: the few improvements made ſince are ſufficient proofs of their ſkill, and at the ſame time of the barrenneſs of invention of thoſe ſince.

As M. *Vauban*'s methods are now moſt in vogue, and chiefly uſed all over *Europe*; we thought it would not be improper to explain them firſt, and after his, thoſe of M. *Coehorn*, which are next in eſteem; and then lay down ſome principles, whereby the advantage or diſadvantage of a fortification may

be

be known; after this, we have examined their methods in each part ſeparately, and pointed out their ſeveral deficiencies, and afterwards have given ſome of the ſame works with proper corrections.

Then we propoſe three different methods, which we hope are not altogether to be deſpiſed, and which we think might be uſed according to the different ſituations and importance of places: this with the conſtructions of ſome of the moſt celebrated authors, and their examination, finiſhes the regular part of fortification.

We begin the irregular, by ſhewing how a place, that cannot be made regular, may be made ſo, as one half may be ſimilar and equal to the other half; then we enquire which part of ſuch a fortification is ſtrongeſt and which is weakeſt; theſe principles, which are demonſtrable, ſerve to judge of the weakeſt and ſtrongeſt part of any irregular fortification whatſoever; and for a farther confirmation of the truth of them, we refer the reader to ſeveral places in *Flanders* fortified by the greateſt maſters, and which agree exactly with what we advanced.

As the greateſt ſtrength of this, and all maritime nations, conſiſts in traffic, and as fortified

fied places which lie near rivers, lakes, creeks, or the ſea, chiefly ſerve to protect and promote trade, we have dwelled upon and explained their conſtructions in a more particular manner, and nothing has been omitted that could be thought of, which might any ways contribute to the right underſtanding this ſubject.

Several examples are given, in order to ſhew, how and in what manner the reader may proceed, if he finds himſelf employed in the conſtruction of ſuch places; the ſeveral advantages and diſadvantages of their ſituations are carefully examined, and thoſe which require leaſt expence to fortify, and are moſt convenient in other reſpects, are diſtinguiſhed; for a further explanation we have examined ſeveral ſea-port towns, and pointed out thoſe which deſerve to be imitated, and others, which ſhould be avoided; the plan of *Toulon* with its harbour is inſerted, as being one of the beſt in *Europe*: laſtly, we have given the principal conditions required in the conſtruction of ſuch places. Having thus far explained the ſeveral parts of irregular fortification, we proceed to ſhew how citadels are to be joined to places, and the faults committed in ſome of the fineſt in *Europe* are pointed out; the work concludes with the

the manner of building forts, where particular notice has been taken of the methods generally followed in the building of ſuch works, near rivers and the ſea, and ſhewn their ill conſequences: as this ſubject is very important to this nation, on account of the many forts we have and daily build, ſo we have endeavoured to point out the moſt proper manner, in which they ſhould be made.

The preſent undertaking contains the theoretical part of fortification only, that which relates to the practice has been treated in another volume; ſo that the whole together makes a compleat treatiſe of fortification, containing all the moſt material principles neceſſary to an *Engliſh* engineer. I may venture to ſay, that whoever reads it with proper attention, will find no endeavours have been wanting to explain every thing that is neceſſary in as ſhort a compaſs as was poſſible.

In this edition, particular care has been taken to enlarge the explanations of the conſtructions and remarks wherever it was thought neceſſary, in order to ſet every thing in as clear a light as we could: for nothing elſe ſeemed to be wanting to compleat the work.

THE

THE

CONTENTS.

SECTION I.

Of Practical Geometry.

Definitions of Geometry - - Page 1
Problems uſeful in fortification - 5
Of the meaſures and ſcales uſed in fortification - - - - - 13
Colours uſed in the drawings of fortification 14

SECTION II.

Of regular Fortification.

Definitions; the riſe and progreſs of fortifications - - - - - - 18
Conſtruction of M. VAUBAN'S *firſt method* 23
Definitions of the ſeveral lines and angles of a fortification - - - - 26
A table of the dimenſions - - 28
Conſtruction of orillons and retired flanks - 30
Conſtruction of ravelins or half-moons - 31

Conſtruction of tenailles - - Page 33
Conſtruction of lunettes - - - 35
Conſtruction of tenaillons - - - 37
Conſtruction of counterguards - - 38
Conſtruction of horn-works - - 39
Conſtruction of crown-works - - 40
Conſtruction of covert-ways, and glacis - 41
Conſtruction of arrows, and detached redoubts - - - - 43
Conſtructions of ſecond ditches and covert-ways - - - - - 45
Conſtruction of profiles - - - 46
Table containing the dimenſions of profiles - 50
Conſtruction of M. VAUBAN'S *ſecond method with tower baſtions* - - - 52
Conſtruction of M. VAUBAN'S *third method, according to the plan of* New-Briſach - 54
Conſtruction of M. COEHORN'S *firſt method* - - - - - 56
Conſtruction of M. COEHORN'S *ſecond method* - - - - - 62
Conſtruction of M. COEHORN'S *third method* - - - - - 65

SECTION III.

Containing the general maxims of fortification, applied in the remarks on the preceding

ceding authors, and others mentioned hereafter - - - - Page 67
Problem to determine the ſeveral parts of a front of a fortification - - 74
Remarks on M. VAUBAN'S *firſt method* - 78
Remarks on M. VAUBAN'S *ſecond and third methods* - - - - - 88
Remarks on M. COEHORN'S *firſt method* - 91
A new conſtruction - - - 97
To conſtruct the ravelin - - - 99
To conſtruct retired flanks - - ibid.
Remarks on this conſtruction - - 100
To conſtruct horn and crown-works - - 101
Remarks on this conſtruction - - 104
Conſtruction of a place with detached baſtions - - - - - 105
Remarks on this conſtruction - - 108
Conſtruction of a place with detached orillon baſtions - - - - 111
Remarks - - - - 112
Conſtruction of a place with lunettes and counterguards - - - - 115
Remarks on this conſtruction - - 116
Conſtruction of M. BELIDOR'S *firſt method* 120
Remarks on this conſtruction - - 122
Conſtruction of M. BELIDOR'S *ſecond method* - - - - - - 123
Remarks on this conſtruction - - 126

Con-

Conſtruction of M. BELIDOR's *third method* - - - - Page 127
Remarks on this method - - - 129
Conſtruction of M. BLONDEL's *ſecond method* - - - - - 132
Remarks on this method - - - 134
Conſtruction of Count PAGAN's *method* - 136
Count PAGAN's *method corrected* - - 142
Remarks on this conſtruction - - 143

SECTION IV.

Of Irregular Fortification.

A preliminary diſcourſe, and ſome propoſitions - - - - - 144
Conſtruction of an irregular place ſituated in an open country - - - - 160
Conſtruction of an irregular place ſituated on a hill, or rock - - - - 167
Conſtruction of irregular fortifications, ſituated near rivers, lakes, or the ſea - - 169
An illuſtration, by a plan of Hunningen - 171
Example I. of a place ſituated near a river 176
Example II. of a place ſituated on both ſides of a river - - - - - 180
Example III. of a place ſituated near the ſea - - - - - 182
Obſervations, relating to places built near the ſea - - - - - 187

An

An inſtance, in the plan of the town and harbour of Toulon - - Page 191
The principal conditions required in the fortifying a ſea-port town - - - 193

Of CITADELS.

How they are conſtructed, and where they ſhould be placed - - - - 197
Obſervations on the Citadel of Lille - - 202
Obſervations on that of Tournay *and* Arras ibid.

Of FORTS and REDOUBTS.

Different conſtructions of forts - - 205
Faults committed in the conſtructions of forts near the ſea - - - - 210

An Explanation of the principal Terms uſed in fortification, digeſted in an alphabetical manner - - - - - 218

A TREATISE

A

TREATISE

CONTAINING

The Elementary PART

OF

FORTIFICATION.

SECT. I.

Of Practical Geometry.

DEFINITIONS.

1. EXTENSION is diſtinguiſhed into *length*, *breadth*, and *thickneſs*, which are called *dimenſions*. Plate A.

2. A *line* has only length, as AB.

3. The terms or bounds of a line are called *points*, and have no dimenſions.

4. A *ſurface* has length and breadth only, as C.

The bounds of a ſurface are lines.

5. A *ſolid* has length, breadth, and thickneſs, as D.

The bounds of a ſolid are ſurfaces.

6. A *right-line* is the ſhorteſt that can be drawn from one point to another.

7. *Parallel lines* are thoſe which are every where equidiſtant, although produced *ad infinitum*, as AB, CD.

8. A *plane ſurface* is that which lies evenly between its bounds, and agrees with a right line placed on it according to any poſition.

9. The opening of two lines, which meet each other in a point, is called an *angle*, as A.

N. B. An angle is generally expreſſed by three letters, as ABC, with the letter expreſsing the angular point in the middle.

10. If a line CD meets another line AB, ſo that the angles CDA, CDB, are equal; that line CD, is ſaid to be *perpendicular* to the other AB.

And the equal angles CDA, CDB, are called *right angles*.

But if the line is oblique, as DE, the greateſt angle EDA, is called an *obtuſe* angle; and the leaſt EDB, an *acute* angle.

11. A plane ſurface terminated by three right lines, is called a *plane triangle*.

12. When the three ſides of a triangle are equal, it is called an *equilateral triangle*, as C.

13. When only two ſides are equal, an *iſoſceles triangle*, as A.

14. When the three ſides are unequal, a *ſcalene triangle*, as B.

15. When one angle of a triangle is a right angle, it is called a *right-angled* triangle, as D.

16. Any one ſide of a triangle may be called the *baſe*, and the angular point oppoſite to the baſe, is called the *vertex*.

17. In a right-angled triangle, the ſide oppoſite to the right angle, is called the *hypothenuſe*.

18. A plane of four ſides, is called in general a *quadrilateral* figure.

19. A quadrilateral, whoſe four ſides are equal as well as the four angles, is called a *ſquare*, as A.

20. If the four angles are equal, and only the oppoſite ſides a *rectangle*, as B.

21. If the oppoſite angles are only equal, and the oppoſite ſides a *parellelogram*, as C.

22. A plane figure of above four ſides, is called in general a *polygon*.

23. A *circle* is a plane figure bounded by one continued line ABC called the *circumference*, which is every where equally diſtant from a point O within the circle, called the *center*.

24. Any line, as AO, drawn from the center to the circumference, is called a *radius*.

25. Any line, as AB, terminating in a circle, it called a *chord*, which divides the circle into two parts, ABC, ADB, called *ſegments*; the parts of the circumference, terminated by the chord, are called *arcs*, and when the chord paſſes through the center, it is called a *diameter*, and divides the circle into two equal parts, called *ſemicircles*.

26. Any part of the circle, as AOB, terminated by two radii and an arc, is called a *ſector*.

27. The meaſure of an angle is the arc deſcribed from the angular point as center with any radius, and terminated by the lines which form the angle.

28. A line AT, which touches a circle in one point A only, is called a *tangent*; and the point A, where it touches, the point of *contact*.

29. The line CT drawn from the center and terminated by the tangent, is called the

ſecant

ſecant of the arc AM, as AT is called its *tangent*, and the perpendicular PM to the radius CA the *ſine*, CP the *coſine*, and AP the *verſed ſine* of that arc, or of the arc BM, its ſupplement to a ſemi-circle.

30. A polygon is called *regular*, when all its ſides are equal as well as all its angles; and *irregular*, when they are unequal.

31. A polygon is ſaid to be *inſcribed* in a circle, when all its angles touch the circumference; and *circumſcribed* about a circle, when all its ſides touch the circle.

Polygons are diſtinguiſhed by the number of their ſides, viz.

5	Pentagon.	9	Enneagon.
6	Exagon.	10	Decagon.
7	Eptagon.	11	Ondecagon.
8	Octagon.	12	Dodecagon.

Problems uſeful in Fortification.

1. *To draw a line, through a given point* C, *perpendicular to another line* AB.

From the given point C as center, deſcribe an arc with any radius ſo as to meet the line AB, in two points E,F, and from theſe points as centers, deſcribe two arcs with the ſame

radius, ſo as to interſect each other at D; then the line drawn through this interſection and the given point C will be the perpendicular required.

2. *To draw a line, through a given point* C, *parallel to another line* AB.

From the given point C as center, deſcribe an arc ſo as to touch the line AB, and from any point E in AB as center, deſcribe another arc with the ſame radius; then the line drawn through the given point C, ſo as to touch this arc, will be the parallel required.

3. *To divide a given line* AB, *into any number of equal parts, as five.*

Through the extremity A draw a line AC at pleaſure ſo as to make any angle with AB, and through the other extremity B, draw BD parallel to AC: then if from the point A towards C, there be ſet off as many equal parts leſs one of any length, on AC, as the line AB is to be divided into, and the ſame thing be done on the line BD; the lines which join the oppoſite points will divide the line AB into the deſired number of equal parts.

4. *To divide a given angle* ACB *into two equal parts.*

From

From the angular point C as center, deſcribe an arc with any radius, meeting the legs of the angle at A,B: from theſe points as centers, deſcribe two arcs with the ſame radius, ſo as to interſect each other at D; then the line drawn through this interſection and the angular point C, will biſect the given angle.

5. *To draw a line* CA, *ſo as to make an angle* ACB, *with a given line* CB, *equal to a given angle* a c b.

From the points C, c, as centers, deſcribe two arcs with the ſame radius taken at pleaſure: make the arc AB equal to the arc a b; and the line drawn through the points C, A, will make the angle required.

N. B. Mathematicians ſuppoſe the circumference of a circle to be divided into 360 equal parts called degrees, each degree divided into 60 equal parts called minutes, as likewiſe each minute into 60 equal parts called ſeconds.

Theſe diviſions are generally marked on a braſs ſemi-circle or a rectangular piece of ivory, called protractor, and ſerve either to meaſure any angle by, or to lay down any angle on paper.

Hence a quadrant or the meaſures of a right angle is 90 degrees, as being the fourth

part of the circumference; a ſemi-circle or the meaſure of two right angles 180; and becauſe the three angles of a triangle being equal to two right ones, each of the angles of an equilateral triangle, is one third of 180; that is, 60 degrees, or the ſixth part of the whole circumference.

6. *To biſect a line* AB, *by a perpendicular to it.*

From the extremities A, B, as centers, deſcribe arcs on both ſides of that line, with any radius ſo as to interſect each other at D, and E; then the line DF will be perpendicular to and biſect AB.

7. *To deſcribe the circumference of a circle, through three given points* A, B, C.

Join theſe points by two lines AB, BC; biſect theſe lines by the perpendiculars DO, EO; then their interſection O, will be the center of the circle deſired.

8. *To inſcribe a ſquare in a circle.*

Draw the diameter AB, to which draw the diameter CD perpendicular; then the lines joining the extremities of theſe diameters will be the ſquare ABCD required.

If the quadrant AC be biſected in E, the chord AE or EC will be the ſide of an octagon, inſcribed in the circle.

9. *To*

9. *To inſcribe a pentagon or a decagon in a circle.*

Draw the radius DC at right angles to the diameter AB, biſect AC in E, and from the point E as center, deſcribe an arc through the point D meeting the diameter AB in F, draw DF; then will DF be the ſide of the pentagon, and CF that of the decagon inſcribed in the circle.

10. *To inſcribe an exagon in a circle.*

Take the radius AO and carry it round the circumference, and you will have the exagon required.

If the arc AB be biſected at D, the chord of the arc AD or DB, will be the ſide of a dodecagon inſcribed in the circle.

N. B. The eptagon, enneagon, and ondecagon, cannot be geometrically inſcribed in a circle; for which reaſon we ſhall give mechanical conſtructions of them, which are ſufficiently exact for practice.

11. *To inſcribe an eptagon in a circle.*

From any point A in the circumference as center, deſcribe an arc through the center O, meeting the circumference in B and C; draw CB and the radius AO; then the half BD or DC of BC will be the ſide of an eptagon nearly.

12. *To*

12. *To inſcribe an enneagon in a circle.*

Carry the radius from A to B, and divide the arc AB into three equal parts, by repeated trials; and let A a be two thirds of AB; then the chord A a, will be the ſide of the enneagon exactly, if A a is exactly two thirds of AB.

13. *To inſcribe an ondecagon in a circle.*

Draw the radius CD, perpendicular to the diameter AB; from the extremity B as center, deſcribe an arc through the point D, meeting the diameter in E, at E erect a perpendicular EF, to the diameter, or draw EF parallel to CD, meeting the circumference in F; then if the arc AF be biſected in G, the chord of AG or GF will be the ſide of the ondecagon required.

14. *To inſcribe a polygon in a circle, ſo that its ſides ſhall be of a given length.*

Inſcribe a ſimilar polygon, that is, one of the ſame number of ſides, in any circle by the foregoing problems; and let AB be one of thoſe ſides, which produce to C ſo as BC be equal to the given ſide, and draw CD parallel to the radius OB, till it meets the radius OA produced at D; then OD will be the radius of the circle required.

This

This problem is eaſier ſolved by means of a ſector, in this manner. On the inner edge is a line marked polygon, whoſe numbers anſwer from a ſquare or pentagon to a dodecagon; you take the length of the ſide of the polygon which is to be inſcribed in a circle, between the points of your compaſs; and ſet one point upon the number of the ſides on the ſector, and open the ſector ſo as the other point of the compaſs meets the ſame number on the other leg of the ſector; then keeping the ſector thus open, you take the opening from 6 to 6 on the ſector between the points of your compaſs, and that will be the radius of the circle wanted.

DEFINITIONS.

The angle ABC made by any two contiguous ſides of a polygon, is called the *angle of the polygon*; and the angle AOB made by two radii drawn to the extremities of the ſame ſide of a polygon, is called the *angle of the center*.

The angle of the center of a regular polygon is found, by dividing 360 degrees by the number of the ſides: thus 360 divided by 5 gives 72 degrees for the angle of the center of

Of the meaſures and ſcales uſed in Fortification.

The *French* make uſe of a meaſure called a *toiſe*, which is ſix feet, and therefore, is what we call a *fathom* here in *England*.

The *Dutch*, and moſt of the *Germans*, make uſe of the *Rhinland rod*, which is 12 Rhinland feet.

The *French* royal foot is to the *Engliſh* foot, as 114 to 107, or as 16 to 15 nearly, in ſmaller numbers.

The Rhinland foot is to the *French* foot, as 1033 to 1068, or as 29 to 30 nearly, in ſmaller numbers; and therefore, half the Rhinland rod is to a *French* toiſe, as 29 to 30 nearly.

As we propoſed to give Mr. *Vauban's* conſtructions, with thoſe of the moſt celebrated authors of that nation, we ſhall uſe the word toiſes in this work, as being more convenient for underſtanding their methods than that of fathom; the valuation of the *French* into *Engliſh* meaſure, may be eaſily made by the proportion given above.

When a plan of a fortification is to be drawn, which is to be executed, it will be con-

convenient to have a ſcale divided into equal parts; as for example, an inch divided into 20, 25, 30, 35, 40, 45, 50, 55, 60: then that of 40 to an inch is to be uſed in this caſe, in order to expreſs every part diſtinctly, which cannot ſo well be done upon a ſmaller one.

When a plan is to be drawn upon any other occaſion, any other ſcale will do, which may be greater or leſs, according as it is thought moſt convenient.

The profiles are generally drawn upon a ſcale of thirty feet to an inch; becauſe they are to expreſs the heights of the different parts, which cannot ſo well be done upon a leſſer.

If a ſcale ready divided cannot be had, or ſuch a one as may be wanted upon a particular occaſion, there muſt be one made on ſtrong paper, by the help of the third problem.

Colours uſed in the drawings of Fortifications.

It is neceſſary to uſe colours in the drawings of plans and profiles of a fortification, in order to diſtinguiſh every particular part, and ſeparate, as it were, the one from the other,

ſo as to make their difference more ſenſible. The manner of uſing colours, is called *colouring*.

The firſt and moſt neceſſary thing required in drawing, is *Indian ink*; for it ſerves, in drawing the lines, to expreſs hills or riſing grounds, and in ſhort, for all what is called ſhading in drawings.

There are ſix different ſorts of colours, generally uſed in theſe kinds of drawings, viz. *carmine*, *verdegreaſe*, *ſap-green*, *gum-bouch*, *indigo*, and *umber*.

The beſt ſort of Indian ink is of a bluiſh black, ſoft, and eaſily reduced into a liquid, free from ſand or gravel; it is ſold in ſticks at various prices, according to its goodneſs and quantity.

The manner of liquefying it, is by putting a little clear water into a ſhell or tea-cup, and rubbing it gently till the water is black, and of a conſiſtence much like common ink; when it is uſed for drawing lines, it muſt be made very black, though not too thick, otherwiſe it will not eaſily flow out of the drawing pen: but when it is for ſhading, it muſt be pale, ſo as to go over the ſame ſhade ſeveral times, which will make it look much finer and ſofter than if it was done at once.

Carmine

Carmine is in powder, and the fineſt red we know of; it ſerves for colouring the ſections of maſonry, the plans of houſes, and other buildings; as likewiſe their elevations, but is then made of a paler colour.

This colour is alſo uſed for drawing red lines in plans, to repreſent walls: it is very dear, being generally a guinea an ounce, but a little goes a great way.

The verdegreaſe uſed in drawings, which is commonly called *ſea-green*, is liquid, and ſold in little vials at a ſmall price; it ſerves to colour wet ditches, rivers, ſeas, and in general to repreſent all watery places.

Sap-green is in ſtone, of a yellowiſh green, when liquefied with clear water; but when it is mixt with ſome ſea-green, it makes a fine graſs green; as all mixt colours are liable to fade, if *verd'iris* can be had, it will be much better; ſap-green is very cheap, for a trifle, one may have as much as will ſerve a great while.

Gum-bouch, is a fine yellow in ſtones, and very reaſonable; it ſerves to colour all projects of works; as likewiſe to diſtinguiſh the works unfiniſhed from thoſe that are ſo. It ſerves alſo to colour the trenches of an at-

This

This colour is prepared, by taking water in a hair pencil, and rubbing it gently, then putting it in a ſhell, and this is repeated till the colour is as ſtrong as is neceſſary.

Indigo is in ſmall cakes, and very cheap; it ſerves to colour iron and roofs of buildings, which are covered with ſlates: it muſt be well ground upon a ſmooth ſtone or glaſs, and then mixt with a little gum-water.

If the ſea-green is too pale, by mixing a little indigo with it, it will make a fine bluiſh colour.

Umber is a yellowiſh brown colour in powder; when it is mixt with gum-water, it ſerves to colour dry ditches, ſand, and all things of earth. By mixing a little red ink with it, it will alſo make a wood colour. If ſome tobacco leaves are ſteept in clear water for ſome hours, and filtered through a woollen cloth, or brown paper, with a little red ink mixt in it, it makes the beſt earth or wood colour, as lying ſmoother than any other.

In drawing encampments, it is neceſſary to have a fine blue, to repreſent the colour of blue cloth; *ſmalt*, ſold in ſhells at a ſmall price, is very good for that purpoſe, or elſe *Pruſſian blue*, well ground and mixt with a little gum-water.

Gum-water is beſt when it is made ſome time before it is uſed; for which reaſon, take ſome gum-arabic, and ſteep it in clear water for ſome hours till it is diſſolved; then ſtrain it through a woollen cloth or brown paper, and preſerve it in a vial, well ſtopped, that no dirt can come into it, till it is wanted.

SECTION II.

Of regular Fortification.

FOrtification, is the art of incloſing towns with works in ſuch a manner, as that a ſmall number of men may reſiſt, for ſome time, a conſiderable army.

The attack of a place, is the art of making and conducting all the different works in a ſiege, in order to become maſter of the place.

And the defence of a place, is the art of defending a town beſieged, with all the advantages that the fortification will admit of.

The art of fortification may be diſtinguiſhed into two parts, *viz.* the elementary or theoretical, and practical.

The elementary part conſiſts in tracing the plans and profiles of a fortification on paper, with ſcales and compaſſes; and to examine the ſyſtems propoſed by different authors, in order to diſcover their advantages and diſadvantages.

And the practical part conſiſts in forming a project of a fortification, according to the nature of the ground and other neceſſary circumſtances, to trace it on the ground, and to execute the project, together with all the military buildings, ſuch as magazines, ſtorehouſes, bridges, *&c.*

It is the elementary part which we propoſe to treat of in this work, reſerving the other for a ſecond volume, which we ſhall divide into regular and irregular fortification; but before we enter any farther upon the ſubject, it will not be diſagreeable to beginners to ſay ſomething concerning the riſe and progreſs of fortification.

The origin and riſe of fortification is undoubtedly owing to the degeneracy of mankind; for in the firſt ages of the world, men were diſperſed up and down the countries in ſeparate families, as we are told in the hiſtories of the Jews and Scythians, who wandered from one place to another for the ſake of find-

ing paſture for their cattle. Theſe families became in time ſo numerous as to form large communities, which ſettled altogether in a place; from whence villages and towns had their origin and riſe; but they found it was neceſſary, for the common ſecurity, to ſurround thoſe towns with walls and ditches, to prevent all violences, *and ſudden ſurprizes from their neighbours.* This was ſufficient for ſome time, till offenſive weapons were invented, and conquering became a faſhion; then walls with loop-holes were made at proper diſtances, in order to ſcreen the defenders againſt the arrows of the aſſailants; but finding that as ſoon as the enemy got once cloſe to the walls, they could from no part be diſcovered or repulſed; for this reaſon they added ſquare towers at proper diſtances from each other, ſo that every part of the wall might be defended by the adjacent ſides of the towers. However, this manner of incloſing of towns was found to be imperfect, becauſe there remained ſtill one of the faces of the towers which fronted the field that could not be ſeen from any other part, and therefore could not be defended. To remedy this, they made the towers round inſtead of ſquare, imagining this figure to be the ſtrongeſt to reſiſt the

the battering engines, as likewiſe to be better defended from the other parts of the wall.

Notwithſtanding the ſuperiority of this method above the former, there remained yet a part of theſe towers unſeen and uncapable to be defended; which made them change the figure of the towers again; that is, they made them ſquares as before; but inſtead of preſenting a face to the field as formerly, they preſented an angle; by this means they effectually found out ſuch a diſpoſition of their works, that no part could be attacked without being ſeen or defended by ſome other part.

This laſt method was in uſe a long while, and would in all appearance have continued to this day, if 'gunpowder had not been found out: but the violence of the guns and mortars ſoon convinced the world, that ſuch towers and walls were but a weak defence againſt theſe thundering engines; and beſides, as the nature of the attack was entirely changed, it was alſo neceſſary to change that of fortifying likewiſe.

From that time, ramparts were added to the walls, the towers enlarged into baſtions, and all ſorts of outworks have been added, ſuch as ravelins, counterguards, horn and

crown-works, and others of the like nature, in order to render the defence in ſome meaſure equivalent to the attack.

Notwithſtanding all the improvements which have been made in the art of fortifying ſince the invention of gunpowder, that of attacking is ſtill ſuperior to it. Engineers have tried in vain to render the advantages of a fortification equal to thoſe of the attack; the ſuperiority of the beſiegers fire, together with the greater number of men, obliges generally, ſooner or later, the beſieged to ſubmit.

The greateſt improvement made in the art of attacking happened in the year 1697, when M. *Vauban* made firſt uſe of ricochet firing at the ſiege of *Ath*, whereby the beſieged, placed behind the parapets, were as much expoſed to the fire of the beſiegers, as if there had been none; whereas, before, they had been ſecure as long as the parapet was not demoliſhed: and the worſt is, that there can be no remedy found to prevent this enfilading, without falling into inconveniencies almoſt as bad as thoſe which we endeavour to avoid.

Although authors agree as to the general form in the preſent manner of fortifying, yet they moſtly differ in particular conſtructions of the parts; as it would be both needleſs and




Fig. 3
O
P
m
1
Fig. 1
b
C
H
a
B

and ſuperfluous to treat of all the different methods hitherto propoſed, we ſhall content ourſelves with explaining thoſe only, which are moſt eſteemed by the beſt judges, and have been moſtly put in practice; with adding obſervations on their perfections and imperfections, and point out how ſome of the parts may be improved.

As M. *Vauban* had more experience than any other engineer whatſoever, and his methods are moſtly uſed all over *Europe*, we preſume it will be more advantageous to beginners to explain his methods firſt; and then thoſe of Mr. *Coehorn*, who, next to M. *Vauban*, excelled in this art.

M. *Vauban* has given three different methods; the firſt is that which has been uſed in the fortifying of moſt places; the ſecond was uſed at *Landau* and *Beford*, chiefly deſigned for places which have a wall or rampart already; and the third has been applied in the fortifying of *New Briſach*; each of theſe methods will be treated of ſeparately, in their order.

Conſtruction of M. VAUBAN's *firſt Method.*

This method is divided into little, mean, and great; the little is chiefly uſed in the con-

AB being biſected by the perpendicular CD as before, ſet off 30 toiſes from C to D, and draw the indefinite lines ADG, BDF, in which take the parts AE, BH, each equal to 50 toiſes; from the center E deſcribe an arc through the point H, meeting AD in G, and from the center H deſcribe an arc through the point E, meeting BD in F; or which is the ſame, make each of the lines EG, HF, equal to the diſtance EH; then the lines joining the points A, E, F, G, H, B, will be the principal or outline of the front.

If the ſame conſtruction be performed on the other ſides of the polygon, you will have the principal or outline of the whole fortification.

If, with a radius of 20 toiſes, there be deſcribed circular arcs, from the angular points B, A, M, T, and lines are drawn from the oppoſite angles E, H, &c. ſo as to touch theſe arcs, their parts a b, b, c, &c. together with theſe arcs, will repreſent the outline of the ditch.

N. B. In any other polygon, beſides the exagon, the radius cannot be equal to 180 toiſes; and in that caſe the radius muſt be found, ſo as to anſwer to a given ſide of 180 toiſes, by Problem 14.

DEFI-

DEFINITIONS.

1. The part FEALN, is called the *baſtion*.
2. AE, AL, the *faces* of the baſtion.
3. EF, LN, the *flanks*.
4. FG. the *curtain*.
5. FN, the *gorge* of the baſtion.
6. AG, BF, the *lines of defence*.
7. AB, the *exterior ſide of the polygon*.
8. CD, the *perpendicular*.
9. Any line which divides a work into two equal parts, is called the *capital* of that work.
10. a b c, the *counterſcarp* of the ditch.
11. A, M, the *flanked angles*.
12. H, E, L, the angles of the *ſhoulder*, or *ſhoulder* only.
13. G,F,N, the *angles* of the *flank*.
14. Any angle whoſe point turns from the place, is called a *ſaliant angle*, ſuch as A, M; and any angle whoſe point turns towards the place, *re-entering angle*, ſuch as b, F, N.
15. If there be drawn two lines paralle to the principal or outline, the one at 3 toiſes diſtance, and the other at 8 from it; the the ſpace y x included between the principa , and that fartheſt diſtant, is called th rt.

And

And the ſpace x x, contained by the principal line, and that next to it, and which is generally ſtained black, is called the *parapet*.

16. There is a fine line drawn within four feet of the parapet, which expreſſes a ſtep called *banquette*.

N. B. All works have a parapet of three toiſes thick, and a rampart of 8 to 10, beſides their ſlopes. The rampart is elevated more or leſs above the level of the place, from 10 to 20 feet, according as the nature of the ground is, and according to the particular conſtructions of engineers.

The parapet is a part of the rampart elevated from 6 to $7\frac{1}{2}$ feet above the reſt, in order to cover the troops, which are drawn up there, from the fire of the enemy in a ſiege; and the banquette is two or three feet higher than the rampart, or about four feet lower than the parapet; ſo that when the troops ſtand upon it, they may juſt be able to fire over the parapet.

17. The body of the place, is all that which is contained within this firſt rampart; for which reaſon it is often ſaid to conſtruct the body of the place; which means properly, the conſtruction of the baſtions and curtains.

18. All

18. All the works which are conſtructe beyond the ditch, before the body of th place, are called *outworks*.

TABLE

	Forts.							Little Fortif.				Mean.		Great.	
Side of Polyg.	80	90	100	110	120	130	140	150	160	170	180	190	200	260
Perpendiculars	10	11	12½	14	15	16	20	21	23	25	30	31	25	22
Faces baſt.	22	25	28	30	33	35	40	42	45	47	50	53	55	60
Cap. of ravel.	25	28	30	35	38	40	45	50	50	52	55	55	60	50

In the firſt vertical column are the numbers expreſſing the lengths of the exterio ſides from 80 to 260.

I

In the ſecond, the perpendiculars anſwering to theſe ſides.

In the third, the lengths of the faces of the baſtions; and in the fourth, the lengths of the capitals of the ravelins.

The forts are moſtly, if not always, ſquares, for which reaſon, the perpendiculars are made one eighth of the exterior ſides; becauſe, if they were more, the gorges of the baſtions would become too narrow.

The little fortification, is chiefly deſigned for citadels, and are commonly pentagons; the perpendiculars are made one ſeventh of the exterior ſide; the mean is uſed in all kinds of fortifications, from an exagon upwards to any number of ſides; and the great is ſeldom uſed but in an irregular fortification, where there are ſome ſides that cannot be made leſs without much expence; or in a town which lies near a great river, where the ſide next the river is made from 200 to 260 toiſes; and as that ſide is leſs expoſed to be attacked than any other, the perpendicular is made ſhorter, which ſaves much expence.

The faces of the baſtions are all $\frac{2}{7}$ths of the exterior ſides, or nearly ſo, becauſe the fractions are neglected.

It

It may be obſerved in general, that in all ſquares the perpendicular is $\frac{1}{8}$th of the exterior ſide, in all pentagons $\frac{1}{7}$th, and in all the reſt upwards $\frac{1}{6}$th.

Conſtructions of Orillons and retired Flanks.

Deſcribe the front MPQRST as before, and divide the flank into three equal parts, of which ſuppoſe S r to be one; from the oppoſite flanked angle M, draw a line M r, in which take the part m r of 5 toiſes; take likewiſe R n in the line of defence M R, produced, equal to 5 toiſes, and join n m, upon which as a baſe deſcribe the equilateral triangle n p m, and from the angle p, oppoſite to the baſe as center, is deſcribed the circular flank, n m.

And if S r be biſected by the perpendicular, 1, 2, and another be erected upon the face ST, at S; the interſection 2 of theſe two perpendiculars, will be the center of the arc which forms the orillon.

The orillons are very uſeful in covering the retired flanks, which cannot be ſeen but directly in the front; and as theſe orillons are round, they cannot be ſo eaſily deſtroyed,

as

as they would be, if they were of any other figure. But for what reaſon the retired flanks are made of ſuch circular arcs as theſe, is not poſſible to be gueſt at; ſince it may eaſily be proved, as we ſhall do in the third ſection, that the flank made upon the chord of that arc would be much better, and is at the ſame time of leſs expence.

But what is more ſtrange, that moſt engineers look upon theſe flanks as the beſt that could have been thought of, and they uſe them in all fortifications, which they propoſe as the beſt models: there can be given no other reaſon of this opinion, than the unaccountable fancy, of mankind in general, for novelty; and their indolence to receive from others, things for true, rather than to inquire whether they be ſo or not.

Conſtruction of Ravelins or Half-moons.

Set off 50 toiſes, from the re-entring angle O of the counterſcarp, on the capital OL of the ravelin, or on the perpendicular produced, and from the point L draw lines to the ſhoulders A,B; whoſe parts LM, LN, terminated by the counterſcarp, will be the faces MO, ON, the ſemi-gorges of the ravelin required. Fig. 2.

This



Fig. 6



Fig. 5



Fig. 2

Conſtruction of Tenailles.

A tenaille is a work made in the ditch before the curtains, the parapet of which is only 2 or 3 feet higher than the level ground of the ravelin. There are three different ſorts: the firſt are thoſe as in fig. 1, which are made in the direction of the lines of defence, leaving a paſſage of 3 toiſes between their extremities and the flanks of the baſtions, as likewiſe another of 2 in the middle for a bridge of communication to the ravelin. Plate II. Fig. 1, 2, 3.

The ſecond ſort, are thoſe as in fig. 2; their faces are in the lines of defences, and 16 toiſes long, beſides the paſſage of 3 toiſes between them and the flanks of the baſtions; their flanks are found by deſcribing arcs from one ſhoulder of the tenaille as center through the other, on which are ſet off 10 toiſes for the flanks deſired.

And the third ſort, are thoſe as in fig. 3; their faces are 16 toiſes, as in the ſecond ſort, and the flanks are parallel to thoſe of the baſtions.

The uſe in general of tenailles, is to defend the bottom of the ditch by a grazing

counterſcarp of the ditch, for one of its faces; the other face PN, is found by making the ſemi-gorge TP of 25 toiſes; the ditch before the lunettes is 12 toiſes, the parapet 3; and the rampart 8; as in the ravelin.

There is ſometimes another work made to cover the ſaliant angle of the ravelin, ſuch as A, called *Bonnet*, whoſe faces are parallel to thoſe of the ravelin, and when produced biſect thoſe of the lunettes; the ditch before it is 10 toiſes.

Fig. 5. There are likewiſe lunettes, ſuch as D, in fig. 5, whoſe faces are drawn perpendicular to thoſe of the ravelin, within a third part from the ſaliant angle; and their ſemi-gorges are only 20 toiſes.

Theſe kind of works may make a good defence, and are no very great expence; for as they are ſo near the ravelin, the communication with it is very eaſy, and one cannot well be maintained, till they are all three taken.

I would have the face PN (fig. B) perpendicular to that of the baſtion, which would then defend it in a direct manner; and if the ſemi-gorges of the bonnet A were only 7 or 8 toiſes, it would become leſs expenſive, and its ditch and the covert-way before it would be better defended by the lunettes.

Con-

Conſtruction of Tenaillons.

Produce the faces of the ravelin beyond the counterſcarp of the ditch, at a diſtance MN of 30 toiſes, and take on the counterſcarp of the great ditch, 15 toiſes from the re-entering angle p to q, and draw Nq; then qNMp will be the tenaillon required; its ditch is 12 toiſes, that is, the ſame as that of the ravelin. Sometimes there is made a retired battery, in the front of the tenaillons, as in fig. B; this battery is 10 toiſes from the front to which it is parallel, and 15 toiſes long. Fig. 6.

There are commonly retrenchments made in the tenaillons, ſuch as O; their parapets are parallel to the fronts MN, or rather perpendicular to the ſide Nq, and biſect the ſide qN; the ditch before this retrenchment is 3 toiſes, and there is a banquette before the parapet, next to the ditch, of about 8 feet, called *Berm*; it ſerves to prevent the earth of the parapet (which ſeldom has any revetement) from falling into the ditch.

It is to be obſerved, that the ravelin, before which tenaillons are conſtructed, muſt have its ſaliant angle much greater than the former conſtruction makes them; otherwiſe

the ſaliant angles of the tenaillons become too acute, for which reaſon we made the capital of this ravelin 45 toiſes, and the faces terminate within 3 toiſes of the ſhoulders.

Conſtruction of Counterguards.

late III. fig. 1, 2. When the counterguard is placed before the ravelin, ſet off 40 toiſes on the capital of the ravelin from the ſaliant angle A, to the ſaliant angle B, of the counterguard; and 10 from C to D, on the counterſcarp of the ditch.

When the counterguard is before the baſtion, ſuch as in fig. 2, its ſaliant angle F, is 50 toiſes from the ſaliant angle E of the baſtion, and the breadth near the ditch of the ravelin is 10 toiſes as before.

The ditch before the counterguards is 12 toiſes, and its counterſcarp parallel to the faces.

Counterguards are made before the ravelin, in ſome particular occaſions only, but are frequently conſtructed before the baſtions; as covering the flanks wonderfully well. Some authors, as *Blondel*, and M. *Coehorn*, will have them much narrower than they are here.

Con-

Plate III.



Conſtruction of Hornworks.

Produce the capital of the ravelin beyond the ſaliant angle A, at a diſtance AB of about 80 toiſes; draw DBE, at right angles to AB; in which take BD, BE, each equal to 55 toiſes; and on the exterior ſide DE, trace a front of a polygon in the ſame manner as that of the body of the place, making the perpendicular BF 18 toiſes; and the faces 30. Fig. 3.

The branches Da, Eb, of the hornwork, when produced, terminate on the faces of the baſtions, within 5 toiſes of the ſhoulders. The ditch of the hornwork is 12 toiſes, and its counterſcarp parallel to the branches; and in the front terminates at the ſhoulders, in the ſame manner as the great ditch before the baſtions.

The capital of the ravelin before the front of the hornwork is 35 toiſes, and the faces terminate on the ſhoulders, or rather 2 or 3 toiſes beyond them: and the ditch before the ravelin is 8 toiſes.

There are ſometimes retrenchments made within the hornwork, ſuch as S, S; which are conſtructed by erecting perpendiculars to

the faces of the ravelins, within 25 toiſes of their extremities. This retrenchment, like all others, has a parapet turfed only with a berm of 8 feet before it; as likewiſe a ditch from 3 to 5 toiſes broad.

g. 4. When a hornwork is made before the baſtion; the diſtance DL, of the front from the ſaliant angle of the baſtion, is 100 toiſes; and the branches terminate on the faces of the adjacent ravelins within 5 toiſes from their extremities; all the reſt is the ſame as before.

Conſtruction of Crownworks.

late IV, ig. 1. From the ſaliant angle A of the ravelin, as a center, deſcribe an arc of a circle with a radius of about 120 toiſes, cutting the capital of the ravelin produced at C; from the point C, ſet off the cords CB, CF, each of them equal to 110 toiſes, and on each of which, as an exterior ſide, conſtruct a front of a polygon of the ſame dimenſions as in the hornwork; that is, the perpendicular ſhould be 18 toiſes, the faces 30, and the branches terminate on the faces of the baſtions, within 25 toiſes of the ſhoulders.

The ditch is 12 toiſes, the capital of the ravelin 35, and its ditch 8; that is, the ſame as in the hornwork.

Some-

Plate IV.



Fig. 1

Sometimes the crownwork is made before the baſtion, as in fig. 2; the arc is deſcribed from the ſaliant angle A, of the baſtion, with a radius of 120 toiſes, as before, and the branches terminate on the faces of the adjacent ravelins, within 25 toiſes of their extremities; the reſt of the dimenſions and conſtructions are the ſame as before. Fig. 2.

Hornworks, as well as crownworks, are never made, but when a large ſpot of ground falls beyond the fortification, which might be advantageous to an enemy in a ſiege, or to cover ſome gate or entrance into a town; they have notwithſtanding been uſed without judgment in ſeveral places, as at *Tournay*, *Ipres*, &c. Their advantages and diſadvantages ſhall be fully diſcuſſed in the third ſection.

Conſtruction of Covert-ways and Glacis.

Although we have not hitherto mentioned the covert-way, nevertheleſs, all fortifications whatſoever have one; for they are eſteemed to be one of the moſt eſſential parts of a modern fortification; and it is certain, the taking the covert-way, when it is in a good condition and well defended, is generally

generally the moſt bloody action of the ſiege.

Plate V. After having conſtructed the body of the place, and all the outworks which are thought neceſſary, lines are drawn parallel to the outmoſt counterſcarps of the ditches, at 6 toiſes diſtant from it; and the ſpace m n m n, included between that line and the counterſcarp, will be the covert-way required.

There is in every re-entering angle of the counterſcarp a place of arms, m; which is found by ſetting off 20 toiſes from the re-entering angle a, on both ſides from a to b, and from a to c; and from the points b, c, as centers, arcs are deſcribed with a radius of 25 toiſes, ſo as to interſect each other in d; then the lines drawn from this interſection to the points b, c, will be the faces of the places of arms.

If lines are drawn, parallel to the lines which terminate the covert-way, and the places of arms, at 20 toiſes diſtant from them, the ſpace x, x, x, between theſe lines and thoſe which terminate the covert-way, will be the glacis.

At the extremities of the places of arms, are traverſes made, ſuch as v, v, which ſerve to incloſe them; theſe traverſes are 3 toiſes thick,

thick, and as long as the covert-way is broad, and a paſſage is cut in the glacis round them, of about 6 or 8 feet, in order to have a free communication with the reſt of the covert-way.

There are alſo traverſes of the ſame dimenſions before every ſaliant angle of the baſtion and outworks, and are in the ſame direction of the faces of thoſe works produced; and the thickneſs lies at the ſame ſide as the parapets.

The paſſages round theſe laſt traverſes are likewiſe from 6 to 8 feet wide.

In each place of arms are two ſally-ports z, z, which are 10 or 12 feet wide, for the troops to ſally out; in time of a ſiege they are ſhut up, with barriers or gates.

Conſtruction of Arrows, and detached Redoubts.

An arrow is a work made before the ſaliant angles of the glacis, ſuch as A; it is compoſed of a parapet of 3 toiſes thick, and 40 long, and the ditch before it 5 toiſes, terminating in a ſlope at both ends. The communication from the covert-way into theſe arrows, is 4 or 5 toiſes wide, and there

there is a traverſe r at the entrance of 3 toiſes thick, with a paſſage of 6 or 8 feet round it.

A detached redoubt is a kind of work much like a ravelin, with flanks placed beyond the glacis, ſuch as fig. B; they are made in order to occupy ſome ſpot of ground which might be advantageous to the beſiegers; likewiſe to oblige the enemy to open their trenches farther off than they would do otherwiſe.

Their diſtance from the covert-way ought not to exceed 120 toiſes, that it may be defended by muſket-ſhot from thence.

The gorge a b is 40 toiſes, the flanks a c, b f, which are perpendicular to the gorge, 10, and the faces c d, f d, 30; the ditch before it is 6 toiſes, ending in ſlopes at both ends; the covert-way 4; the branches of the covert-way is 42 toiſes long, or thereabouts; the faces of the places of arms y, y, which are perpendicular to the branches, 10; and the other, which is parallel to them, 14.

The communication from the covert-way into the redoubt, is 5 or 6 toiſes wide; and there is a traverſe made juſt at the entrance; and another in the middle, when it is pretty long. The parapets of this communication terminate in a ſlope or glacis.

If


Tab V.
d
b
a
Müller delin.
sculp.




D

If theſe redoubts are above 50 toiſes diſtant from the covert-way, the beſiegers carry their trenches round, and enter through the gorge; by which the troops that are in them are made priſoners of war, if they do not retire betimes: to prevent this, ſome other outworks ſhould be made to ſupport them.

Conſtruction of Second Ditches, and Covert-ways.

When the ground is low, and water to be found, there is often a ditch of about 10 or 12 toiſes made round the glacis; and oppoſite to the places of arms are conſtructed lunettes, beyond the ditch, ſuch as D, whoſe breadth on the counterſcarp of the ditch is 10 toiſes, from b to a, and from c to d, and the faces aL, dL, are parallel to thoſe of the places of arms; the ditch before them is from 8 to 10 toiſes wide. Plate VI.

The ſecond covert-way is 4 toiſes, the ſemi-gorges of the places of arms m about 15, and the faces perpendicular to the counterſcarp; the ſecond glacis is from 15 to 18 toiſes broad.

This ſecond covert-way has traverſes every where, in the ſame manner as the firſt.

Theſe

Theſe are nearly all the different outworks, which are uſed now-a-days, in the conſtruction of places: although they are generally ranked among M. *Vauban*'s works, yet none are of his invention, except the conſtruction of the body of the place, and the circular flanks; for all the reſt are to be met with in *Dilichiu's Peribologia*, printed at *Frankford* in 1640: and it may be obſerved, that M. *Vauban* has chiefly copied this author, as *Coehorn* did *Spekel*.

Conſtruction of Profiles.

Plate VII. A profile is the repreſentation of a vertical ſection of a work; it ſerves to ſhew thoſe dimenſions which cannot be repreſented in plans, and are neceſſary in the building of a fortification; they are generally conſtructed upon a ſcale of 30 feet to an inch. It would be needleſs to deſcribe all their particular dimenſions, ſince they are marked in the ſchemes; we ſhall therefore lay down the principal rules only, given by M. *Vauban*, on this ſubject.

1. Every work ought to be at leaſt 6 feet higher than that before it, ſo that it may command thoſe before it; that is, that the garriſon

garriſon may fire from all the works at the ſame time, with great and ſmall arms, at the beſiegers in their approaches: notwithſtanding this ſpecious pretence, there are ſeveral authors, who object againſt it. For they ſay, if you can diſcover the enemy from all the works, they can diſcover by the ſame reaſon all the works from their batteries; ſo that they may deſtroy them, without being obliged to change their ſituation, and thereby diſmount all the guns of the place before they come near it.

But if all the works were of the ſame height, thoſe within cannot be deſtroyed, till ſuch time that thoſe before them are taken; guns might be placed in the covert-way and outworks to obſtruct the enemy's approach, and when they come near the place, they might be tranſported into the inner works; and as the body of the place would be much lower, the expence would be conſiderably diminiſhed.

But when works are low, they are eaſily enfiladed by the ricochet batteries, which is a kind of firing, with a ſmall quantity of powder, by giving the gun an elevation of 10 or 12 degrees: this might, however, be partly prevented, by making the parapets

The ſeventh plate repreſents in milit perſpective the profiles of the body of a pla the ravelin and covert-way, which give clear idea of what is meant by a profi and from which thoſe of all other wo may be eaſily conceived.

M. *Vauban* gives in the following ta the dimenſions of walls from 10 to 80 f high, from 10 to 10 feet.

Height of the wall.	Thickneſs above.	Thickneſs below.	Diſtances between the centers of the counterforts.	Diſtances between the centersof the counterforts.	Length of the counterforts.	Thickneſs near the wall.	Thi nef the en
10	5	7	18	15	4	3	2:
20	5	9	18	15	6	4	2:
30	5	11	18	15	8	5	3:
40	5	13	18	15	10	6	4:
50	5	15	18	15	12	7	4:
60	5	17	18	15	14	8	5:
70	5	19	18	15	16	9	6:
80	5	21	18	15	18	10	6:

All theſe numbers are feet, except in laſt column, which are feet and inch M. *Vauban* adds, that when the ſtone bric

te VII.

vith Revetement.



demi-Revetement.

brickwork is very good, the thickneſs of the wall above may be reduced to $4\frac{1}{2}$ feet or 4 only; but when it is bad it may be increaſed to $5\frac{1}{2}$ feet, and ſometimes more.

That the counterforts at the ſaliant angles ſhould be well braced or bound together.

When the ramparts are partly turfed and partly walled, he makes the intervals between the centers of the counterforts but 15 feet; but when they are walled quite up to the top, theſe diſtances are 18 feet.

Theſe dimenſions have been uſed in the conſtructions of a great many places, and the walls have never failed; it may however be demonſtrated, that his low walls are too ſtrong, and the high ones too weak; but this ſubject ſhall be examined in the ſecond book, where practical fortification is treated of.

As M. *Vauban* has conſtructed the foregoing tables from practice and his own obſervations only, and not by the help of theory, without which it is impoſſible to arrive to any degree of perfection; the dimenſions contained therein are moſtly erroneous, which indeed appears by mere inſpection; for that all walls of any heights ſhould have the ſame thickneſs at top, is contrary to ſenſe and reaſon. Beſides, he makes no diſtinction

between ſtone and brick walls, although ſtones are ſpecifically heavier than bricks, and conſequently need not be made ſo ſtrong. For which reaſon we have inſerted tables for ſtone and brick walls in the ſecond volume of this work, which treats of the practice of fortification, deduced from theory and the moſt approved practice.

Conſtruction of M. Vauban's *ſecond method, with Tower-baſtions, according to the plans of* Landau *and* Befford.

This method is adapted to the fortifying of places built already; for which reaſon he begins his conſtruction inwards, and fortifies outwards, contrary to his other methods, as being more convenient for that purpoſe.

Pla. VIII. Let AB be the interior ſide of an exagon of 120 toiſes, ſome authors will have it 130, and ſay that they are ſo at *Landau*; draw AC, BD, from the center through the extremities of the ſides: ſet off 6 toiſes from A to b, and from B to c; through the points b and c, draw lines at right angles to AB, from the point b ſet off 6 toiſes to f outwards, and 4 from b to d inwards; and from the points

Plate VIII.





thod of M.
uban.

points f, d, draw perpendiculars f r, d n, to the capital AC; then if r E is made equal to r f, the point E will be the ſaliant angle of the tower baſtion; and E f d n half that tower.

If in the capitals, there be taken from the ſaliant angles of the tower baſtions, the diſtances EC, FD, each of 40 toiſes, the points C and D will be the ſaliant angles of the counterguards before the towers: from the points C and D draw the lines of defence C c, D b, to the points where the flanks of the towers cut the curtain; and which ſet off 56 toiſes for the faces of the counterguards, the flanks are found as in the firſt method, and likewiſe the tenailles.

The ditch before the ſaliant angles of the towers is 6 toiſes, and its counterſcarp drawn to the extremities of the flanks of the counterguards; the right line which joins the ends of theſe flanks will determine the inſide of the tenailles.

The ditch before the counterguards is 12 toiſes at the ſaliant angles, and the counterſcarp is drawn to the oppoſite ſhoulders in the ſame manner as in the firſt method.

The capital of the ravelin is 45 toiſes, its faces, when produced, terminate on thoſe of the counterguards, within 10 toiſes of the

ſhoulders; 10 toiſes are cut off from the faces by the flanks which are parallel to the capital as uſual.

The ditch before the ravelin is 10 toiſes, the covert-way 5, the ſemi-gorges of the places of arms 12, the faces 17, and the glacis 20.

Conſtruction of M. Vauban's *third method, according to the plan of* New-Briſach.

Plate IX. This method is applied to an octagon, whoſe exterior ſide AB is 180 toiſes, the perpendicular CD 30; the faces AK, BL, of the counterguards 60: the flanks LN, KM are found by ſetting off 22 toiſes, as chords to the arcs deſcribed from the oppoſite ſhoulders as centers: from the extremities of the flanks a line is drawn, which will be parallel to the exterior ſide AB, meeting the capitals AE, BF of the counterguards at G and H; this line terminates the inſide of the tenaille, as likewiſe the ſaliant angles G, H of the tower baſtions.

If EF be drawn parallel to GH, and at 9 toiſes diſtant from it, the interſections E,F, with the capitals of the counterguards, will be



de Vauban.

If from the points C, D, fig. 1, there be ſet off on the lines of defence 14 toiſes to the points Y, W; and upon each of the baſes YI, WK be deſcribed an equilateral triangle, the angles oppoſite to theſe baſes, will be the centers of the higher flanks YI, WK.

And if R be the interſection of the two lines of defence, RM biſected at S, and RC at Q; by drawing SQ, *v*SQR will be half the tenaille; and drawing from the point C, a line parallel to IY, ſo as to meet the tower, upon which the mean flank is deſcribed in the ſame manner as the former.

Fig. 2. The parapets of the three flanks, and thoſe of the parts m V, VM, of the towers, are 24 feet thick; the other parts M r, r n m, but 16; and all the other parapets in general are 20 feet.

There is a wet ditch before the mean flank of 6 toiſes broad, and another z, behind the towers of the ſame breadth, over which are made two draw-bridges, parallel to the higher faces.

The ſpace X between the higher and lower faces of the baſtions is a dry ditch, whoſe bottom is but 6 inches above the ſurface of the water in the wet ditch.

Behind



Behind the lower parapet there is a banquette of 3 feet, and a rampart of 5; and under this rampart a ſtone gallery, which runs from one end to the other, and is divided into ſeveral apartments, which are ſhut with doors; as likewiſe another, going from the ſaliant angle of the lower faces, to that of the higher, with loop-holes from diſtance to diſtance facing the dry ditch; there is likewiſe a row of paliſades placed parallel to the higher faces, and at 4 toiſes diſtant from them.

There are three embraſures in O r, as has been ſaid, to flank the ditch z behind the towers; and two in IO to flank the dry ditch near the higher faces.

The great ditch is 24 toiſes broad; and its counterſcarp parallel to the lower faces of the baſtions; the ſemi-gorges OL of the ravelin are 29 toiſes, and the faces LP, 45; the dry ditch Y is 16 toiſes, the rampart 28 feet, and the lower faces a T are parallel to the higher ones; the parapet of which is 20, and the banquette 3.

The level ground of the rampart in the ravelin near the ſaliant angle is 20 feet broad, for the length of 20 toiſes from that angle, and the reſt but 15.

In

In the gorge of the ravelin is a ſmall redoubt *a*, of about 5 feet high, and underneath a lodgment of ſtones, the walls being 18 inches thick at the ſides; the roof is made of planks, with 3 feet of earth over them.

There is a dry ditch going from the extremities of the faces to the redoubt, and round its angle, having a row of paliſades before it, to ſecure the retreat from the ravelin into this redoubt; there is likewiſe another row going from the extremities of the faces, in a round form, turning towards the gorge of the ravelin.

In the dry ditch of the ravelin, within 6 toiſes from the great ditch, is a coffer, and a ditch p of 6 toiſes before it: this coffer has a wall on both ſides, and the roof is planked and covered with a foot and a half of earth; above this, is a ſtone parapet of 5 feet high, with a banquette behind it.

There runs a covered gallery under the rampart of the lower faces, and another joining the two ſaliant angles, together with a row of paliſades, in the ſame manner as in the dry ditch before the baſtions.

The wet ditch before the ravelin is 18 toiſes; the counterguards *x*, which the author calls *cover-faces*, are 25 feet broad, and

the


E
M
Z
S
G
O
I
T
Fig. 2.
Villers del in.
Le Sc.



the ditch before them 14 toiſes; the covert-way is 12 toiſes broad, and the glacis 20: the ſemi-gorges f g, g h, of the places of arms, are 22 toiſes, and are taken from the point g, where the branches of the covert-way meet, and the faces f k, h k, are 28; within theſe places of arms are traverſes of 20 feet thick and 18 toiſes long, within 10 or 12 feet from, and parallel to the faces.

The ſtone lodgments b, within the places of arms, are found by ſetting off 12 toiſes from the point g, for the ſemi-gorges, and the faces are drawn parallel to thoſe of the places of arms.

At 6 toiſes from the places of arms, are coffers q of 8 feet broad, made with planks at the ſides, and above with a foot of earth over and before them.

There are two banquettes all round the covert-way, and before the traverſes; as alſo two rows of paliſades before the traverſes, one of which joins them, and the other goes round the covert-way.

Laſtly, the re-entering angles of the counterſcarp next to the covert-way are made a little round, as likewiſe that in the ravelin; but the contrary way, that is, they are made hollow.

Conſtruction of M. Coehorn's *ſecond method.*

Pl. XIII. The author ſuppoſes an eptagon, whoſe interior ſide is 126 toiſes, and the level of the ground to be 3 feet above the ſurface of the water.

Let, therefore, the interior ſide A B of an eptagon be 126 toiſes, take in the capitals, AC, BD, each of 72 toiſes; at the extremities C, D, make the angles ACE, BDF, each of 40 degrees; and ſet off 66 toiſes for the faces CE, DF of the baſtions; on the interior ſide, take AG, BH, each of 30 toiſes, and from the point D, as center, deſcribe an arc through the point G, on which ſet off a chord of 30; and on this chord deſcribe the mean flank GI, which is an arc of 60 degrees.

Draw a line from the ſaliant angle D through the extremity I of this flank, on which take I a of 10 toiſes; join a E, on which deſcribe the orillon as uſual.

The outline of the higher flank is 13 toiſes diſtant from that of the outline of the mean; this flank is an arc deſcribed from the ſame center as that of the former, the chord of which is 40 toiſes.

From

From the points G, H, draw the broken parts of the curtain perpendicular to the capital of the baſtion, and make it 9 toiſes long; the extremity of the higher flank is terminated by the inſide line of the parapet of the curtain produced.

The tenaille is found by producing the faces of the baſtions 10 toiſes; through the extremity of which, an arc is deſcribed from the oppoſite ſaliant angle of the baſtion, as center; on this arc is ſet off a chord of 20 toiſes; and this chord ſerves to deſcribe the flank, upon which is an arc of 60 degrees; the curtain is a right line.

There is a wet ditch before the tenailles of 10 toiſes broad, with two bridges at each end, near the orillons; the one directly over it, and the other along the faces of the baſtion.

The dry ditch round the body of the place is 20 toiſes broad, before the faces of the baſtion to which it is parallel, and the lower rampart KL, 29 feet; the ſemi-gorges ML are 15 toiſes, and the flanks LN, 18, and are deſcribed from the ſaliant angles K of the lower faces as centers.

The ſaliant angle of the ravelin is 125 toiſes diſtant from the curtain of the body of

of the place, and is 70 degrees; the faces are 50 toiſes long; the faces of the redoubt x, are 16 toiſes diſtant from thoſe of the ravelin, and 14 long.

The wet ditch round the lower faces of the ravelin is 24 toiſes broad: the work beyond this ditch, which the author calls the ſecond counterſcarp, is 20, parallel to the ditch.

To find the broken part of this work, join the two re-entering angles, m, r; on which take m r, of 30 toiſes, and draw r t, r v parallel to the outline of the counterſcarp, each equal to 12; ſet off 22 from t to s, and from v to q; and upon theſe lines as chords deſcribe the round flanks, which are arcs of 60 degrees.

The traverſes in this counterſcarp are drawn at 10 toiſes from the flanks perpendicular to the parapet.

The redoubt z in the re-entering angles, are found by ſetting off 16 toiſes from the points m to n, for their capitals, and the faces are parallel to the broken curtain before them: thoſe marked y, which are in the ſaliant angles, are found by producing the counterſcarps of the great ditch, and ſetting off 12 toiſes from the points of their interſections for their faces;

and

Plate XIII.

od.

J. Mynde sc.

and the flanks are drawn parallel to their capitals.

The ditch before this work is 14 toiſes; as to the covert-way and glacis, they are the ſame as in the author's firſt method.

Conſtruction of M. Coehorn's *third method.*

The author ſuppoſes an octagon, whoſe interior ſide AB is 110 toiſes; the ſemi-gorges A n, B m, 21; the capitals AC, BD, of the baſtions 64; and the ſaliant angles 85 degrees; the faces CE, DF of the baſtions 54 toiſes; the parts Qs, Qr of the tenaille 32; the lower flanks, that is, thoſe of the tenaille, are found by deſcribing arcs through the points s, r, from the oppoſite ſaliant angles DC, on which are 20 toiſes ſet off as chords; and theſe chords ſerve to deſcribe arcs of 60 degrees upon, for the required flanks. Pl. XIV.

From the extremities v, t, of theſe flanks, lines are drawn to the oppoſite angles D, C, and 6 toiſes ſet off from v to q; and upon q E the orillon is deſcribed as uſual.

The higher flanks are deſcribed from the ſame centers, as the lower through the ex-

tremities n, m of the curtain; and their chord is 30 toiſes.

The wet ditch before the body of the place is 20 toiſes, and its counterſcarp parallel to the faces of the baſtions.

The capital VW of the detached baſtion is 100 toiſes; the faces are directed to the ſaliant angles of the inner baſtions; the dry ditch behind the lower faces in the detached baſtions is 20 toiſes; and the higher faces are parallel to the lower, and 31 toiſes long: the towers x, and the ditch before them, are made in the ſame manner as in the firſt method. To find the flanks, make the ſemi-gorges Va, Vb, each 38 toiſes, and draw the chords of theſe flanks parallel to the capital VW; and from the extremities of the higher faces draw alſo lines to the former, upon which the flanks are deſcribed as uſual.

The counterſcarp of the ditch before the redoubt z, is drawn from the extremities of the flanks parallel to the faces; and at 6 toiſes from this, the faces of the redoubt are drawn; 4 toiſes of which are cut off for the flanks.

The ditch before the detached baſtion is 24 toiſes; the ravelins, counterguards, covert-way,

Plate XIV.

J. Mynde sc.

way, and glacis, are the ſame here as in the firſt method.

There are little pits or ponds l, l, dug between the higher and lower curtains, to hold water, in order to prevent the paſſing from the tenailles to the flanks.

SECT. III.

Containing the general Maxims of Fortification, applied in the Remarks on the preceding Authors, and others mentioned hereafter.

IN learning fortification, with an intention to make any progreſs in it, it is not ſufficient to be capable of drawing lines, and to know the names of the different works; but it is neceſſary to be well acquainted with the principles or foundation on which the perfection and imperfection of a work depends; to be able to give reaſons for what is done, and to be in a condition to judge upon good grounds, what is good and what is not ſo, in the various manners of fortifying, by all the different authors who have wrote on this ſubject.

There are three conſiderations eſſentially required in a good and well-ordered fortification, without any of which it can never anſwer the ends propoſed.

The firſt is, the EXPENCE neceſſary for the building of it: for ſhould that be greater than the importance of the place requires, it is plain that ſuch a place would be of no advantage.

The ſecond is the NUMBER of troops, to guard and to defend it: for if a place ſhould require ſo many, as that the expence, together with providing it with artillery, ammunition, and ſtores, be equal to, or exceed the revenue or advantage ariſing from ſuch a place, it is manifeſt, that inſtead of being an advantage, it would be a diſadvantage.

And the third is, the CAPACITY of the town with regard to the ſpace taken up by the fortification; for if it ſhould happen that the town could not contain a ſufficient number of troops to defend it, beſides the inhabitants, it is evident that it may be taken with leſs expence than another of fewer works, provided with the ſame number of troops; and therefore, ſuch a fortification will not anſwer the ends propoſed in fortifying it: St. *Philip*'s Caſtle in *Minorca* is an inſtance of

this ſort; and ſuch are M. *Coehorn*'s ſyſtems, as we ſhall ſhew hereafter.

If the queſtion was only to fortify a town ſtrongly, without any other conſiderations, one might make outworks upon outworks without end; but if it is conſidered, that a whole ſtate might be exhauſted in the building of one ſingle fortification, and which would require a whole army to defend it, it will eaſily appear, that the ſtrength and bigneſs of a fortified place ought abſolutely to depend on the importance it will prove to a nation.

Beſides the general conſiderations, there are ſeveral particular ones; which are neceſſary in the well-ordering all the different parts, ſo as to make the beſt defence that can be for a place of that expence.

1. There ought to be no part, but what can be ſeen or defended by ſome other; which in the phraſe of fortification is, all parts ſhould flank each other reciprocally; for flanking or defending is the ſame thing.

For if there is any part that is not ſeen or defended, the enemy might approach that way under cover, and make themſelves maſters of it, without much trouble or loſs.

2. The defence of every part ſhould be always within the reach of muſket-ſhot, ſo as to be defended both by great and ſmall fire arms; for if it be only defended by cannon, the enemy may diſmount them by the ſuperiority of theirs, and then the defence would be deſtroyed at once; whereas, if a work is likewiſe defended by ſmall arms, then, if the one is deſtroyed, the other will ſtill ſubſiſt.

3. All the defences ſhould be as nearly direct as poſſible; for it has been found by experience, that the ſoldiers will fire directly before them, without troubling themſelves whether they do execution or not; there are other advantages in a direct defence, as we ſhall prove in the following propoſitions.

4. A fortification ſhould be equally ſtrong on all ſides, otherwiſe the enemy may attack it in the weakeſt part, whereby its ſtrength would become uſeleſs.

In a regular fortification where all ſides are equally fortified, it cannot happen otherwiſe than to be every where equally ſtrong: but it is not ſo in the irregular, which requires great ſkill and knowledge to make a place ſo; and no author, that I know, has ſhewn how, and in what manner, we are to judge of the ſtrength

Fig. 1.





lin.

ſtrength of the ſeveral parts in ſuch a fortification, although they all agree to the importance of that maxim.

There are commonly ſeveral other maxims given by authors, which, in my opinion, ought rather to be proved, than only aſſerted.

PROPOSITION I.

Of two batteries which have equal fronts, that whoſe fire is direct is the moſt advantageous.

For let AB be an object to be fired at, from the battery CD equal in front; then I ſay, that this battery CD, which is directly oppoſite to AB, is more advantageous than any oblique one, as CL, whatſoever. Plate XV.

For if CD be divided into any number of equal parts, ſuch as c a, a b, *&c.* and from theſe points perpendiculars are drawn to CD, interſecting CL, in c, d, *&c.* then, if each of theſe parts of CD is the ſpace neceſſary for one gun, or for one man; it is evident, that each of the correſponding parts C c, c d, of CL, will likewiſe be neceſſary for one gun, or for one man: from whence it reſults, that there can be no more guns or men placed on the

oblique battery CL, ſo as to fire at the object AB, than on the direct one CD.

Now becauſe the oblique battery CL is longer, and therefore of more expence than the direct one CD; and as the troops placed on the battery CL, fire with more uncertainty, eſpecially when they are in a hurry, and in danger, than if they were placed behind CD, where they only fire directly forward; it evidently follows, that the direct battery CD is more advantageous than any oblique one whatſoever.

N. B. As the parapets are 3 toiſes, or 18 feet thick, it is not only uncertain, that the ſoldiers in a hurry fire at an object obliquely ſituated, but likewiſe very difficult and troubleſome; ſo that beſides the advantage of a direct defence, mentioned in the laſt propoſition, this one is as much eſſential as any.

PROPOSITION II.

If the object AB be a counter-battery, the direct battery CD is ſtill preferable to any oblique one CL whatſoever.

Let BE be perpendicular to CL produced; then the force, whereby a cannon-ſhot from

from the battery AB would ſtrike the battery CD, is to the force it would ſtrike the oblique battery CL, as BL to BE; or becauſe of the ſimilar triangles BLE, CLD, as CL to CD; that is, reciprocally as the lengths of the batteries.

But the reſiſtances of the batteries are reciprocally as the forces whereby they are ſtruck, and therefore directly as the lengths or expences.

But the reſiſtances of theſe batteries are only at the beginning, as the expences; for as ſoon as the leaſt breach is made in the wall, they are nearly equal: beſides, if the guns of the battery AB fire directly, as they eaſily may, except the battery CL is very oblique, the reſiſtances will be equal from the beginning; and as the guns are as eaſily diſmounted on the oblique battery CL, as on the direct one CD, it evidently follows, that the direct battery CD, is more advantageous than the oblique one CL.

COROLLARY.

From whence it follows, 1°. that if the fire from the battery CD is to be directed towards a point A, the battery CD ought to be Fig. 2.

be an arc of a circle, deſcribed from that point A, as center.

2°. And if the fire from the battery CD is to be directed to a line EF, of a greater or leſſer extent than the battery, it ought again to be an arc of a circle, ſuch that the radii CA, DA, drawn from its extremities, ſhall paſs through the extremities E, F of the object, and make equal angles therewith.

PROBLEM.

To determine the ſeveral parts of a front of a fortification.

Fig. 3. I. It is evident, that every part of the front AEFGHB, diſpoſed in the manner deſcribed before, is ſeen and defended by ſome other part, as well as the ditch before it; for the flank GH, defends the ditch from the perpendicular CD to the face EA produced, as well as that face itſelf; the flank EF and half the curtain, and the flank EF defends the other half of the ditch from CD to the face HB produced, that face the flank HG and half the curtain; and conſequently no part of this front can be approached, without being ſeen and defended by ſome other part.

II. The

II. The next thing to be conſidered, is the length of the lines of defence AG, FB, which ſome will have to be within muſket-ſhot, and others longer; the firſt ſay, that the principal ſtrength of a fortification conſiſts in the uſe of ſmall arms, becauſe the guns fire but ſlowly, are ſoon diſmounted, and require much time to be remounted; whereas the fire from ſmall arms is very briſk, and when one man is killed, another takes his place immediately; this is anſwered, that cannon does greater execution, and requires much trouble to make an epaulement to reſiſt their force, whereas a moderate epaulement is a ſufficient cover againſt ſmall arms: beſides, when the lines of defence are of a ſufficient length, the ſeveral parts of the fortification become ſpacious and more convenient for placing both more guns and men in them; it alſo obliges the enemy to extend their trenches much farther, than if theſe lines were ſhorter.

But it is evident that, although the lines of defence are within muſket-ſhot, there may be placed both ſo many men and cannon as are neceſſary to defend the works; and the works are likewiſe ſpacious enough for all other purpoſes.

From

From whence it is concluded, that the length of the lines of defence ſhould not exceed the reach of muſket-ſhot, which is commonly obſerved now-a-days; except when the front lies near a great river, and can hardly be attacked on that ſide, there they are often made longer.

It has been found by experience that a common muſket-ſhot will hardly kill a man at a greater diſtance than 160 fathoms Engliſh meaſure; and therefore the lines of defence ought not to exceed that length when the front can be approached.

III. The length of the faces AE, BH ſhould be ſuch, that the flanks are of a ſufficient length, and the gorges of the baſtions not too narrow: they are never made leſs than 50 toiſes, nor greater than 70, in a fortification whoſe exterior ſide is 180 toiſes or upwards.

But as to the length of the perpendicular CD, it is no ways determined; for ſome engineers make it twice as long as others: they ſeem indeed to differ from one another merely out of contradiction; ſince none of them, that I know of, has given any reaſons for this practice; although it be plain, that the longer this perpendicular is, the greater the

the flanks will be, and therefore the defence ſo much the greater likewiſe.

But then the expences increaſe alſo in proportion, and conſequently the length of the perpendicular ſhould be determined according to the expence which a ſtate will be at, and according to the importance of the place.

IV. The poſition of the flanks is no more certain than the reſt, ſince almoſt all engineers differ from one another in that reſpect: although it is evident that there muſt be a certain and determined poſition better than any other.

For if their uſe be conſidered, the poſition will eaſily be known, as they are to defend the ditch before them: and it is a received maxim in fortification, that the direct defence is the beſt; and we have proved in the two foregoing propoſitions, that it has ſeveral advantages above an oblique one: it follows from the corollary after theſe propoſitions, that the flanks ſhould be an arc of a circle deſcribed from the point of interſection, of the line of defence and oppoſite counterſcarp produced, as center: or, becauſe this arc differs but little from its chord, a right line which makes equal angles with the line

its ditch and covert-way would be greater, and the beſiegers would find leſs room in them for batteries.

The faces of the lunettes ſhould be one perpendicular to the face of the ravelin, and the other to that of the baſtion, in order to be defended in a direct manner, which ought to be obſerved in all works, if poſſible.

Some authors object againſt the lunettes on account that the ditch, which is defended by the ravelin, has no defence left as ſoon as the ravelin is taken; but as it is hardly poſſible to take the ravelin without being maſter of the lunettes, their objection is of no conſequence; and ſhould the beſieged be imprudent enough to paſs by the lunettes without taking them, they muſt certainly ſuffer much more than if they had.

The counterguards before the ravelins are but ſeldom made; for a redoubt within the ravelin anſwers the ſame purpoſe, and is leſs expenſive: but as to thoſe before the baſtions, they are ſome of the beſt of all outworks, when they are well conſtructed; ſince the enemy cannot pretend to make a breach in the baſtion, nor deſtroy the flanks before they are maſters of the counterguard; and then they have not a ſufficient ground to make

make batteries in them to deſtroy the flanks and make a breach.

All tenaillons and counterguards ſhould have retrenchments, ſuch as that markt by the letter K, fig. 6, in the ſecond plate: for by this means their defence becomes much more conſiderable than without them. This the *French* have done in the counterguards lately conſtructed before the baſtions at *Lille*, and in the tenaillons at the front, which was attackt by Prince *Eugene* and the Duke of *Marlborough* in Queen *Anne*'s war; when theſe tenaillons made one of the beſt defences that ever was known.

M. *Blondel*, and after him M. *Coehorn*, make their ramparts ſo narrow, as to leave no room to place guns upon them; and this is to prevent the beſiegers from erecting batteries there, whereby they will be obliged to bring earth from the covert-way, in order to deſtroy the flanks. But as theſe counterguards are only defended in the front by ſmall arms, they can make no great reſiſtance; beſides, the beſiegers may make a few mines under them, and ſo blow up as much as will diſcover the faces and flanks from the covert-way; whereas, if their ramparts are 7 or 8 toiſes broad, they cannot be deſtroyed

by mines; and there will nevertheleſs not be ſufficient room to erect batteries in them to deſtroy the flanks.

I would chuſe to make theſe counterguards as high as the baſtions themſelves, in order that the enemy might not diſcover the baſtions but from within the counterguards; by which means the fire of the whole baſtion would defend the counterguards in ſuch a manner, as to make it almoſt impoſſible to make any lodgment there.

The horn and crown works are chiefly made to take away a ſpot of ground which might be advantageous to the enemy; to cover the gates of a town, or to build ſtore-houſes and hoſpitals in them.

The flanks are too ſmall, as well as the fronts themſelves, and the ditches before the branches are too obliquely defended: the retrenchments made in them are very good, to retire behind when the work is taken, and to diſturb the lodgments made there.

Theſe kind of works ought never to be made but upon the above-mentioned occaſions; for their building is very expenſive and cheaper works would be of a much better defence; notwithſtanding M. *Vauban* has too profuſely made them, in the fortifica-

tions of *Tournay*, *Ipres*, and in ſeveral other places; and placed them often ſo near each other, as would incline one to believe, that he rather intended more to terrify an enemy by their number, than to ſtrengthen the place.

The covert-way ſeems to be of a ſufficient breadth to contain the neceſſary troops to defend them, and the traverſes are abſolutely neceſſary for their defence; contrary to the opinions of M. *Coehorn* and others; for without them the covert-way may be enfiladed by the ricochet batteries, from one end to the other: beſides, when the ſaliant angle is attacked, the beſieged have a ſecure retreat behind them; and ſo may be defended to the laſt extremity; experience has ſufficiently proved their uſefulneſs, for at *Liſle* a traverſe was three times taken and retaken.

M. *Vauban* invented three different manners of covering the paſſages round the traverſes at the ſaliant angles; the one by cutting the paſſes out of the glacis, as in plates VIII. and IX, the other by making a kind of ſhoulder before them, and the third in the form of the teeth of a ſaw, which he calls *en Cremaille*, ſo as the paſſage may be ſeen

and defended from behind the traverſe which forms the place of arms at the re-entering angle; which is undoubtedly preferable to the other two, and has been practiſed in all the fortifications built in latter times.

I am not ignorant that the whole front of the covert-way is ſometimes attacked at once; in ſuch a caſe the traverſes ſeem to be uſeleſs; but as this only happens when the garriſon is very weak, or the enemy preſumptuous and unſkilful, they generally pay dear for their raſhneſs, and ſeldom can maintain their ground. Beſides, the beſiegers may drive the troops out of the covert-way with their ricochet batteries, when they are as yet far off, ſo that it is of no manner of uſe after the ſecond or third day of the attack; but to prevent the traverſes being uſeful to the beſiegers in covering them, I would chuſe to make a ſmall mine under them, and when they can no longer be defended, to blow them up.

The arrows and detached redoubts are of no great expence; and nevertheleſs are very good in hindering the enemy from beginning their trenches too near, and to diſturb them in their approaches; but the redoubts are liable to be ſurrounded by the trenches and taken

taken by the gorge, if they are not well protected from the covert-way or ſome other outwork; for which reaſon they ſhould never be farther from the covert-way than about 50 toiſes; and if they were mined ſo as to be blown up when they can be no longer defended, they would afford no ſhelter to the enemy when they are taken.

As to the ſecond ditch and covert-way, they being works only made of earth, are of no great expence, and yet may make a very good defence, eſpecially when the ſlope of the firſt glacis goes as low as the ſurface of the water; or when the water can be raiſed in time of a ſiege, ſo as to overflow the beſt part of the firſt glacis; it would oblige the enemies to bring earth from the ſecond glacis to retrench themſelves upon the firſt, which would coſt them a good deal of time and trouble; and as this muſt be done under the grazing fire of the covert-way, it could not be done without much coſt and danger: the ſecond covert-way ſhould be not above a foot above the ſurface of the water in the ditch, to oblige the enemy to bring earth for making their trenches in it.

M. *Vauban* was ſo ſenſible of the goodneſs of theſe works, that he never failed to make

them where-ever he found the ground convenient for it; as may be ſeen at *Sarre Louis*, at the city of *Liſle*, and in other places.

Remarks on M. VAUBAN'*s ſecond and third methods.*

The deſign of the ſecond method is to fortify an old town already incloſed by a rampart; and it is for that reaſon that he begins within and fortifies outwards, contrary to his other methods, as being more convenient in this caſe: the tower-baſtions are joined to the old wall, and have underneath a magazine in the form of a croſs; all round this magazine are caſemats, or cellars, to hold both men and guns; thoſe in the flanks have each an embraſure which opens into the ditch, and thoſe in the faces have embraſures ſo as to fire out of one into the other when taken by the enemy; and above is a parapet of 12 feet thick with embraſures, as may be ſeen in plate XI, where a plan and ſection of a tower-baſtion is repreſented.

As theſe towers are almoſt a ſolid bulk of maſonry, they muſt be of great expence, though their reſiſtance can be but little; for it has been found by experience, that the caſemats

mats are but of little uſe, becauſe as ſoon as they have fired once or twice, the ſmoak will oblige the defenders to leave them, notwithſtanding their ſmoak-holes.

In my opinion, inſtead of attacking the towers themſelves, the ramparts near the flanks of the counterguards may be attacked; and then the flanks of the towers may be deſtroyed by the guns placed on the flanks oppoſite to them, which are already made for that purpoſe, and want nothing elſe but embraſures.

It may be concluded, that the ſtrength of theſe towers does by no means anſwer their expences, and that if ſmall baſtions were made inſtead of them, without caſemats, they would be much better, and of leſs expence.

As to the counterguards, they are very good, and may be defended to the utmoſt extremity without expoſing the town to be taken by ſtorm; but their flanks are too ſmall, and are eaſily deſtroyed from the oppoſite covert-way; there ſhould either be two, or if but one, it ſhould be pretty large.

M. *Vauban* conſidering, that as ſoon as a breach was made in the faces of the baſtions, and the paſſage over the ditch finiſhed, the garriſon

ſhall now proceed to ſhew the advantages and diſadvantages of the particular parts.

We ſhall begin with ſhewing that the expence which he pretends to be much leſs in the building of this fortification, than that of the *French* method, is not ſo inconſiderable as he fain would perſuade the world: firſt the room within for buildings, is to that taken up by the fortification, as one to three nearly, rather more than leſs; and as he makes his inward polygon equal to that of M. *Vauban*'s exagon; and we have found, that the inward polygon is to the ſpace taken up by the fortification, as unity to $1\frac{1}{2}$; the fortification of M. *Coehorn*'s method takes up juſt as much ground again as that of M. *Vauban*, and therefore double the expence for removing the earth; but then he ſays, that much leſs maſonry is required here than there, and it is upon this he grounds his frugality; but it has been found by experience, that works of earth coſt as much in time, as thoſe made of ſtone, on account of their continual repairing; ſo that in the whole it appears, that M. *Coehorn*'s exagon coſts more, or at leaſt as much as M. *Vauban*'s exagon; then if we conſider the lowneſs of theſe works, and how eaſily they may be ſurpriſed, they will

will require at leaſt three times the number of troops and ammunition to defend them, as the *French* one.

For when a place is out of danger from being ſurpriſed, there requires but a few troops to guard the works which are not attacked; whereas, on the contrary, the others muſt be every where equally guarded; otherwiſe the beſiegers may make a ſham attack on one ſide to draw the beſieged that way, and ſurpriſe ſome of the works on ſome other ſide.

The next thing is to examine whether the different works are conſtructed in the beſt manner: firſt, as to the upper and mean flanks, they ſeem to be the only thing the author borrowed from the *French*, and is juſt the worſt of all M. *Vauban*'s works, as we have ſhewn heretofore: the curtain of the tenaille would have been better ſtraight than crooked; the towers being but ſmall, and a parapet quite round them, are very dangerous, and a fair mark for throwing ſhells, by which there is no ſecurity for thoſe within; the dry ditches and lower faces of the baſtions and ravelin are eaſily enfiladed by the ricochet batteries: and the paliſades placed in them, to ſecure a ſafe retreat, are very dangerous; becauſe if a ſhot hits them, the ſplinters will do more miſ-

miſchief than the ſhot itſelf; as to the caſe-mats in the towers, they are very bad, as we have ſhewn before, ſpeaking of the tower-baſtions; the ſtone galleries made under the ramparts of the lower faces of the baſtions and ravelins, ſeem to be uſeleſs, on account of the ſmoak, for the ſame reaſon as all caſe-mats are; and if ſome grenadiers go between the loop-holes and fling a few grenades into them, they muſt infallibly deſtroy thoſe within.

The redoubt in the gorge of the ravelin is of excellent uſe to ſecure a ſafe retreat to the beſieged, which is in my opinion of the greateſt conſequence; for if the troops have no retreat, they can never defend a work ſo well as they might do otherwiſe.

The wet ditch before the lodgment and the dry ditch of the ravelin, are in a wrong place, ſince they are directly oppoſite to the ditch before the counterguards; and theſe lodgments themſelves being only a ſtone wall, are eaſily deſtroyed by the ricochet batteries.

The rampart of the counterguards being only 28 feet broad, including the parapet, they are eaſily deſtroyed by mines, as we have mentioned before, ſpeaking of counter-guards; no cannon can be placed in them; neither are their ditches defended by cannon, except

except from the higher faces of the ravelin; and as to the covert-way, it is by much too ſpacious, and liable to be enfiladed from the beginning of the ſiege, by the ricochet batteries placed before the firſt parallel; ſo that of this ſpacious work, there are only the places of arms which can make a defence; the redoubts in the places of arms being incloſed quite round, are dangerous to defend, for a few ſhells thrown into them muſt inevitably deſtroy thoſe within, or oblige them to quit the work; and they are contrary to the general maxim of fortification, that no part whatſoever ſhould be ſo as not to be ſeen or flanked by ſome other; but here, if the enemy gets once poſſeſſion of theſe redoubts, the walls near the counterſcarp will cover them in ſuch a manner, as not to be ſeen from any part of the fortification.

As to the coffers made in the glacis, they cannot much retard the approaches of the enemy, being only defended by ſmall arms; ſo that a few gabions filled with earth will eaſily cover the beſiegers againſt the fire of theſe works.

It is moſt certain, that when M. *Coehorn* publiſhed his book, he knew nothing of the ricochet firing, the invention of which being of

of later date; and therefore was not aware of the inconveniencies which attend now-a-days theſe low works; otherwiſe he would never have made uſe of them; and it is undoubtedly for this reaſon, that he never put them in practice afterwards, when he was acquainted with this manner of firing; the manner of fortifying *Bergen-op-zoom* differs ſo little from M. *Vauban*'s firſt method with orillons, that I took it for the very ſame till I was better informed; and this place is undoubtedly a maſter-piece of art.

The comparing of this method with the *French* exagon, fortified with ravelin and covert-way only, is not juſt; for the one takes up twice as much ground, and requires about three times more troops to defend it than the other, and therefore there ought to be no more compariſon between them, than there is between a place of few works, and another of a great many; but to make the compariſon juſt, the author ſhould have compared his exagon with a *French* one of an equal number of works.

M. *Coehorn*'s ſecond and third methods are abſolutely impracticable; for their fortification takes up five times as much ground as the town; and therefore the town would hardly

hardly hold more people, than the number of troops required to defend the fortification, beſides the ſtore-houſes for the prodigious number of artillery and ſtores.

As we have ſhewn the faults M. *Coehorn* has committed in his works, which he has publiſhed before he acquired that great knowledge for which he is ſo juſtly eſteemed as one of the greateſt engineers, juſtice requires that we ſhould likewiſe mention his extraordinary ſkill ſhewn in fortifying *Bergen-op-zoom*; which is one of the beſt contrived fortifications in all Europe.

Having thus finiſhed our examination of the methods of the two moſt celebrated authors, we ſhall now proceed to ſhew in what manner the ſeveral parts of the body of the place are to be conſtructed, ſo as to be capable of the beſt defence, proportionably to the expence.

A new Conſtruction.

Let AB be the exterior ſide of any length, ſuppoſe 180 toiſes; make the perpendicular CD of any length, as the 6th, 5th, or 4th part of the exterior ſide, according to the expence or importance of the place: here Pl. XV. Fig. 3.

it is the 6th part or 30 toiſes, ſet off 50 toiſes or more for the faces BH, AE, or rather ⅔ of the exterior ſide; from the ſalient angle A deſcribe an arc with the radius [illegible] toiſes, that is, 2 or 3 toiſes more than the breadth of the ditch; draw from the [illegible] ſhoulder H a tangent HI to that [illegible] the angle A the indefinite line [illegible] to that tangent; then if from the [illegible] an arc a b be deſcribed [illegible] the flank GH is drawn [illegible] chord a b: one of the flanks [illegible] the others will be found [illegible] face DG, between the [illegible] angle of the flank, and [illegible] extremities of all the [illegible] lines of defence, as [illegible] done, the counter- [illegible] drawn parallel to the [illegible] having the point [illegible] its diſtance from the [illegible] perpendicular, being carried [illegible] re-entring angles be- [illegible].

[illegible], which M. *Belidor* has [illegible] them *Rams-horns*, are [illegible] off 3 toiſes from the [illegible] ſection to the point h, and drawing

drawing h f perpendicular to the line of defence; then its interſection f, with the other line of defence produced, will be the center of the arc h k.

To conſtruct the Ravelin.

Set off 12 or 15 toiſes from the ſhoulder E to the point r, in the face of the baſtion, and from the angle G of the flank, as center, deſcribe an arc through the point r, meeting the perpendicular CD produced at L; from this point L draw the faces, ſo as when produced to fall on the faces of the baſtions within 3 toiſes of the ſhoulders; the ditch of the ravelin is 12 toiſes.

To conſtruct Retired Flanks.

Find the flank QR as before, on which ſet off 5 or 6 toiſes for the ſhoulder or orillons; and from a point g in the oppoſite face of the baſtion at 5 toiſes from the ſaliant angle B, draw the broken part of the flank; then draw the retired flank parallel to the line QR, at 5 toiſes diſtant from it: the orillon may be made round in the manner of M. *Vauban*'s, if it be thought proper.

Remarks on this Conſtruction.

This conſtruction is general, let the exterior ſide AB be what it will; the flanks make equal angles with the line of defence and the counterſcarp produced, and therefore defend the ditch in the moſt direct manner; the counterſcarp terminates at the inner angle of the ſhoulder, ſo that the gun placed in that angle grazes all along the counterſcarp: the ravelin is of a due proportion, its faliant angle is neither too narrow nor too open, and its faces cover the flank of the baſtions ſufficiently from being ſeen obliquely.

The orillons are made 5 toiſes long only, which appears to me ſufficient for covering the retired flanks, and by making them ſo, the flanks are larger than if they were made 9 toiſes, as M. *Vauban*'s: the rams-horns have ſeveral advantages over the common tenailles, they cannot be enfiladed, leave more room between them and the flanks, ſo that the rubbiſh from the flanks do not incommode the troops in the rams-horns; and being circular, they ſee not only the ditch directly, but likewiſe the level ground of the ravelins, and the oppoſite covert-way; they alſo reſiſt the oppoſite batteries

the horn-work to the ſalliant angle A, of the ravelin or baſtion, ſhould not exceed 100 toiſes, otherwiſe the branches cannot be well defended by the oppoſite faces of the baſtions or ravelins; they ſhould only be about 80, as in this figure, if it may be done; the front EDF is 120 toiſes; the perpendicular DC one fifth part of the exterior ſide, that is, 24, and the faces 30; and ſo in proportion to the exterior ſide: the arc deſcribed, for finding the poſition of the retired flanks, ſhould have a radius of 15 toiſes, and the ditch 12; that the counterſcarp of the ditch may terminate at the extremity of the orillon, which is but 5 toiſes long, the flanks are as much retired, and made in the ſame manner as thoſe in the body of the place: we have added rams-horns inſtead of tenailles, in order to get as much flank as could be.

The branches of the horn-work terminate on the faces of the baſtions within 30 toiſes of the ſhoulders, the ditch is 12 toiſes, the parapet of the horn-work is 12 feet high, as well as that of the ravelin, which is conſtructed in the manner deſcribed before; that is, by deſcribing an arc from the angle of the flank, through a point in the faces of the horn-work, 12 toiſes diſtant from the ſhoulder, whoſe

whoſe interſection with the perpendicular CD produced, will give the ſaliant angle of the ravelin; the faces terminate within 3 toiſes of the ſhoulder; the ditch of the ravelin is but 8 toiſes; the retrenchments S are conſtructed by producing the branches, and the counterſcarp of the ditch before the ravelin, till they meet; and by ſetting off 25 toiſes on that counterſcarp, for the firſt, and 20 more for the ſecond; then if from the point O, as center, arcs are deſcribed through theſe points, which meeting the branches will give the other points through which the retrenchments paſs; they are made of earth only, their parapets ſhould be but 9 feet higher than the level ground, with a berm of 6 or 8 feet, and a dry ditch of 4 toiſes before them.

The diſtance AB or radius of the arc, which paſſes through the points C, B, D of the crown-work, is 100 toiſes, and ſhould not exceed 120 or 130 at moſt; the exterior ſides BG, BD are 100 likewiſe; the perpendiculars 20, that is, one fifth of the exterior ſides; the faces 26; the radius of the arc, which ſerves to determine the poſition of the flanks, is 15, and the ditch 12; the branches terminate on the faces of the baſtions within Fig. 2.

30 toiſes of the ſhoulders, in the ſame manner as thoſe of the horn-work; the ravelins are conſtructed in like manner as in the horn-work; as likewiſe the retrenchments S, except that the firſt is only 20 toiſes from the great ditch.

Remarks on this Conſtruction.

The branches of theſe works are more directly defended by the faces of the baſtions, than thoſe which are uſually made; the flanks much larger, and covered by the orillons, and the rams-horns added to the flanks, make together a larger battery than can be erected againſt them, which is a maxim in fortification, to be obſerved, if poſſible; otherwiſe the flanks are ſoon deſtroyed, the faces become defenceleſs, and ſo the work may eaſily be taken.

It is to be obſerved, that there ſhould be a row of paliſades placed in the middle of the dry ditches before the retrenchments S, and the parapets of theſe retrenchments ſhould be a row of paliſades placed about 3 feet above the berm horizontally, or rather with the points a little downwards, that the grenades may roll off into the ditch.

For,

For, if this precaution is not taken, the enemy might purſue and follow the troops which defend theſe works, ſo as to enter with them into the retrenchments, and thereby get maſters of them at the ſame time the horn-work is taken.

Becauſe the retrenchments S making equal angles with the branches, and the counterſcarp of the ditch before the ravelin, they will defend the level ground before them in the moſt direct manner, as we have ſhewn in the conſtruction of our flanks, and therefore is preferable to any other poſition that can be given to theſe retrenchments.

The reader will eaſily imagine, that there muſt be a barrier or gate in the ditch near the branches of the horn or crown-work; likewiſe a ſally port under the parapets, for the troops to retire through, when the work is taken.

Conſtruction of a place with detached Baſtions.

As a garriſon ſeldom or never ſuffers the enemy to make an aſſault on the baſtions when they are joined to the place, for fear of being put to the ſword, and the town ſacked,

them into the inner works, and ſo from one to another, till into the body of the place; for if the guns in the baſtions, or counter-guards and ravelin, are not diſmounted till ſuch time the covert-way is attacked, it will be a difficult matter to get and remain in poſſeſſion of it.

All the objection that can be made againſt low walls, is, that they are eaſily enfiladed by the ricochet batteries; to avoid which the ſaliant angles of all the works ſhould be raiſed about 4 feet above the other parts, for the ſpace of 5 or 6 toiſes on each ſide; and the rampart ſhould likewiſe ſlope towards the place by 2 or 3 feet: this has been done by M. *Vauban* at *New Briſach*, and by M. *Coehorn* at *Bergen-op-zoom*; which being the laſt places that theſe great men have fortified, is ſufficient to determine others to follow their examples.

The redoubt in the place of arms, ſhould be a wall of three feet thick only, with loop-holes, and no higher than the glacis, or rather two feet lower, ſo that they cannot be diſcovered but from the ridge of the glacis; the inſide of them may be 2 or 3 feet lower than the reſt of the covert-way, and ſo as to ſlope towards the ditch, that if any grenades


Bastion
15
Redout
15
Upper Flan
P
Müller delin.



Müller delin.

grenades or ſhells ſhould fall into them, they might roll into the ditch.

The redoubts R in the ravelin ought to have a parapet of 12 feet thick only, as being ſufficient to oblige the enemy to raiſe a battery in the ravelin to deſtroy it, which is all that is wanted; they ſerve to retire into when the ravelin is taken, and obſtruct the lodgments there; from whence the troops may retire into the body of the place, when they can hold out no longer.

As to the flanks, they are ſo diſpoſed as to defend the ditch in the beſt manner poſſible, and ſince the detached baſtions are wide and ſpacious, a third flank may be added, if it is thought neceſſary.

Conſtruction of a place with detached Orillon Baſtions.

Let the exterior ſide AB of an octagon be 200 toiſes, the perpendicular CD 40, that is, a fifth part of the exterior ſide, the faces AE, BF 55; the radius of the arc, which ſerves to determine the poſition of the flanks, 22; the ditch 16 at the ſaliant angles; the orillon 5; the flank is retired 5 toiſes; and the line k d, which terminates the flanks, is drawn PL. XVIII.

... in the face, at 5 toiſes
... angle, the ſhoulders of the
... from thoſe of the baſ-
... parallel to the others, and
... through the points of
... the flanks and lines of de-

... lines F b, F b, drawn from
... faces parallel to the
... terminate the inſide of the
... each of 6 toiſes,
... ditch; and upon the
... ſtruct a front of a po-
... perpendicular 12, and

... made of a wall 3 feet
... toiſes, their faliant an-
... counterſcarps of the
... and the faces termi-
... the ſhoulders; the
... is 4 toiſes.
... ert-way are con-
... as thoſe in the

REMARKS.

... being more expenſive than
... advantage in proportion;
the

the ditch is defended by large double flanks, which will hold more guns than the enemy can oppoſe; for we ſuppoſe the body of the place and the detached baſtions to be but 3 feet higher than the glacis, that is, 10 feet above the level; ſo that the flanks cannot be diſcovered but from the ridge of the glacis; the redoubts V are of ſpecial uſe to retire into when the detached baſtions are taken, and to obſtruct the lodgments there; and as the communication from theſe redoubts into the body of the place cannot be ſeen from any part, this ſafe retreat is of great advantage; for by this means the troops will be able to maintain their ground to the laſt extremities; neither can the flanks of the inner front be diſcovered but from the level ground of the tenailles, which therefore I would make but a foot above the water in the ditch, ſo that there will not be a ſufficient quantity of earth to raiſe a battery.

If the flanks and faces of the tenailles were arched and open behind, it would be much better, for by that means the enfilading them would be impoſſible, neither would the ſhells have any effect upon them; and then the upper flanks might be made two or three feet lower than the faces, which

would prevent the enfilading them by the ricochet batteries; but if this ſhould be thought too expenſive, I would make the upper flank 7 feet above the level, that is, 2 feet lower than the faces, and the lower one 3 feet above the level; but then the faces of the tenailles muſt be 4 feet higher than the flanks, to cover them from the enfilades: for it is of the greateſt importance to prevent the enfilading the works as much as poſſible, ſince it is much more dangerous than to be ſeen in the front, and it is too dangerous to defend ſuch a work: this and the ſecuring the retreats from one work into another, are the two greateſt advantages to be gained in a good fortification; and for which the ſtone redoubts in the places of arms, in the detached baſtions, and thoſe in the ravelins, are all that can be done; for when thoſe works can be no longer defended, the beſieged watch their opportunity in the dark, or when the enemy's fire ſlackens, to croſs the ditch and retire; for it would be imprudent to defend them to the laſt; and there ſhould be mines to blow them up, when they can be of no further uſe.

Con-



Müller delin.

Conſtruction of a Place with Lunettes and Counterguards.

This figure is an octagon, whoſe exterior ſide is 200 toiſes, the perpendicular 30, and the faces 55; the radius of the arc which terminates the poſition of the flanks is 20 toiſes, the orillons are 5; the firſt flank is 5 toiſes retired, and the ſecond 10 from outline to outline; the rampart of the lower flank is 4, and the ditch behind it 3: the faces are 4 feet higher at the ſaliant angles, and three at the ſhoulders, than the flanks and curtain, and that exceſs ſhould be of turf: the ditch is drawn from the extremities of the orillon parallel to the line which ſerves to determine the poſition of the flanks; the tenailles, or rams-horns m, are deſcribed from the point of interſection, of the line of defence produced, and a perpendicular to the faces produced 3 toiſes; and there are terminated by a line 3 toiſes diſtance from, and drawn parallel to the curtains. Pl. XIX

The ſemi-gorges of the ravelins R are 20 toiſes, their capitals 30, and the ditch before them 6.

The ſemi-gorges of the lunettes n, the one is 15, and the other 30 toiſes; and the

faces are drawn perpendicular to thoſe of the ravelin and the baſtions; the ditches before them are 8 toiſes.

The counterguards *a* are 7 toiſes broad at their extremities, and the faces perpendicular to thoſe of the lunettes, or parallel to thoſe of the baſtions; the ditch before them is 10 toiſes.

The bonnet b before the ravelin is 10 toiſes broad at the ends, and its faces are parallel to thoſe of the ravelin, or perpendicular to thoſe of the lunette: the ditch before this work is 10, the covert-way 6, and the glacis 20; the places of arms r, are found by ſetting off 20 toiſes one way, and the perpendicular drawn through that point, meeting the face of the lunettes produced.

Remarks on this Conſtruction.

As all the defences of this place are direct, that of the ravelin excepted, the works will be in a condition of making as great a reſiſtance as can be expected; the curtain, ravelin, lunettes, and bonnet, ſhould be all of the ſame height; as likewiſe the counterguards and baſtions, ſo that the baſtions may not be ſeen but from the counterguards, where

where there is not ſufficient room for making batteries to deſtroy the flanks; the rams-horns ſerve to ſally out into the ditch, when dry, or to harbour boats behind them when wet; their level ground ſhould not be above 4 or 5 inches above water, or even with the bottom of the ditch when dry; and as they cannot be enfiladed from any part, their grazing fire will extremely well defend the great ditch, and that before the ravelin; as likewiſe the level ground of the ravelin, lunettes, and counterguards.

The reaſon that the rams-horns are not continued quite to the curtain is, that the ſplinters from the wall may not hurt thoſe in the rams-horns, it ſaves likewiſe ſome expences, and this paſſage may ſerve in a wet ditch for boats to go out and come in, and the part between the lower flank and the rams-horn ſerves as a ſafe harbour for the boats, or as a place of arms when the ditch is dry.

Although theſe baſtions are of as great a defence as poſſible, yet the enemy will in time be able to ruin the flanks, and make breaches in the faces; and this being once accompliſhed, the garriſon will be obliged to ſurrender, unleſs ſome other defence be

found; for which reaſon, good retrenchments, ſuch as marked S, ſhould be partly made, either at the ſame time that the place is built, or in time of peace, with a good ſtrong wall and a ditch before it; as likewiſe with countermines under them, to prevent the enemy from blowing them up with their mines; and from the bottom of this ditch, galleries might be carried on under any part of the baſtion, to blow it up, when it can be defended no longer above ground: I ſaid that theſe retrenchments ſhould only be partly made; becauſe there muſt be about 4 toiſes left unfiniſhed at each end near the flanks, in order that there may be ſufficient room behind the flanks to place cannon; and when the attack is once made, the parts next to the flanks, which are of no uſe, may then be finiſhed, and the other afterwards, when the flanks are of no further uſe; by this means the baſtions will be able to make as great a defence, as if they were detached.

For it is in vain to pretend that a place ſhould make a long and ſtout defence, though ever ſo well fortified, if the governor either wants means, or does not know how to defend it; and there ought not to be a ſingle work

work but what ſhould be defended inch by inch, and when the works are ſpacious enough to admit of retrenchments, there ſhould be as many made as can be done: the works muſt not only be thus diſputed above ground, but likewiſe under ground; for all the parts, where the enemy is likely or muſt make lodgments, ſhould be countermined, in order to blow them up when they can be no longer maintained above ground.

The expence of making countermines and retrenchments is inconſiderable, in reſpect to that of building the fortification, and yet they may lengthen the defence conſiderably. It appears ſhameful, that as ſoon as a breach is made in the baſtion, and often not wide enough to make an aſſault, the garriſon ſhould be obliged to capitulate; it ſeems that the baſtions, which are the moſt conſiderable part of a fortification, and coſt moſt, ſhould ſerve more as a ſhew than as a real additional ſtrength to the place; this is undoubtedly owing to the incapacity or ſlothfulneſs of governors, who think more by what means to make moſt money of their places, than how or in what manner the town is to be defended, and to provide in time againſt the dangers which may happen in an attack.

That a town may make a conſiderable defence, though moderately fortified, is no romantic fancy, as evidently appears by the ſieges of *Vienna* and *Candia*, when they were attacked by the *Turks*; there was not a foot of ground gained by the beſiegers, which the beſieged did not immediately cut off; the former made a defence of near three months till it was relieved, and would have continued ſo to the laſt inch of ground of the whole town, if it had not, and the latter held out ten years.

In order to form a better judgment of theſe three new conſtructions, we have added the profiles of the ſeveral works, and which are nearly the ſame as thoſe the *French* made uſe of in ſome of the laſt places they have fortified. Though we have uſed the octagonal polygon here, yet the ſame works will do in any other above an exagon with ſome very few variations in reſpect to the direct defence.

Conſtruction of M. BELIDOR's *firſt method.*

Plate XX. This figure is a part of an octagon, whoſe exterior ſide AB is 200 toiſes; the perpendicular

Müller delin.

dicular CD, 50; the faces AE, BF, 70; and the flanks are found according to M. *Vauban*'s method.

The line joining the extremities *a* and b of the flanks of the ſame baſtion, ſerves as an exterior ſide to trace the front of a polygon; whoſe perpendicular c d is 13 toiſes, the faces 22; the parts d f of the lines of defence, which terminate the flanks, are 14: the dry ditch before this front is 10 toiſes at the points *a*, b, and the counterſcarp terminates at the oppoſite ſhoulders.

The rams-horns *g*, are deſcribed from a point in the middle of the faces of the interior front, as centers, with a radius of 25 toiſes.

The retrenchments H are drawn from a point h in the face, at 15 toiſes from the ſhoulder to the points b, *a*, and are 25 toiſes long; the orillons k l, 8, and the flanks n m are 8 toiſes retired near the orillon, which are the chords of an arc from the oppoſite ſhoulders; the ditch before theſe retrenchments is 8 toiſes near the parapet of the baſtions, and its counterſcarp directed to the ſhoulders.

The ſaliant angle of the redoubt B touches the interſections of the curtains produced, and

and the faces terminate on the faces of the inner front within 3 toiſes of the ſhoulders; its ditch is 3 toiſes; theſe redoubts are a ſtone wall of 3 or 4 feet thick, with loop-holes in the faces.

The author having made no outworks to this ſyſtem, we have added ravelins and a covert-way made in the uſual manner; the great ditch is twenty toiſes before the ſaliant angles of the baſtion, and its counterſcarp is directed to the ſhoulders; and the faces of the ravelins to the outline of the retrenchments H.

Remarks on this Conſtruction.

This fortification has the advantage of all thoſe which have detached baſtions; the retrenchments within are of a good defence; but they take up too much ground, eſpecially the ditches, which ground might, in my opinion, be better diſpoſed of; beſides, if the breach was made at h F, by the guns placed in the oppoſite place of arms and ravelin, the beſiegers would find a lodgment H ready made, wanting only a part oppoſite to the face of the inner front. But the flanks of theſe large baſtions, which are about


B
n
k
Müller delin.

bout 26 toiſes long, ſeem to be too ſmall, nd the great ditch too large; for if it was nly 15 or 16 toiſes at the ſaliant angles, nd the counterſcarp directed to the flanks vithin 2 or 3 toiſes of the ſhoulders, the eſieged would not find ſo much room to lace their counter-batteries.

The ditch before the inner front might e ſmaller, that is, of about 5 toiſes; and hen the flanks would become ſo much the onger.

As the ditches before the retrenchments H are directly oppoſite to thoſe before the ravelin, the author deſigned to make a battery in them; for which reaſon he carries that ditch through the parapet, and leaves only the walls to cover it; but as the enemy might ſoon deſtroy the wall, and therefore need make no other breach to enter the baſtion, we have continued the parapet, and thoſe batteries might be arched and open behind.

Conſtruction of M. BELIDOR'*s ſecond method.*

This figure is again a part of an octagon, whoſe exterior ſide AB is 200 toiſes: the per- Pl. XXI.

perpendicular CD, 55, and the faces, AE, BF, 70, as in the former; and the flanks are likewiſe found according to M. *Vauban*'s method.

The line *a b*, which paſſes through the extremities of the flanks, ſerves as an exterior ſide to the inward polygon; whoſe perpendicular c d is 5 toiſes, the faces 24, and the flanks are chords of arcs deſcribed from the oppoſite ſhoulders of the detached baſtions as centers.

This inward polygon is nothing elſe but a ſtrong wall, behind the curtain of which, and of about 18 feet diſtant from it, is a parapet or epaulement of earth 3 toiſes thick; and within the baſtions are cavaliers, whoſe fronts are circular arcs deſcribed with a radius of about 23 or 24 toiſes; the flanks are 7 toiſes long, and gorges 32.

The counterſcarp of the ditch before this polygon is 7 toiſes at the ſaliant angles *a*, *b*, and parallel to the curtain.

The rams-horns or tenailles touch the lines of defence within 3 toiſes of the ſhoulders, and are deſcribed ſo as to meet the other lines of defence in the ſame point as the counterſcarp of the inner ditch.

The

The outline of the curtain between the arms-horns is 9 toiſes from the ditch.

The exterior ſide h k of the retrenchments within the detached baſtions, meets the faces within 20 toiſes from the ſhoulders: the perpendicular m n is 17, the faces h l, 20; the chord on which the orillon is deſcribed is 5 toiſes, and likewiſe the retired part of the flank; the flanks and orillons are made according to M. *Vauban*'s method.

The circular curtain and the round part of the ditch behind it, are deſcribed with a center, 25 toiſes diſtant from the points *a*, *b*.

The great ditch is 20 toiſes before the faliant angles of the detached baſtions, and is ſuppoſed to be dry; for which reaſon M. *Belidor* made a caponiere to go from the curtain to the ravelin, of 18 or 20 feet wide, whoſe parapets terminate on both ſides in a ſlope or glacis.

The capital of the ravelin Q is 66 toiſes, that of the redoubt P, 30; the faces of the ravelin are directed to thoſe of the retrenchments within the baſtions, and thoſe of the redoubt to the ſhoulders; the batteries in the ravelin are retired 8 toiſes behind the faces; the ditch of the ravelin is 12 toiſes, and that of the redoubt 7.

The

The ſemi-gorges of the lunettes R are 25 toiſes, and the faces perpendicular to thoſe of the ravelin and the baſtion; the ditch before them is 8 toiſes, and the batteries S are retired as much, and are 15 toiſes long: laſtly, the covert-way is 6 toiſes.

Remark on this Conſtruction.

If the parapet behind the curtains, and the cavaliers in the baſtions, of the body of the place had been joined to the wall, it would have been much better, ſince the wall will ſoon be deſtroyed, and thereby open the place at once; the perpendicular of the great polygon is a great deal too long, it makes the baſtions too big and expenſive; the great ditch is likewiſe too wide; the earth taken out of it will be more than is required for raiſing the ramparts. As to the outworks, they ſeem to be extremely well diſpoſed, and capable of a good defence, excepting the retired batteries in the ravelin Q are, for the greateſt part, covered by thoſe of the lunettes R; for which reaſon, lunettes diſpoſed in the manner repreſented in the other plate are, in my opinion, of a much better defence than theſe here; but the whole

Müller delin.

whole work together is too expenſive to be ever made uſe of; for it would require almoſt a whole army to defend theſe works, and if we conſider the prodigious quantity of ſtores and ammunition required, one may eaſily perceive that this fortification will never be uſed.

Conſtruction of M. BELIDOR'*s third method.*

This figure is likewiſe a part of an octagon, whoſe exterior ſide AB is 200 toiſes, the perpendicular CD, 40; the faces AE, BF, 55; the parts D r of the lines of defence, between the perpendicular and the broken part of the curtain, 30; and the length of the broken parts r n, 25; the orillon is 9, and is part of a flank found according to M. *Vauban*'s method; the flanks are 8 toiſes retired, and are arcs of 60 degrees; the outlines of the rams-horns are 13 toiſes diſtant from each other; the paſſages at their extremities are 3, the outmoſt or loweſt is deſcribed with a radius of 30 toiſes, and the other is deſcribed from the ſame center. Pl. XXII.

We

[illegible] the ravaliers placed in [illegible] being according [illegible].

[illegible] line KL is 18 toiſes [illegible] flanking angle of the coun- [illegible] KL is 4 toiſes, as well as [illegible] ſide; and the radius [illegible] is 10 toiſes retired.

[illegible] redoubt made of a ſtone wall [illegible] toiſes, with a ditch of 2 toiſes [illegible].

[illegible] before the lunettes is 12 toiſes at [illegible] its counterſcarp directed [illegible] of the oppoſite faces.

[illegible] the ravelin W is 44 toiſes, [illegible] the flanks are 9 toiſes, [illegible] ſhoulders of the baſtions.

[illegible] the ravelin is 10 toiſes, and [illegible].

[illegible] before the ſaliant angles of the baſtions, [illegible] toiſes broad; the demi-gorges [illegible] arms X are 26 toiſes; [illegible] ramparts, or ſtone wall within them, [illegible] from the edge of the ditch T, and the faces are drawn parallel to the oppoſite demi-gorges.

The redoubts S, within the lunettes, are alſo made of a wall 3 or 4 feet thick, full

of loop-holes, with a ditch of 3 toiſes before them.

The dimenſions of the arrows and detached redoubts, are the ſame as thoſe in M. *Vauban's* method, only the arrows have flanks parallel to the paſſage of 10 toiſes.

Remarks on this Conſtruction.

M. *Belidor* commits the ſame faults in all his works, as almoſt all thoſe who fortify upon paper only; by conſidering how a place might be ſtrongly fortified, without troubling themſelves about the expences of building, or the great number of troops to defend it; imagining, I ſuppoſe, that a Prince, or State, ſhould ſpare no expence to ſecure the ſubjects againſt a powerful enemy. If it were only for the expence of building them, I ſhould be of their opinion; but when it is conſidered how much artillery and ammunition is required, together with the great number of troops to defend ſuch places, it may eaſily be conceived, that their firſt notions muſt neceſſarily vaniſh into ſmoak.

But let us enter upon particulars; the redoubts m are intended to ſecure a ſafe retreat from the lunettes when they are taken;

but as the beſiegers may eaſily deſtroy them with the ſame guns placed in the oppoſite ravelin, which ſerve to batter the faces of the lunettes, as likewiſe the curtain of the body of the place, they will hardly anſwer the purpoſe for which they were deſigned; he ſhould have added a parapet of 12 or 15 feet, which would have effectually ſecured the retreat. The lunettes might have been conſtructed ſo as to defend each other directly, as likewiſe to be defended directly by the oppoſite faces of the baſtions; and if there had been made counterguards inſtead of the glacis T, they would have covered the baſtions and the oppoſite flanks, and would not be liable to be taken ſword in hand, as theſe works may be taken. I ſuppoſe the author intended to ſecure them with paliſades, but when the paliſades are higher than the glacis, the beſiegers guns will ſoon deſtroy them, and make their defence more dangerous than uſeful; if they are equal in height with the glacis, and placed near the parapet, the enemy jumps over them; and if they are farther off, they are troubleſome, and eaſily deſtroyed by the ricochet batteries; from whence it may be concluded, that theſe works are of little or no defence.

The

The places of arms are too ſpacious, and the counterſcarp of the ditches before the detached redoubts being parallel to the flanks, render the ditch before the faces defenceleſs, and therefore ſerve as retrenchments ready to receive the enemy, without requiring ſo much as a traverſe to cover them; the flanks of the arrows are made with no more judgment than theſe ditches.

The rams-horns are certainly very well contrived, they are much preferable to the tenailles; they cannot be enfiladed from any one place, reſiſt better, by their bending outwards, the enemy's batteries, and render the flanks much ſuperior to any battery that the enemy can raiſe againſt them; but the retired flanks have the ſame defect as thoſe of M. *Vauban*'s, which we have ſhewn before; it is ſurpriſing, that no author has ever obſerved the badneſs of theſe kinds of flanks; the great character which M. *Vauban* has juſtly acquired, has probably impoſed upon their underſtandings. The ſtone redoubts S, and X, in the lunettes and places of arms, are undoubtedly very good, they add much ſtrength to thoſe places, and ſecure a retreat to the troops which defend them.

Conſtruction of M. BLONDEL's ſecond Method.

PLXXIII. M. Blondel eſtabliſhes two ſorts of fortifications, viz. the great, whoſe exterior ſide he makes 200 toiſes, and that of the little 120. He begins with the angle made by the exterior ſides and the lines of defences, for which he gives the following rules.

Subtract 90 degrees from the angle of the polygon, and take the third part of the remainder, to which add 15 degrees, and the ſum will be the angle ſought. For example, in an exagon, the angle of the polygon is 120 degrees; from which take 90, and there remains 30, the third part of which is 10, which added to 15 gives 25 for the angle required.

He makes likewiſe his lines of defence equal to that of the exterior ſide; that is, 119 or 120 toiſes in the little, and 140 in the great; theſe being premiſed, the conſtruction is as follows.

Let the exterior ſide AB of an exagon be drawn at pleaſure, the angles ABC, BAD, 25 degrees each, the lines of defence AD, BC, 140 toiſes, let O be the point of interſection

ſection of theſe lines, biſect AO, BO in E and H; then will AE, BH be the faces, EC, HD the flanks, and CD the ſtraight part of the curtain.

The orillons EI, LH, are 10 toiſes each, the flanks are retired 5 toiſes behind the lines EC, HD; in all polygons above an eptagon, he makes the retired flanks from 10 to 12 toiſes diſtant from theſe lines, in order to lengthen the curtains.

Each flank exceeds the flank before it 9 feet in height, and they are 8 toiſes diſtant from outline to outline.

The counterſcarp of the ditch is drawn from the extremities I, L of the orillons, parallel to the faces of the baſtions; the counterguards are but 4 toiſes broad, 10 or 12 feet of which are taken for the parapet; the ditch before them is 10 toiſes.

If from the ſhoulder E, as center, there be an arc deſcribed through the ſhoulder H, and from H through E, their interſection will be in the ſaliant angle of the ravelin, the faces of which are directed to a point in the faces of the baſtions within 6 toiſes of the ſhoulders; the gorge of the ravelin is determined, by producing the faces of the counterguards; the ditch of the ravelin is 12 toiſes.

The [illegible] of the lunettes V, are [illegible] lines parallel to the courtines, before the ravelin, [illegible], and the ditch before [illegible] the covert-way 6, and [illegible] of arms, which are [illegible] the counterscarps, are as [illegible]

[illegible] in the baſtions and [illegible] from the faces; and [illegible] determined by the faces [illegible] produced of the ravelin [illegible]

[illegible] the Fortification.

[illegible] formerly a great man [illegible] ſpread all over *Eu-* [illegible] have be made very [illegible] the different man- [illegible] the ſeveral nations, [illegible] on fortifica- [illegible]

[illegible] great ſkill in diſco- [illegible] committed by others, and [illegible] yet he fell into [illegible] conſequence; neither [illegible] the great expence his method muſt

muſt coſt, (which is the caſe of moſt authors) and likewiſe the numerous artillery required to defend it.

However, if the works were of good defence, he might be excuſed in neglecting the expence; but how far he has ſucceeded in that reſpect, we ſhall make appear.

He imagines, that places are generally loſt for want of having ſufficient flanks, for which reaſon he makes three, one behind another; but they are too near each other, ſo that the rubbiſh of the upper flank muſt certainly deſtroy the uſe of the lower: beſides, if any ſhells fall into the lower ones, they muſt inevitably deſtroy the troops that are there, as not having room enough to avoid them; they are likewiſe too open, and ſo more liable of being deſtroyed from the covert-way, for the counterguards are not broad enough to ſkreen thoſe flanks, as the author imagines; ſince a few mines will ſoon deſtroy them, as we have obſerved in M. *Coehorn*'s method, who made his after M. *Blondel*.

The low batteries *x*, are likewiſe too narrow and too much confined; though they might have been of good defence, before the ſhells were ſo much uſed, which was

perhaps the caſe, when this method was invented.

Had M. *Blondel* known the uſe of ricochet batteries, he certainly would not have omitted the traverſes in the covert-way as he does; his places of arms are too ſmall to make any tolerable defence.

His great ditch is too wide by much, for it is at leaſt 25 toiſes before the faces of the baſtions; for the expence of removing the great quantity of earth out of them, to a great diſtance, is both idle and needleſs.

Conſtruction of Count PAGAN's *method.*

This author eſtabliſhes three ſorts of fortifications, *viz.* the great, mean, and little, whoſe principal dimenſions are contained in the following table:

TABLE.

	Great Fortification.		Mean.		Little.	
	Square.	In all the other Pol.	Square.	In all the other Pol.	Square.	In all the other Pol.
Exter. Sides	200	200	180	180	160	160
Perpendic.	27	30	24	30	21	30
Faces	60	60	55	55	45	50

Let the exterior ſide AB of an octagon
e 180 toiſes, the perpendicular 30, and
ıe faces 55; draw the flanks perpendicu- Pl. XXIII.
r to the lines of defence, which biſect by
line drawn from the oppoſite ſaliant angles;
ıe one half ſerves for the orillon, the firſt
flank

ries; moſt authors take it for a general maxim, that the direct defence is the beſt, and we have proved it in the beginning of this ſection; and yet a late *French* author, who takes M. *Vauban* to be his hero, ſays, *that if they were not ſo direct, they would be no leſs good, and it is not neceſſary here to obſerve a geometrical exactneſs*; but how this author reconciles his manner of arguing with the above-mentioned general maxim, is a thing I do not underſtand; for if this maxim is not to be followed, it ſhould not be mentioned; and if exceptions are to be made in certain caſes, it is not general.

This author blames likewiſe Count *Pagan* for making his orillons equal to half his flanks; by which means, he ſays, there is ſo much of the flanks loſt, and a leſſer orillon would have been ſufficient: in which he is miſtaken, for there may be 4 guns placed upon the orillon; and if the Count made his retired flanks but half the ſtraight flanks, it is becauſe he thought that there is room enough to place as many guns in them as are neceſſary to defend the ditch; and by doing ſo, they were better hid, and not ſo eaſily diſmounted by the beſiegers; it is certain, that his flanks are too near one another; and if there

there were but two in polygons under an octagon, it would have been much better; the ditch before the redoubt is but ill defended, which ſhould never be made without making tenailles likewiſe; ſo that it might be defended from thence.

We have ſaid that his ramparts are but 7 toiſes in general, ſo that the parapet, which is 3, being taken from 7, there remains but 4 toiſes or 24 feet for the free paſſage and batteries, which is too little; becauſe the platforms take up 18 or 20 feet, ſo that there remains not room enough to paſs by with another carriage. M. *Vauban* made the level ground of his ramparts 30 feet, and ſometimes more, in moſt places he fortified, though in his conſtruction but 4 toiſes or 24 feet; but as he never publiſhed any thing himſelf, thoſe that have given his works to the public have, I ſuppoſe, ſubſtituted their own dimenſions.

His covert-way ſeems to be too narrow, and the places of arms too inconſiderable, for defending the glacis; the not making traverſes in the covert-way, is likewiſe a great miſtake; but as the ricochet batteries were not known in his time, there was not ſo much occaſion for them then, as there is now.

The

The counterguards in his ſecond method are too ſpacious; his propoſing to build hoſpitals, ſtore-houſes, and magazines in them, muſt prove a great detriment to their defence, unleſs thoſe buildings are demoliſhed when theſe works are attacked.

Count PAGAN's *method corrected.*

The exterior ſide of this octagon is 200 toiſes, the perpendicular 30, the faces 69, the orillon 5; the firſt or loweſt flank is 4 toiſes retired behind the orillon, the flanks are 12 toiſes diſtant from outline to outline; the great ditch is drawn from the extremities of the orillons, parallel to the faces of the baſtions; the ravelins are made in the manner deſcribed in plate XV.

The ſaliant angle of the counterguards is 35 toiſes diſtant from that of the baſtions, and they are 8 toiſes broad at their extremities, the ditch 12; there ſhould be retrenchments made in the counterguards, perpendicular to the middle of the faces, with a ditch before them 3 or 4 toiſes.

The covert-way is 6 toiſes, the ſemi-gorges of the places of arms 20, and the faces are perpendicular to the counterſcarps.

Remarks on this Conſtruction.

All the works in this fortification have a very good defence; the compactneſs of the works, and the little expence, in reſpect to the extent of the town, makes this method far preferable to any other.

For we ſuppoſe the town wall no higher than the counterguards and ravelins, ſo that a line drawn from the inſide of the parapet of the body to the extremity of the glacis, determines the heights of the counterguards, ravelin, and the ridge of the glacis.

We have made but two traverſes in each branch of the covert-way, but becauſe of their length, there may be made three, to prevent better the enfilades of the ricochet batteries; theſe traverſes need not be ſo thick as they are generally made, for 10 or 12 feet would be ſufficient to reſiſt the ricochet batteries.

As the flanks are here perpendicular to the lines of defence, it was neceſſary to make the counterſcarp of the great ditch parallel to theſe lines, according to what has been ſaid with reſpect to the true poſition of the flanks, at the beginning of this ſection.

If

If the lower flanks were arched and open behind, in all places that have two or three, it would be much better, ſince this would effectually prevent the enfilading them, when they are not covered by orillons; they would likewiſe be out of danger from the ſhells, eſpecially when there is a ditch behind, and the level ground goes ſloping towards the ditch.

SECT. IV.

Of Irregular Fortification.

THE moſt eſſential principle in fortification, conſiſts in making all the fronts of a place equally ſtrong, ſo that the enemy may find no advantage in attacking either of the ſides; this can happen no otherwiſe in a regular fortification ſituated in a plain or even ground; but as there are but few places which are not irregular, either in their works or ſituations, and the nature of the ground may be ſuch as makes it impracticable to build them regular, without too great expence; it is ſo much the more neceſſary to ſhew

ſhew in what conſiſts the ſtrength or weakneſs of a town irregularly fortified, ſo that the weakeſt part may be made ſtronger by additional outworks; as likewiſe, if ſuch a place is to be attacked, to know which is the ſtrongeſt or weakeſt part.

All the authors who have wrote on fortification, that I have ſeen, are ſo deficient in regard to this, that not the leaſt knowledge can be gathered from their writings; they do not even mention any thing about it. From whence it ſeems to appear, that there can be given no general rule, whereby the ſtrength or weakneſs can be diſcovered; and if we conſider the ſeveral attacks that were made in the late wars, one would be inclined to think that the engineers were no ways acquainted with it. A late author has mutilated, what is here ſaid, and enlarged upon the ſubject very much; he had the aſſurance, not to ſay worſe, to perſuade the public, that all was his own invention, as if this work had not been known before his; but his whole performance conſiſts in nothing elſe than a heap of abſurdities.

That M. *Vauban* underſtood irregular fortification perfectly well, is plain from thoſe places he has fortified of that kind; and yet

his commentators mention nothing of it; they very often laviſhly beſtow their praiſes on ſome of his works which do not deſerve it, and are ſilent upon thoſe which are very juſtly to be eſteemed.

When the ſituation of a place is ſuch that it cannot be regularly fortified, it ſhould be contrived to make it nearly ſo; that is, inſtead of inſcribing it in a circle, it ſhould be inſcribed in an oval, ſo that one half may be like and equal to the other half; and when this cannot be done, it ſhould be made as regular as it poſſibly can be, and as much as the nature of the ground will admit of.

But to reduce irregular fortification into ſome form, that from thence their perfections and imperfections may be diſcovered; we ſhall ſuppoſe, in the firſt place, that one half of the place is equal and like the other half; and then ſhall ſhew the application of this principle in all ſorts of irregular places.

PROPOSITION.

PL.XXIV. If a fortification be inſcribed in an oval, that is, if the one half is equal and like the other half; I ſay, that the ſides CD, GH,

on the flat parts, are ſtronger than the ſides AB, EF, on the narrow parts, ſuppoſing all the exterior ſides equal, and the place equally fortified.

It muſt be conſidered, that a front may be eſteemed more or leſs ſtrong, in proportion as the beſiegers are obliged to make more or leſs works in their approaches; and when theſe approaches are ſuch, as being produced, ſhall always fall without the fortification, otherwiſe they may be ſeen in front by ſome of its parts; therefore when the angles BCD, CDE of the polygon are very great, and the beſiegers come within a ſmall diſtance of the works, they cannot approach any nearer without being ſeen in front, excepting by a direct ſap, with traverſes; and as this way of approaching preſents but a ſmall front, the beſieged, who have a much larger, may oppoſe what obſtacle they pleaſe.

And on the contrary, if the angles HAB, ABC of the polygon are very ſmall, the beſiegers may carry on their approaches to the very counterſcarp, and have always a larger front than the beſieged.

Moreover, as the beſiegers muſt extend their approaches to three fronts, whether

they are ſmall or large, the work of the approaches before the front BCDE, will be to the work before the front HABC, as the line BE is to the line HC nearly; that is, as the greater axis of the oval is to the leſſer; conſequently the front CD on the flat ſide, is ſtronger than the front AB on the narrow ſide.

COROLLARY I.

Hence it follows, that the longer the exterior ſide CD of a polygon is, provided the lines of defence are within the reach of muſket-ſhot, and the angles BCD, CDE of the polygon the ſame, the ſtronger the front will be; ſince the works become more ſpacious, may hold more troops to defend them, and the beſiegers are obliged to extend their trenches farther.

COROLLARY II.

It follows likewiſe, that the greater the angles of the polygon BCD, CDE are, the exterior ſides being the ſame, the ſtronger the front CD will be; becauſe the length of the line BE increaſes, and the extent of the

the beſiegers approaches in proportion, as has been proved in the foregoing propoſition; conſequently the ſtrength of a fortification increaſes in proportion to the number and length of its ſides; that is, a dodecagon is ſtronger than an octagon, ſuppoſing the length of their ſides equal; and an octagon, whoſe ſides are 200 toiſes each, is ſtronger than another octagon, whoſe ſides are only 180; and hence a right line fortified, is the ſtrongeſt of all, contrary to the opinion of moſt engineers: there are even ſome, who imagine preciſely the contrary to be true.

Mr. *Villeneuve*, a French author, at the end of his regular fortification ſays, that if, inſtead of fortifying a regular octagon in the uſual manner, a ſquare was made ſo as the ſides are equal to 360 toiſes, or double the ſides of the octagon; and making flat baſtions in the middle of theſe ſides, ſo as three baſtions being placed in a right line, the faces being 50 toiſes, and the perpendiculars 22 toiſes and 3 feet, which is one eight of the exterior ſide; this figure would be more advantageous than the octagon fortified in the uſual manner.

As the angular baſtions are weaker than the others by what has been proved before, he would have counterguards made before them, and their gorges retrenched, as likewiſe tenailles in the ditches: if this method be conſidered with attention, it will appear not altogether uſeleſs; for as the attack is reduced to the four angular baſtions, they may be well ſecured by outworks, with leſs expence than the common octagon; for if inſtead of making tenailles, I would make rams-horns next to the flat baſtions only, in order to increaſe the defence of the angular baſtions; and if ſmall lunettes were added next to the counterguards, ſo as to defend their ditches, it would increaſe the defence conſiderably. This fortification has another advantage, which is, that the inſide may be filled with regular buildings, and the ſtreets made at right angles to each other, without loſing an inch of ground. And though the capacity of an octagon is greater than that of this ſquare, yet the latter will contain as many buildings as the former.

A late *Engliſh* author goes upon quite contrary principles; for inſtead of making an octagon, whoſe exterior ſides are 180 toiſes each, he would make an enneagon, whoſe

whoſe exterior ſides are to be 170 toiſes only; whereby he pretends to gain great advantages. But as an enemy is obliged to carry his works no farther than three ſides, he will have leſs work to do in the attack of the enneagon than in the octagon; and as the angle of the polygon in the firſt exceeds by 5 degrees only that of the ſecond, the ſmall advantage ariſing therefrom, is by no means ſufficient to balance the diſadvantage of leſſening the ſides; nor does it anſwer the expence of that baſtion which is added to the octagon. Beſides, we have proved, and it is allowed by the moſt able engineers, that the longer the exterior ſide of a fortification is, the ſtronger it will be, provided the lines of defence are not too long for muſket-ſhot; becauſe you can always place more men and guns in the works.

N. B. The truth of the foregoing propoſition and its corollaries is likewiſe confirmed by practice, and experience; firſt, as to practice, if the plan of *Namur* be conſidered, it will be found, that at St. *Nicolas* gate, where the town is narroweſt, there are more works than in any other part; at *Cambray*, near the *Cantipers* and *Seille* gates where the place is narrower than any where elſe, there

are horn-works; at *Lille*, near the gate of the ſick, is a caſtle in the curtain, a ravelin and counterguard before it, as likewiſe a horn-work before each baſtion: abundance of other examples might be given, which confirm the foregoing propoſition.

Experience has ſhewn likewiſe that large places moderately fortified, have made better defences in proportion, than ſmall ones of more works; for *Metz* in *Lorrain* was beſieged, without ſucceſs, by *Charles* the Vth, emperor of *Germany* and king of *Spain*, although he had an army of 100,000 men, and the town was only fortified with a ſingle rampart, without baſtions and a dry ditch before it; *Lille* in *Flanders*, when beſieged by the allies, made a much better defence than any other place in that country; and laſtly, *Prague* in *Bohemia*, when beſieged by the *Auſtrians*, which has but a rampart with baſtions and a dry ditch, and yet the beſiegers were obliged to abandon it, without being in a condition to take it.

An ingenious gentleman has obſerved very judiciouſly, that an army of 30,000 men may eaſily defeat 40,000 men divided into two or three parts ſeparately, though not the whole together: the ſame reaſon holds

holds good in fortification; for one place fortified moderately, and garriſoned with 30,000 men, will make a better defence than three equally fortified, with a garriſon of 10,000 men each.

It may be ſaid, that theſe places had ſtrong garriſons, ſkilful governors, and well provided with every thing neceſſary for a good defence, and that the *Auſtrians* before *Prague* were in want of artillery and ammunition to carry on the ſiege, and that the ſame place was taken a year before by the King of *Pruſſia* and the *French*, in the firſt aſſault. To this may be anſwered, that theſe places were only garriſoned in proportion to their extent, and *Lille* was obliged to ſurrender ſooner than it would have done for want of powder and ammunition; and as to *Prague*, if the *Auſtrians* had been well provided with neceſſaries, they would have found it a difficult matter to force it, as may be judged by their beginning, ſince what works and batteries they made were deſtroyed by the beſieged, and their cannon nailed up.

There are ſeveral other advantages in large fortified places, which cannot poſſibly be had in ſmall ones; as that the ſick and wounded may be lodged in a quarter remote

mote from the attack, where they are pretty ſecure from the beſiegers ſhells and cannon-ſhot; the ſeveral artificers neceſſary in a ſiege may do their buſineſs with leſs diſturbance; and thoſe troops which are not on duty may reſt and refreſh themſelves, whereby they are better able to do their duty; and laſtly, the powder may be lodged in ſeveral magazines at ſome diſtance from each other, ſo that it is not in the beſiegers power to deſtroy them, at leaſt not all; whereas it is a difficult matter to lodge powder in ſecure places in ſmall fortifications, the ſick and wounded are in a continual apprehenſion of being deſtroyed by the ſhells of the enemy, as happened in the ſiege of *Oſtend* laſt war, where there was not any one place ſecure from danger; and the troops not on duty, having no place to reſt themſelves in without fear, will never be able to act with that ſpirit as they would do otherwiſe.

It appears to me a vain imagination to think, that a fortification ever ſo ſtrong, with a ſmall garriſon, can reſiſt long a numerous army; for if their loſs is ever ſo inconſiderable, in reſpect to that of the beſiegers, it muſt nevertheleſs prove a great detriment to them in the end; on the contrary, nothing,

in

in my opinion, but a proportionable number of troops in a garriſon, to that of the beſieger's army, can make a proper defence according to the bigneſs of the place.

It may be ſaid, that caſemats or underground lodgments may be made for the troops to reſt in and refreſh themſelves; but this cannot be done without great expence, and therefore the queſtion is ſtill, whether this expence is not better laid out in making a larger fortification, ſuppoſing the place is of ſufficient importance to a nation; we except however thoſe which are only made to defend a paſs or a port, which might prove a temporary advantage to an enemy.

Having thus proved the foregoing propoſition, and confirmed it by practice and experience, it will ſerve as a maxim or a general rule, on which irregular fortification is to be eſtabliſhed; as likewiſe a ſtandard, whereby the ſtrength or weakneſs of thoſe already fortified may be diſcovered.

As the ſituations of irregular places are ſo various, it is impoſſible either to enumerate them, or to give an example of each; therefore we ſhall endeavour to give ſuch as are moſt common, and uſeful at the ſame time, by which the intelligent reader may be guided

guided in any other caſe that may occur to him.

If a ſituation is ſuch, as to make it impoſſible to reduce it into a regular form, it ſhould be brought to one as near as can be done; that is, if the polygon cannot be inſcribed in a circle, it ſhould be inſcribed in an ellipſis or oval; but as this inſcription is pretty difficult, we will give another method, which anſwers the ſame purpoſe, and is very eaſy in practice.

PL.XXIV. Suppoſe a ſpot of ground to be reducible to the figure ACEG, draw BE, AF parallel to each other, ſo as the interval may be 180 or 200 toiſes, more or leſs, according as the nature of the ground will admit.

To theſe lines draw CH, DG perpendicular, and equally diſtant from the points B, E, ſo as their interval be equal to that of the lines BE, AF; this done, draw DC, GH parallel to AF, BE, and equally diſtant from them, and from their interſections C, D, H, G, with DG, CH, as centers, deſcribe arcs, with a radius equal to CD, or GH ſo as to interſect the lines AF, BE, in A, B, E, F, and join the points A, B, and E, F; then will ABCDEFGH be an oblong octagon, ſo that one half will be ſimilar and equal to the other half.

Much

Much after the ſame manner may be deſcribed any other polygon; for example, in an exagon, inſtead of drawing the two lines CH, DG, there need be but one, in a decagon three, and in a dodecagon four.

If it ſhould ſo happen, as that all the ſides cannot be made equal without too much expence; then the ſides AB, EF, on the narroweſt part of the polygon, ſhould be the longeſt, if poſſible, on account of its being the weakeſt, as has been proved before.

It may ſometimes happen, that the figure cannot be made regular in any reſpect; in ſuch a caſe, the ſtrength of each ſide muſt be eſtimated according to the works a beſieger is obliged to make in the attack, and according to the obſtacles he meets with in his approaches.

If ſome parts of a place are commanded in front by a hill, the parapet muſt be raiſed 8 or 9 feet high, inſtead of 6 only, as is cuſtomary; if it is in the reverſe, then a traverſe muſt be made along the capital of a ſufficient height to cover the work; or in both caſes, cavaliers may be made nearly in the ſame form of the baſtion.

It

It may ſometimes happen, that there is an abſolute neceſſity of fortifying a re-entring angle, in which caſe, the works muſt be conſtructed in ſuch a manner, that there may be no part but what can be flanked, or ſeen by ſome other part; in ſhort, all that art and knowledge can furniſh ſhould be uſed in irregular works; the weakeſt parts ſhould be made ſtrong by an addition of works; care muſt be taken that no part be commanded by a neighbouring hill, or riſing ground; and if that cannot be avoided, to raiſe traverſes or cavaliers; in general, particular care ſhould be taken to make every ſide equally ſtrong, and to be as frugal in the expence as poſſible, that the expence of building and the maintaining a garriſon, may not exceed the advantage ariſing from the fortifying of the place.

I have ſeen a project of a fortification which was to be built near a paſs, to occupy a hill which commands a neighbouring fortification *, of a very odd figure, although made by an engineer of great repute; it

* *St. Philip*'s caſtle in *Minorca*. This hill commands the harbour, as well as all the works of the caſtle, and yet it has been neglected hitherto; what uſe there can be made of it by the beſiegers, will, I am afraid, ſoon be known, but hope this will caution us another time.

was

was impoſſible to judge, from the diſpoſition of the works, for what intent the fortification was to be made.

When a place is to be fortified, it is of the greateſt importance to employ ſkilful engineers to form the project; and to have it afterwards examined with great care and judgment by others, in order to be ſatisfied that the figure is properly adapted to the ſituation and nature of the ground, and the number of works anſwerable to the importance of the place; but above all things, the expence of building, as likewiſe the number of troops for the garriſon, ſhould be well conſidered; for without that it is morally impoſſible that the place ſhould anſwer the end for which it is built.

Notwithſtanding that the foregoing principles are or ought to be quite obvious to any one that has the leaſt knowledge in fortification, yet many examples might be produced, wherein one would imagine that the projectors had not the leaſt regard to this precept, but on the contrary they ſeem to deſpiſe all the principles which are not of their own invention.

Con-

Conſtruction of an irregular place ſituated in an open country.

If the place to be fortified is an old town incloſed by a wall or rampart, as it moſt frequently happens, the engineer is to conſider well, all the different circumſtances of the figure, ſituation, and nature of the ground, to regulate his plan accordingly, ſo as to avoid the diſadvantages, and gain all the advantages poſſible; he ſhould examine, whether by cutting off ſome parts of the old wall or rampart, and taking in ſome ground, the place cannot be reduced into a regular figure, or nearly ſo; for, if that can be done without increaſing the expence conſiderably, it ſhould by no means be omitted; old towns have often towers placed from diſtance to diſtance, as *Douay*, *Tournay*, and many other places, which are generally made uſe of, and mended when it may be done; if there is a rampart without baſtions or towers, it muſt be well conſidered, whether baſtions may not be added, or if it is not better to make only ſome outworks; if the ditch about this rampart is not too wide and deep, it would be advantageous to make detached baſtions,

baſtions, otherwiſe ravelins and counterguards muſt be conſtructed: ſpecial care muſt be taken, to make all the ſides of the polygon as nearly equal as poſſible, and that the length of the lines of defence do not exceed the reach of muſket-ſhot; but if that cannot be done, thoſe ſides which are on the narroweſt part ſhould be made the longeſt.

If it ſhould happen that ſome of the ſides are inacceſſible, or of very difficult approach, either on account of ſome precipice, marſhy ground or inundation, they may be made much longer than the others, which are of eaſy acceſs, and the flanks need not be ſo large as the reſt; by doing ſo, there will be ſome expences ſaved, which may be uſed in making the other ſides ſtronger, by adding more outworks.

There are few ſituations, but what are more advantageous in ſome parts than in others; it is therefore the buſineſs of an engineer to diſtinguiſh them, and to render thoſe ſides ſtrong by art, which are not ſo by nature.

If the ſituation is low and watery, lunettes or tenaillons, and ſuch other ſmall outworks, ſhould be conſtructed, becauſe they are not of any great expence, and may

them, in the conſtruction of thoſe places which he fortified in his latter time; and where he made any, it was always to cover a gate or entrance into the town.

If the place to be fortified is new, and the ſituation will not admit of a regular conſtruction; particular care muſt be taken, in chuſing ſuch a ſpot of ground as is moſt advantageous, and leaſt liable to any diſadvantages, either in the building or in the maintaining of it; all hills or riſing grounds ſhould be avoided, which might command any part of the works, and marſhy grounds, becauſe ſuch ſituations are unwholeſome; or lakes and ſtanding waters for the ſame reaſon, excepting a lake is, or may be made navigable; good water ſhould be had either within the place or near it, for it is abſolutely neceſſary for men and cattle; the air ſhould be wholeſome, otherwiſe the continual ſickneſs that may reign in ſuch a place might prevent people to come and live in it, and the garriſon would not be in a condition to defend themſelves as they ought to do; in ſhort, all the different circumſtances attending ſuch an undertaking ſhould be maturely conſidered, before a reſolution is taken to fortify any place.

When

When a ſituation is pitched upon, the next thing to be conſidered, is the bigneſs of the town and the number of its outworks, which muſt abſolutely depend upon the conſequence ſuch a place is of to a nation; if it is only to guard a paſs, or entrance into a country, it need not to be ſo large; but if it is to be a place either to promote or to protect trade, it ſhould be large and commodious; the ſtreets ſhould be wide, and the buildings regular and convenient; as to what regards the fortification, its conſtruction ſhould depend on the nature of the ſituation, and the number of works, on the funds, or expence a prince or a nation will be at; which however ought to be according to the benefit ariſing from ſuch a place. For as ſuch undertakings are of very great expence, an engineer cannot be too ſparing in his works; on the contrary, the greateſt œconomy ſhould be uſed, both in regard to the number of works, and to their conſtruction. The body of the place may have* revetements quite up to the top, or only in part, and the reſt turfed; but as to the outworks, they ſhould

* Revetements are chiefly made to prevent a place from being ſurpriſed; outworks do not want to be made ſo, as taking them by ſurpriſe is of no great conſequence, except in a ſiege, when other cautions are uſed to prevent it.

have half revetements, or they may be made with turf only; as being not ſo neceſſary to prevent the place from being ſurpriſed, and may nevertheleſs make a good defence.

The plate XXIV. is the plan of an octagon, one half of which is ſimilar and equal to the other half; it being ſuppoſed that the ſituation would not admit of a fortification quite regular; the exterior ſides are each 180 toiſes, and the works are conſtructed according to our method; but becauſe the ſides AB, EF are weaker than the reſt, as has been proved before, we have added tenailles, redoubts in the ravelins, and lunettes, to render them nearly equal in ſtrength with the others; and if counterguards were made before the baſtions A and B, it would effectually ſecure that front. Inſtead of lunettes, any other works may be made, as it may be thought convenient, and according to the nature of the ground. If it ſhould be judged neceſſary to add other outworks to the ravelins all round the place, care muſt be taken to add likewiſe more to the fronts AB, EF, in order to render the advantages and diſadvantages of attacking on either ſide equal.

Con-

Plate XXIV.



there ſhould happen to be a ſpring, near the top of the hill, it ſhould be incloſed in the fortification, or if that cannot be done, by ſome work or other; for there is nothing more neceſſary, and at the ſame time ſcarcer in ſuch ſituations, than water, for which reaſon there cannot be too much care taken in providing it; ſeveral ciſterns are to be made to receive the rain-water, and to preſerve it; wells ſhould be dug likewiſe, though ever ſo deep, the water of which will ſerve for common uſe.

Places built on hills or rocks, ſhould never be large, for their uſe is generally to guard paſſes or inlets into a country, and are ſeldom uſeful in traffick, and it is a difficult matter to provide for a large garriſon in ſuch ſituations; neither ſhould any ſuch places be built without ſome very material reaſons; but when it is abſolutely neceſſary, great care and precaution ſhould be taken to render the works as perfect as the ſituation will admit of, and at the ſame time to be as frugal in the expence as poſſible.

Conſtruction of irregular fortifications, ſituated near rivers, lakes, or the ſea.

As the intent of building theſe kind of places, is chiefly to facilitate and protect trade, it is of much more importance than any other kind, eſpecially in maritime countries, where the principal ſtrength and power depends on it; for which reaſon, we ſhall treat of it more largely than of any other part.

The firſt thing to be conſidered is their ſituations, which ought to be ſuch as to afford a good harbour for ſhipping, of a ſafe and eaſy entrance in ſtormy weather; but as it is hardly poſſible to find any, where ſhips may go in and lie ſecure, with all winds, care ſhould be taken to make them ſafe to enter with thoſe winds which are moſt dangerous; but it is not ſufficient that the harbour is ſafe againſt ſtormy weather, they ſhould likewiſe be ſo againſt an enemy, both by land and water; for it often happens that ſhips are deſtroyed where it was imagined they were ſecure, which is of too great a conſequence not to be provided againſt; for which reaſon, forts or batteries muſt be built

in

in the moſt convenient places, to prevent the enemy's ſhips from coming too near, ſo as to be able to cannonade thoſe in the harbour, or fling ſhells amongſt them; and if there is any danger of an enemy's approach by land, high ramparts and edifices muſt be built, ſo as to cover them.

When a river is pretty large, and it is not convenient for making a harbour without great expence, the ſhips may ride along the ſhore, which, for that reaſon, muſt be made acceſſible for ſhips of burthen; this may be done by advancing the quay into the river, if the water is too ſhallow, or by digging the river ſufficiently deep for that purpoſe.

And to prevent any enemy from coming up the river, forts muſt be built on both ſides, eſpecially when there is any turnings or windings. *Antwerp* is ſuch a place, for the *Scheld* is ſufficiently deep to carry ſhips of great burthen, which may come quite near the town-wall; and ſeveral forts are built below it on both ſides, ſo that it would not be an eaſy matter for an enemy to come up the river.

When the river is but ſmall, ſo that no ſhips of burthen can come through it; it is ſufficient to make it run through ſome

of the works, where proper landing places are contrived, from whence the goods may be carried into the place; as at *Sarrelouis*, where a horn-work is built beyond the *Sarre*, in the gorge of which the goods are landed.

If the breadth of the river does not exceed 200 yards, it commonly paſſes through the middle of the town, and proper quays are made on each ſide; in ſuch a caſe, the fortification is ſo contrived, as that the river paſſes through the curtain, in order to have a baſtion on each ſide to defend the coming in and going out.

When M. *Vauban* fortified near rivers, he made always the exterior ſide near the water much longer than any of the others; ſuch as *Hunningen* on the *Rhine*, and *Sarrelouis* on the *Sarre*; but for what reaſon he fortified theſe places in that manner, has not been told by any author I know of; for thoſe who beſtow moſt praiſes on him, are quite ſilent in this reſpect, although theſe works ſhew better, in my opinion, his great ſkill in fortification, than many others for which he is generally eſteemed; it is true, authors treat in general ſo ſuperficially of regular fortification, as would incline one to

to believe that they either knew not the importance of the ſubject, or elſe imagined it was impoſſible to reduce it under general rules or maxims, whereby its perfections and imperfections might be diſcovered.

But it is plain, from what has been demonſtrated before, that the ſides which terminate at the river, are the weakeſt; becauſe the beſiegers trenches being ſecured by the river, they may draw moſt of their troops off, and act therefore with more vigour and ſtrength on the other ſide: beſides, as the ſtrength of a ſide increaſes in proportion as the angle of the polygon is greater, by making the ſide next the river longer, the angles at its extremities become wider, and conſequently the adjacent ſides ſtronger.

There are other advantages, beſides theſe mentioned already, which ariſe from the lengthening that ſide; for if the river is pretty deep, ſo as not to be fordable, that ſide is not liable to be attacked; and by increaſing its length, the capacity of the place increaſes much more in proportion to the expence, than if more ſides were made; the center of the place will be likewiſe nearer the river, which makes it more convenient for

Müller delin.

for tranſporting the goods from the water-ſide to any part of the town.

To illuſtrate this method of M. *Vauban*'s, we ſhall give the plan of *Hunningen*; this place was built for the ſake of having a bridge over the *Rhine*, for which reaſon he made it only a pentagon; the ſide AB next to the river is 200 toiſes, and each of the others but 180; the body of the place, as likewiſe all the outworks, are conſtructed according to his firſt method, by obſerving that the perpendicular to the ſide AB is only 25 toiſes, according to the table given at the beginning of his firſt method, and the capital of the ravelin before that front 28; whereas thoſe of the others are 50. Pl. XXV.

About the ſpace *abc*, which lies before the front AB, is a ſtone wall, and the paſſages *x*, *x* are ſhut up with ſluices, to retain the water in the ditches in dry ſeaſons, and to prevent an enemy from deſtroying the ſluice near the point c, whereby the water would run out and leave the ditches dry; the redoubt y was built in the little iſland hard by, in order to cover that ſluice; without this precaution the place might be inſulted from the river-ſide, where the water is ſhallow in dry ſeaſons.

The

ſecure in ſtormy weather, and in time of a ſiege; and as water-carriage is very advantageous for tranſporting goods from one place to another, as likewiſe for bringing the neceſſary materials, not only for building the fortification, but alſo the place itſelf, the expences will be leſſened conſiderably, when this convenience can be had; for which reaſon, places ſhould never be built any where elſe but near rivers, lakes, or near the ſea; excepting in extraordinary caſes, where it cannot be avoided.

For the better underſtanding this important part of fortification, we ſhall give ſome examples of various kinds, from which the reader may gather the manner of fortifying others of the ſame nature.

EXAMPLE I.

PL.XXVI. We ſhall ſuppoſe a river of 100 toiſes or more broad, and ſuch as is always navigable, at leaſt for ſmall veſſels or boats, and the ſituation to be ſuch as to admit of a regular fortification; the body of the place is a regular octagon, and the flat ſide next to the river cuts off a fourth part from the circle, and is lengthened ſo as to be 360 toiſes; the perpendiculars are 25 toiſes only on this ſide, and all the others 30; the faces 50, and the flanks

are

are found according to our method; the great ditch is 16 toiſes, and the ravelins are conſtructed as uſual; the lunettes L near the river, have one of their faces perpendicular to the middle of thoſe of the adjacent ravelins, and the others are parallel to the flat ſide; their ditch is 12 toiſes. Within the flat baſtion is a baſon B, to receive ſhips, 40 toiſes broad, and its length is terminated by perpendicular lines drawn from the extremities on the adjacent curtains, and a paſſage is made in each flank of 10 toiſes, for the ſhips going in and out; theſe paſſages are ſhut up with ſluices, with a kind of a paſſage over them, in order to have a free communication with the flat baſtion, and from thence over the bridge into the fort G, on the other ſide of the river.

This fort is conſtructed in the following manner; from the ſaliant angle of the flat baſtion, as center, deſcribe an arc with a radius of 200 toiſes; on which ſet off two chords of 120 toiſes each, for the exterior ſides, the perpendiculars to which are 20, and the faces 35; the branches of this fort are perpendicular to the oppoſite faces of the baſtion; the ditch before this work is 12, that of the ravelin 8; and the ravelin as well as the flanks are conſtructed according to our

method. The ſemi-gorges of the lunettes k are 20 toiſes each; and the faces are, the one perpendicular and the other parallel to the branches of the fort; they ſerve to cover the entrance into the baſon B, which might otherwiſe be ſeen from thence; the ditch before theſe lunettes is 8 toiſes.

The gorge of the redoubt H is 40 toiſes, the flanks 10, the faces 30, and the ditch before it 6; this work ſerves for ſecuring the retreat when the fort G is taken; and whilſt the enemy is endeavouring to get maſters of it, the troops may retire in the dark over the bridge into the town.

The market-place A is about 70 toiſes one way, and 50 the other; all the ſtreets 6, which is rather too much for the by ones; our deſign is not ſo much to give the particular dimenſions of them, as to ſhew that they ſhould be perpendicular to the river, and croſs each other at right angles; reſerving the reſt for the practical part of fortification.

The buildings C, C, are deſigned for naval ſtore-houſes, E a ſtore-houſe for land ſervice, D for barracks, and F are the bridges near the gates of the town.

We have given the conſtruction of the body of the place and ravelins only, without deter-

Plate XXVI.



J. Mynde sc.



determining the reſt of the outworks, whoſe number and capacities depend on the importance of the place. It ought to be remembered, that it muſt be better fortified near the river than any where elſe, it being the weakeſt part, as has been proved before.

If the ſituation does not admit of a regular fortification, then it muſt be conſtructed in ſuch a manner, as to approach as near to it as can well be done, without being at an exceſſive expence; and if there ſhould be a hill, or riſing ground within cannon-ſhot, which can ſee into ſome of the works, it muſt either be fortified, or cavaliers are to be made in the oppoſite baſtions.

It may ſometimes happen, that the river forms a natural baſon for ſhipping, or they may be made ſerviceable by a little work; ſuch an advantage is by no means to be neglected, a ſkilful engineer will know how to uſe all the advantages which the nature of the ground affords, ſo as to be ſaving in the expences, and to make the place in the moſt convenient manner.

The landing places may be made in the great ditch, near the curtains next to the river, if it is thought proper; in ſuch a caſe, part of thoſe curtains may be left open, in order

it will probably be attacked on the ſide quite oppoſite to the river, ſome more works ſhould be made in this place.

Notwithſtanding the booms and chains, which are to be laid acroſs the river, in the night and in time of danger, the enemy may find an opportunity to force his way through, whereby the place might eaſily be taken. To prevent which a wall of 8 or 10 feet high ſhould be built along the river, with iron gates oppoſite to the ſtreets, ſo as to be locked up at night.

EXAMPLE III.

Places built near the ſea are of the greateſt importance to a nation on account of trade; ſo they require likewiſe the greateſt care in the chuſing their ſituations, in ſuch a manner as to be of the leaſt expence in building, and the moſt convenient for ſhipping. We ſhall ſhew how ſuch a place may be fortified, when the ſituation is plain and even, and where there is no harbour formed by nature.

Plate XXVIII. This plan is a part of a regular decagon, four ſides of which are cut off for the flat ſide next to the ſea, the perpendiculars to which are but 15 toiſes; all the reſt of the works are conſtructed as uſual; as the place is weakeſt

Plate XXVII.



weakeſt near the ſhore, we have added lunettes with bonnets, to make it nearly equal in ſtrength there with the reſt of the ſides; we have added no outworks beſides ravelins and lunettes near the waterſides, becauſe their number and capacities depend on the importance of the place.

The baſons or harbours A, A, are 30 toiſes broad and 80 long, and the entrance into them 10; this we imagine might be ſufficient for ſhips going in and out: however, it may be made more or leſs, according as it will be thought convenient; our deſign being rather to ſhew the figure, and in what manner it may be done in ſome caſes, than to pretend to give the exact dimenſions, which ought to be determined by experience, or according to the nature of the ſituation.

The channel or road C, leading into the baſons A, A, is 18 toiſes broad, and muſt be as long as the ſhallow water goes; B, B, are two ſemi-circular forts to defend the entrance into the harbour, which being made of that figure, are better for defence on every ſide. If theſe forts ſhould not be thought ſufficient, one or two more may be made between theſe and the place, or on ſome flats or ſands where the ſhips cannot come too near.

The buildings D, D, are naval ſtore-houſes, E a ſtore-houſe for land ſervice, and F the barracks.

The ſtreets and other buildings are to be made nearly in the manner expreſſed here in the plan; but the market-place might be made quite open to the ſea, if it is thought proper.

We ſuppoſe here in this plan, that there is no harbour formed by nature, for which reaſon an artificial one is made; but if there be any bay, creek, or large baſon, formed by the ſea, or a river, it ought to be uſed and enlarged, if neceſſary, and ſometimes moles are made to form a harbour, as at *Gibraltar*; by which a great deal of labour and expences are ſaved.

If a place is to be fortified in an iſland formed by the ſea, and there is a navigable river, then the propereſt ſituation will be at its entrance, if the river is but ſmall; or a little way up in the land, if it is pretty large, ſo as not to be in danger of a bombardment from the ſea; but it muſt be obſerved, that here, and in all places of this kind, the conveniency for making a good harbour muſt chiefly be conſulted, whoſe entrance ſhould always be defended by two or more forts or batteries, placed on both ſides of it.

Plate XXVIII.



Winter delt. J. Mynde sculp.

UNIV. OF MICH.

It will alſo be proper to take particular notice, that if an enemy may land any where thereabouts, the forts muſt be built ſo as to be every where equally ſtrong, in order to be in a condition to reſiſt, which way ſoever they may make their attack, the want of this conſideration has often proved of dangerous conſequence, becauſe if theſe forts or batteries may be ſurpriſed, the harbour will lie open to the enemy, who therefore may enter without any further danger, deſtroy the ſhips, and take the town. It is by no means ſufficient to raiſe batteries in ſuch places as command the entrance of a harbour, without conſidering likewiſe whether their conſtruction is ſuch as to anſwer the purpoſe for which they are built, they will otherwiſe be of very little uſe in the defence of the place: if there ſhould be but one or two ſuch places where an enemy may land, they ought to be fortified with ſome ſmall works; but if there are ſeveral, it is much better to build two good forts, one on each ſide of the harbour, near ſome ſhallow water, ſo that the ſhips may not approach too near, to prevent their being demoliſhed by them.

If a ſmall iſland formed by a river is to be fortified, care muſt be taken to occupy the

the whole iſland, if poſſible, in order that the works of the fortification may defend every part of the firm land, whereby the enemy will not be able to land any where without great danger and difficulty; but if the iſland ſhould be ſo large, that the whole cannot be conveniently fortified, and ſome parts are acceſſible and others not, the place ſhould then be built in the moſt acceſſible part, and the others, if not too many, may be fortified with ſmall forts or batteries.

If there is any lake of ſome length, or which diſcharges its waters into a navigable river, a place built near it will be very convenient for trade; although a lake has no communication with the ſea, or is not navigable, at leaſt for large ſhips, yet it may be very uſeful for trading with the country round about; the bigneſs and ſtrength of ſuch a place muſt be according to its importance.

We have thus explained, in a few words, the manner of fortifying places ſituated near navigable rivers, lakes, or the ſea, which is far from being ſufficient to give a compleat notion of the ſubject; it would require a whole volume to enumerate all the different circumſtances that may poſſibly happen, either in reſpect to the various ſituations formed by

by nature, the conveniencies required to ſave expences, or their importance with regard to traffick; for all theſe conſiderations are to be maturely conſidered and well weighed at leiſure, before an undertaking of this importance is put in execution.

It would be a help to the reader, if a great many plans of places already executed were collected; for by examining them with all the attention and care that is poſſible, and not omitting the leaſt circumſtances, ariſing from their different ſituations or nature of the ground; as likewiſe from the importance they are of either to protect or increaſe trade; and then taking notice for what reaſons works are made in ſuch a manner in one caſe, and different in another, a right notion might be formed of the ſubject, ſo as to be able to proceed in any other caſe of the like nature. But as this would ſwell the work too much, and draw it into a greater length than is agreeable to our purpoſe, we ſhall finiſh this part with explaining the ſituations of a few places already built, to ſupply, in ſome meaſure, what is wanting to compleat the ſubject.

At *Dunkirk* is a bank of ſand before the entrance into the harbour, nearly parallel to the ſhore, which is an admirable defence againſt

againſt any bombardment; for when ſhips lie without it, they are too far from the place to do it any damage; and if they ſhould venture to go between this bank and the ſhore, there is a fort built ſo nigh, which would deſtroy them, as not having ſufficient room for working a ſhip, ſo as to turn about; the channel leading into the harbour is pretty long, and defended by two forts on one ſide, and three on the other, which makes it impracticable for an enemy to paſs through it. Another great convenience this port has, is, that there are three rivers, coming from the inland country, which run into the harbour; at their entrances are ſluices, which are ſhut up at high water and opened at low, which carry out the mud and ſand brought in by the ſea, and thereby prevent the harbour from being choaked up.

Whenever a ſituation is to be found, that has theſe advantages, it ſhould not be neglected, ſince it ſaves great expences in keeping the harbour always clear, and renders an attack by ſea impracticable.

Oſtend lies cloſe to the ſea, and the road leading into the harbour, which lies oppoſite to the ſea, paſſes by one ſide of it; but as the entrance is very difficult, and no wind but a north-

north-weſt one will permit any ſhips to enter, and the town being liable to a bombardment, ſuch a ſituation as this is not to be uſed, excepting other reaſons occur for fortifying it; this place has one advantage, that it cannot be attacked by land but on one ſide only, which is along the ſhore, becauſe all the other ſides may be ſurrounded with water in the time of a ſiege, and therefore the acceſſible ſide may be made ſo ſtrong, as to make it a difficult matter to take it that way.

This notion has been found to be erroneous in the laſt ſiege; for the *French* found means to place two batteries on the other ſide of the channel that leads into the harbour, the one fired into the entrance of the channel, and the other directly into the harbour. This laſt battery being ſeen, from the face of the oppoſite baſtion, ſomewhat oblique, where 12 eighteen pounders were mounted, which would ſoon have ſilenced this battery, had the *French* not prevented it by tracing another epaulement parallel to, and about 20 yards behind the firſt, and making the embraſures of the laſt in a line with thoſe in the firſt, by which they could fire into the harbour, and they were covered by the firſt epaulement againſt the guns of the place.

Antwerp

Antwerp lies near the *Scheld*, and has no other harbour than the river itſelf, which is large and navigable for ſhips of great burthen. A citadel is built above the town, to defend it againſt an enemy coming by land, and below are ſeveral forts on both ſides the river, to prevent an enemy from approaching it by water; this place is ſo happily ſituated, that it was formerly the principal trading place of all *Flanders* and adjacent countries; but afterwards, when the *Dutch* had ſhaked off the yoke of the *Spaniards*, and the beſt part of *Flanders* was ſubjected to the houſe of *Auſtria*, the *Dutch* prohibited all the trade of this place, and transferred it to their own dominions.

By what has been ſaid with reſpect to this place, the reader may eaſily perceive the great advantages it has; and that few ſituations deſerve ſo much notice to be taken of them as this.

Boulogne is ſituated near a creek going pretty far up the land, at the entrance of which is a bar difficult to paſs without a good guide; and on one ſide is a high hill which commands it entirely, ſo that the place is ſecure againſt any attack by ſea; for which reaſon, ſuch a ſituation is not to be neglected.


THE T
of
TOUL
Harbour for
Merchand
Ships.
The

Dieppe is another place ſituated near the ſea; the channel or entrance into the harbour is guarded by two piers or moles, which harbour is nearly perpendicular to the ſea, with a turning near the channel.

The channel and harbour of this place ſeem to be very convenient, and as they are chiefly formed by nature, the expence of making them muſt be inconſiderable; but the place itſelf is ſituated ſo near the ſea, as to make it liable to a bombardment, ſuch a ſituation ſhould therefore be avoided, excepting forts can be made ſo as to prevent the approach of an enemy's fleet.

The laſt ſea-port we ſhall mention is the famous one of *Toulon*, ſituated in the *Mediterranean*; the entrance into the bay or road is large and ſpacious, covered by a neck of land, and defended by three caſtles, two forts, and ſix batteries; the road is ſo large, that a whole fleet may ride in it; adjoining to the town are incloſed two large harbours by piers or moles, the one for the king's ſhips, and the other for merchant men; the firſt is much larger than the ſecond, and its entrance is made in the form of a V open at bottom, by which the ſhips are carried in gradually, without danger of running againſt the piers.

To

XXIX. To give an idea of this * harbour, which is certainly one of the fineſt in *Europe*, we have repreſented the plan of the town and harbour only in the 29th plate, though it would have been much better for the reader's information, to have added the road and entrance likewiſe; but this could not be brought into ſo ſmall a compaſs as to be inſerted in this book, without rendering the parts indiſtinct. From this the reader may form a judgment how to proceed, if he ſhould find himſelf employed in ſuch ſort of works: for nothing can be more inſtructive than examples of works executed; the precepts only, without them, will never make ſo ſtrong an impreſſion upon the mind as is required in the execution of any project, which muſt be perfectly well underſtood beforehand. Thoſe that are curious in ſeeing the manner of forming harbours, may conſult the ſecond part of M. *Belidor*'s Architect Hydrauliques, where they will find plans of the moſt noted harbours in *Europe*.

Before we finiſh this ſubject, we think it will not be improper to give the principal

* *N. B.* This plan has by miſtake been reverſed by the engraver; ſo that the king's harbour, which appears on the right, ſhould be on the left.

con-

conditions required in a ſea-port town, and which ought to be obſerved in the building ſuch places.

Firſt, the harbour is of the greateſt importance to all places of trade by ſea; it ought therefore to be well conſidered, whether there is one to be found, which is formed by nature, ſuch as a bay, creek, or a baſon, or if by the help of a little labour one may be made; for to make one entirely by art, becomes generally too expenſive, and they can never be made ſo large, as to contain a conſiderable number of ſhips; whether the road before the harbour has a ſufficient depth of water for ſhips of great burthen to ride in it ſafely; whether there is good anchoring, and the ſhips may be ſafe in ſtormy weather, and eſpecially the ſhips may enter by ſuch winds as are moſt dangerous upon that coaſt; if the entrance can be defended againſt a ſtrong fleet, by means of forts, caſtles, or batteries built on each ſide of it: and laſtly, whether the ſhips riding in the road and harbour, are ſafe againſt a bombardment.

Secondly, whether the chief or principal materials for building the fortification and the town, are to be had near the place, or thereabouts; ſuch as ſtone, timber, lime, &c.

or if not, whether they can be brought by water, otherwiſe the conſtruction of ſuch a place would be attended with an immenſe expence; whether the country round about is plentiful in thoſe things which are neceſſary for the ſuſtenance of men and cattle; for ſhould it be barren, the bringing theſe neceſſaries from diſtant countries, might be attended with great difficulties, eſpecially in time of war, when an enemy might intercept them, and thereby reduce the place by famine; whether the air is good and the ſituation wholeſome in all reſpects, and good water to be found near or thereabouts; for if it ſhould be unwholeſome, people would not care to ſettle there, and thoſe that would venture, would neither increaſe or act with that ſpirit and chearfulneſs required for the improvement of new ſettlements; and as to good water, it is ſo neceſſary, that it is impoſſible to do without it; laſtly, it ſhould be conſidered whether the country round about it produces ſuch commodities as are fit for trade; how it may be improved, and where it may be tranſported to, either for ſale or exchange, for ſome others which may turn to account either at home or abroad.

All

All theſe things being well conſidered, together with the nature of the ground, the plan of the place muſt be made accordingly; in which the conſtruction of the works ought neither to be exceſſive in the expence for building of them, nor yet ſo ſmall as not ſufficiently to defend the place, but ſuch as the importance of the place requires, and the ſituation admits of. As there are few ſituations which have all the advantages which could be deſired, care muſt be taken to pitch upon ſuch as have moſt of them, and where the reſt may be ſupplied partly by art.

The moſt favourable ſituations for building maritime towns are near the mouth or entrance of a navigable river, eſpecially when it is free from rocks and ſands, and is of eaſy acceſs for ſhipping. In ſuch ſituations, the harbour may be made on the oppoſite ſide of the place, in reſpect to the ſea, as at *Oſtend*, and ſome other places.

If the river is large, the place may be built at ſome diſtance from the ſea, as *Antwerp*; and there is no occaſion for a particular harbour, the river itſelf being ſufficient; the only thing to be obſerved is, that there may be ſome place, where ſhips may be ſafe in ſtormy weather; a hill or riſing ground near the ri-

ver, which ſhelters it from the moſt dangerous winds, will be very advantageous for that purpoſe.

Theſe ſituations near large navigable rivers not too far from the ſea, are the moſt advantageous that can be found; for they have all the advantages of a ſea-port town, and are not liable to be attacked by an enemy's fleet, and are abſolutely free from bombardment, excepting by land, ſince a few forts built in the turnings of a river will be ſufficient to prevent any attempt that way; beſides, the merchandiſe brought by water may be carried into the country to foreign markets with little trouble, and no great expence.

As the greateſt wealth of a country depends on traffick by ſea, ſo there is nothing of ſo great conſequence, as the well protecting it, by building proper harbours to contain ſhips in ſafety, and to make them ſo that they may be defended againſt the force or ſtratagem of an enemy: proper landing-places ſhould not be omitted, nor good magazines and convenient ſtore-houſes to lodge the goods in, and in general, every thing ſhould be thought of that any ways may contribute to eaſy conveyances, and the proper diſpoſing of them. But as nature is ſo various in its

its operations, that it is impoſſible to foreſee all the different circumſtances which may happen, ſo it is likewiſe impoſſible to deſcribe them, and conſequently the choice of a proper ſituation, and the manner of conſtructing ſuch a place, according to its importance, muſt be referred to the ſagacity of the engineer employed in the undertaking, who certainly can have no larger field to diſplay his knowledge, than on ſuch occaſions.

Of CITADELS.

In a country newly conquered, or one of a long ſtanding, where the inhabitants are ſuſpected of being diſaffected to the government, citadels are built to keep them in awe, and prevent all attempts they may make to ſhake off their dependency; as likewiſe to ſecure the garriſon from their treachery, which they might be willing to undertake againſt them.

It happens likewiſe ſometimes, that when a town is large and wealthy, and has little or no fortification, a citadel is built to ſecure it againſt an enemy, when it would be too expenſive to fortify the town itſelf; and to ſerve for a place of ſecurity, to carry in the beſt effects of the inhabitants in time of dan-

ger, when the approach of an enemy is apprehended.

There are many ſuch places in *Italy*, which are large and wealthy, the ſovereigns of which not being in a condition to fortify them, build citadels or caſtles to ſave expences; as likewiſe to ſave large garriſons to guard and defend them.

In regard to the ſituation of a citadel, if the town lies in an open country, it ought to be built on the higheſt part of the ground, in order to command all the parts of the town, if poſſible; if the town lies near a navigable river or lake, it ſhould be placed near the entrance, to prevent the approach of an enemy with ſhips; and if the place is a ſea-port, the citadel ſhould be placed near the harbour, ſo as to command it from one end to the other; that it may protect the ſhips lying in it, and ſecure the place againſt any bombardment.

Another conſideration ſhould be had in placing citadels, with reſpect to the town; which is, that the principal ſtreets of the place ſhould be ſeen and lie open to the works of the citadel, in order to fire on them, [illegible]erſe the mob that might riſe and [illegible]ther in time of ſedition; as likewiſe [illegible]event the approach of an enemy [illegible]er the town is taken.

An

An open ſpace, of ſome hundred yards broad, ſhould be left between the works of the citadel and the town, called an *Eſplanade*; which ſerves chiefly to draw up the troops or garriſon, to muſter and exerciſe them there; as likewiſe to prevent any hidden approach that might be carried on from the town againſt the citadel.

The figure of a citadel may be either a ſquare, pentagon, or exagon; but the pentagon is moſt proper, and generally uſed; the exagon being rather too big for that purpoſe, as requiring too great an expence in the building, in proportion to its uſe, or the advantage ariſing from it; and the ſquare is thought too inconſiderate for making a ſufficient defence.

When a citadel is to be built, either to an old place already fortified, or to a new one, its plan is to be traced by itſelf on a piece of paper, and upon the ſame ſcale as that of the town; then the paper is cut off on that ſide which is to be next to the town, quite cloſe to the edge of the works, and is laid on that of the town in ſuch a manner, that the ditches and works of the fortification are well flanked and enfiladed by the works of the citadel; and when it is placed according to its proper

ſituation, it is pricked off, and drawn upon the ſame paper as that of the place.

It happens ſometimes that there is a hill, or riſing ground, within the fortification of the place, on which the citadel is built; ſuch ſituations may ſerve to keep the inhabitants in awe, if it is provided with neceſſaries, that the garriſon may defend themſelves, till ſuch time that a relief may be ſent; but they are of no manner of uſe againſt an enemy, who after being in poſſeſſion of the town, may eaſily reduce the garriſon in the citadel by famine.

The exterior ſides of the citadel are generally about 150 toiſes; but they may be more or leſs, as occaſion requires. Particular care muſt be taken, to fortify the citadel ſtronger than the town, otherwiſe the enemy might attack it firſt, and by the help of which reduce the town; it muſt alſo be obſerved, to make the parts where the citadel joins the town ſufficiently ſtrong, otherwiſe the town and citadel might be attacked together. Moſt citadels that I have ſeen are defective in that reſpect, as we ſhall ſhew hereafter.

There are generally two gates made to a citadel, the one for a communication with the town, and the other with the country; the



firſt ſerves for the garriſon to retire into, aſe of a ſedition, or after the town has tulated, and the other to receive ſuccour, n the town is taken, or the citadel is ked up by the inhabitants.

The citadel takes up generally two ſides he fortification, and ought to be placed ıch a manner, that the ditch of the place either be defended by the faces of the ions, or by thoſe of the ravelins, in as di- a manner as poſſible; otherwiſe the ene- may attack the town in that place, as be- weakeſt; as likewiſe becauſe the ſame cks may ſerve to reduce both together. covert-way of the citadel ought to be ıterrupted, ſo that the part next to the n may have a free communication with other.

n general, a citadel ſhould be conſtructed uch a manner, that an enemy may have advantage where-ever they make their cks; and that, if the citadel is attacked , it may coſt them as much time and ble, as the attacking the town firſt, and citadel afterwards.

'here are few citadels, that, in my opi- , are rightly joined to towns; the de- e of the ditch is generally ſo oblique

and

and inſignificant, that it appears ſtrange they are not attacked there; that of *Lille* is one
Pl. XXX. of this kind. For the ravelin A cannot defend the oppoſite ditch in the leaſt manner, nor is there any other work that can, ſo that if the town was attacked in that place, the beſiegers would meet with very little obſtacle in the paſſage over this ditch; neither does the baſtion B defend the oppoſite ditch, which can be done only by the oppoſite covert-way, from which the troops may eaſily be driven by the ricochet batteries.

This plan is as the citadel has been built at firſt, but at preſent the ſecond ditch and covert-way towards the town have been taken away, and new counterguards have been built before all the baſtions; and retrenchments have been made in the faces of theſe counterguards: which is a practice the *French* follow in all the counterguards and tenaillons, whether conſtructed already, or when they make new ones.

Pl. XXXI. The citadel of *Tournay* is another inſtance of this kind; for neither the ravelin A, nor the baſtion B, can afford any tolerable defence to the oppoſite ditches; and as they are both dry, they are liable to ſerve an enemy for making their trenches in them under cover.


VI.
THE
Müller delin



del; by which all the great works about the reſt of the town would not be of the leaſt uſe.

Before we finiſh this ſubject, it will perhaps not be improper to ſay ſomething farther of citadels in general. When they are built with an intention to keep the inhabitants, who are diſaffected to the government, in awe, methinks they need not be fortified ſo ſtrongly as is cuſtomary; for if the garriſon can only hold out till ſuch time that ſuccour may be ſent, it would be ſufficient: for which reaſon, if the town is fortified, by cutting off two baſtions only, with ſome good retrenchment; it would anſwer the ends propoſed as well, as the adding another fortification of ſo great expence, as is moſt commonly practiſed: and as theſe ſupernumerary fortifications add but very little ſtrength to the place in proportion to the expence, it appears to me, that if a part of that expence were employed in adding more works to the town itſelf, it would be of more advantage.

The little defence made in the late war, by the citadels of *Lille* and *Tournay*, ſhould, one would think, cure a prince of making theſe ſorts of works ſo expenſive; but there ſeems to be a neceſſity of following the faſhion in fortification as well as in dreſs, to avoid appearing ridiculous.

It

It may be ſaid, that the want of a good garriſon, ammunition, and other neceſſaries, was the occaſion of the ſhort defences theſe two citadels made: it may probably be, that they were obliged to ſurrender ſomewhat ſooner on this account. But if a large town is able to make as long a defence as there is any ammunition and troops to defend it; there ſeems to be not the leaſt occaſion for any more works, which can but little increaſe the ſtrength of the place.

Beſides, it is manifeſt, by what has been ſaid before, that a ſmall place ever ſo well fortified, and provided accordingly, can never make the defence, which a larger may do with leſs works in proportion.

Of Forts and Redoubts.

Forts are a kind of ſmall fortifications, built in order to guard ſome paſſes, in a mountainous country, or near cauſeways, rivers, and other ſuch like places. Their figure and bigneſs are various, and depend chiefly on the nature of the ſituation, and importance of the place: ſometimes they are only made triangular, as in the firſt figure, with half baſtions; but this ſort is very imperfect, becauſe the faces are not ſeen or defended from any

Plate XXXIII.

Fig. 1.

any other part. If inſtead of being terminated at the angle, they were directed to a point within about 20 toiſes from it, they would be much better, as being then defended by that length of the rampart, though very obliquely. There ſhould be a ditch of 8 or 10 toiſes about this fort, although we have not marked it in this figure.

Fig. 2. Sometimes they are made as in the ſecond figure, that is, triangular, as before, but inſtead of making half baſtions at the angles, whole ones are placed in the middle of the ſides. The gorges of theſe baſtions may be from 20 to 24 toiſes, when the ſides are from 100 to 120; the flanks are perpendicular to the ſides from 10 to 12 toiſes long, and the capitals from 20 to 24: if the ſides happen to be more or leſs, the parts of the baſtions are likewiſe made more or leſs in proportion; the ditch round this fort may be 10 or 12 toiſes wide.

The ramparts and parapets of theſe ſorts of works are commonly made of turf, and the outſide of the parapet fraiſed; that is, a row of paliſades are placed in about the middle of the ſlope, in an horizontal manner, the points declining rather outwards, that the gren-

upon them, may roll down into the ditch: and if the ditch is dry, a row of paliſades ſhould likewiſe be placed in the middle of it, to prevent the enemy from paſſing over it unperceived, and to ſecure the fort from any ſurpriſe.

Forts are moſt commonly made ſquare, as in the third figure; at leaſt, when the paſs they are to guard is of any conſequence, or the place may eaſily be approached; the ſides of this ſquare are 100 toiſes, the perpendicular 10, and the faces 25; the ditch about this fort may be from 10 to 12 toiſes; the parapet is to be made of turf, and fraiſed, and the ditch paliſaded when dry. There may be made a covert-way about this fort, or elſe a row of paliſades might be placed on the outſide of the ditch. Fig. 3.

They are often made of various figures, regular or irregular, ſometimes in the form of a ſemi-circle, eſpecially when they are ſituated near a river, ſea, or at the entrance of a harbour; by which figure, they are able to fire at the ſhips on all ſides of it; at others with a long ſide, and ſeveral ſmall ones with-
ny baſtions; this ſhould however not be
but when they cannot be approached,
ch time and difficulty: for it is
not

not ſuppoſed that any fort can hold out long againſt a ſuperior force provided with artillery; their intent is only to prevent parties of an enemy to paſs that way, and to ſtop them for ſome time till they may be ſuccoured.

When a fort is to be built in the neck of land, formed by the confluence of two rivers, or in the windings of a river, in order to prevent an enemy from tranſporting any thing by water, or to prevent the paſſing of their ſhips that way; the figure of the fort muſt be adapted to the ſituation, in ſuch a manner, that there may be no place for landing troops, but what can be diſcovered by the fire of ſome work or other, and the ſide next to the land ſhould always be better fortified than the other parts near the river; as being more liable to be attacked.

Fig. 4. The fourth figure repreſents ſuch a fort; three ſides of which are 100 toiſes each, and the fourth but 50, as ſuppoſing the ground to be narrow in that place; the perpendiculars to the greateſt ſides are 14, and the faces 30; the perpendicular to the other 10, and the faces 15: the capitals of the ravelins 25; the great ditch 12; that before the ravelin 8, and the covert-way 4 or 5. The narrow front towards the land is covered by

by a horn-work, whoſe front is at the diſtance of 36 toiſes from that of the fort, and 90 long, the perpendicular 12, faces 25, and the branches 10 toiſes broad at their extremities; the capital of the ravelin before this work is 22 toiſes, the ditch before the horn-work 8, and that before the ravelin 6 or 7.

We ſhall add another example of this kind, ſuch as is repreſented by the fifth figure: the land is ſuppoſed to open gradually; for which reaſon 3 ſides are 100 toiſes each, and the fourth 160; the perpendiculars to the ſhorteſt 12, and the faces 30; that to the greateſt 20, and the faces 45; the ditch before the three ſhort ſides is 12, and 18 before the greateſt. The capital of the ravelin is 46 toiſes, its ditch 10; the faces of the lunettes are at right angles to thoſe of the ravelin, and fall within 16 toiſes from the ſaliant angle; theſe faces are 25 toiſes long, and the others are perpendicular to thoſe of the baſtions; the narrow part of the bonnet is 10 toiſes, and the faces are perpendicular to thoſe of the lunettes, or parallel to thoſe of the ravelin; the ditches before the lunettes and bonnet are 8 toiſes, and the covert-way 4. Fig. 5.

There are generally great faults committed in the conſtructions of forts near the ſea, or navigable rivers, for want of rightly conſidering all the different circumſtances attending theſe ſorts of works, and without which it is impoſſible that a work will ever anſwer the intents and purpoſes for which it was built. For inſtance, if a battery or fort, built near the water where ſhips may approach, has its parapet not of a ſufficient height; thoſe behind them may be fired upon, from the round-top of the maſt, by which the gunners are obliged to abandon their guns, to ſave themſelves by flight; and ſo theſe forts or batteries become of little or no uſe.

This was the caſe at *Portobello*, when attacked by Admiral *Vernon*; for the forts and batteries, which were deſigned to defend the harbour, had been made ſo low, that the ſhips could come quite cloſe to them, and the troops in them were ſoon obliged to take to their heels and run away.

There is generally another fault committed, which is, that if theſe forts or batteries are left open behind, or are very little fortified wards the land, the enemy may land men ie dark and ſurpriſe them, by which the



Plate XXXIII.



Fig. 1.



guns placed in them become not only uſeleſs to the place, but ſerve rather to deſtroy it.

At *Carthagena* the *Spaniards* had a faſcine battery on the other ſide of the entrance into the harbour, oppoſite to the camp, by which they prevented ſhips from going in; ſailors were ſent to take it, which was ſoon performed; but being ſatisfied with driving only the *Spaniards* from it, they were obliged to take it a ſecond time to nail up the guns.

The ſame thing happened laſt war at *Cape Breton*, where the *French* had a battery of 15 large pieces of cannon; which the *Engliſh* ſurpriſed in the dark, and turned the cannon againſt the place, whereby they became ſoon maſters of it. This fort was quite open behind, which being ſurpriſed by the ſailors in the night, as we ſaid, turned the cannon againſt the town and took it. Whereas if this battery had been ſecured in a proper manner, we might perhaps not have been able to take it, or at leaſt it would have lengthened the ſiege conſiderably. Many examples might be cited of this kind, to ſhew, that the want of judgment in building theſe forts has proved a detriment, inſtead of an advantage, to the places which they ſhould have defended.

To prevent the inconveniency of being ſeen behind the parapet, it will be neceſſary to make them 9 or 10 feet high, and to cover the batteries overhead, which may be done, by making an arch over every piece, left open behind to let out the ſmoak; but if this ſhould be thought too expenſive, they might be covered with planks, like ſheds; and to prevent the wood being ſet a-fire, they may be covered with earth or dung about a foot and a half thick: for if it is but ſtrong enough to reſiſt muſket-ſhot it is ſufficient.

And to prevent a fort or battery being ſurpriſed, they ſhould be fortified all round with a good rampart and ditch at leaſt, or with an addition of outworks, if the place is of any importance; the rampart muſt be fraiſed with paliſades, if it is made with turf, and the ditch ſhould have a row of paliſades, planted in the middle of it, in caſe it is dry; which will prevent an enemy approaching unperceived.

It has been the cuſtom, in latter times, for ſhips to approach forts and deſtroy them without any concern, as knowing too well the little danger they expoſe themſelves to; and this has been occaſioned by their bad conſtruction; whereas, if they were made

as they ſhould be, it would not be impoſſible to ſink every ſhip that ſhould dare venture to come near them. The reaſon of this is plain, if we conſider the uncertainty there is to fire from a ſhip which is in a continual motion, and that a battery, covered with a good parapet, may watch the opportunity, when the ſhip comes near and oppoſite to it, and fire all the guns at once, pointing nearly at the ſame place a little above the water, which will hardly fail of deſtroying it.

On the contrary, if the guns of the ſhip hit the battery by chance, they can do it but little or no damage, when the parapet is well made.

There are ſome who are of opinion, that ſhips will always be able to deſtroy a fort, on account that they have more guns within a leſs compaſs than any battery on land can have; and if the contrary happens, it is more owing to the cowardice of the commander, than to any thing elſe: but this is a wrong notion, as we ſhall make appear. For ſuppoſe a firſt rate man of war, which has three decks, and therefore may have perhaps four, five, or ſix guns to one; the chance of hitting the battery, on account of the ſhip's motion, is not above three to one; and when the ſhot

ſtrikes the parapet, it can do it but very little damage, excepting it ſhould hit a gun by chance, which it would diſmount; but this is not ſo eaſily done, conſidering the ſmallneſs of the gun with regard to their intervals; it is certain not one gun in 30 will hit; whereas the battery may watch the opportunity, ſo as when the ſhip comes near and oppoſite, to make a general diſcharge with all the guns, where there will be not one that miſſes, and every ſhot will make its hole into the ſhip, and deſtroy all things that are in its way. From whence it may be concluded with juſtice, that ſhips are never able to deſtroy any fort, when it is conſtructed in the manner it ſhould be.

If the nature of the ground is ſo as to admit of making two batteries, one above the other, it ſhould not be neglected; the one nearly a level with the ſurface of the water, to fire in a horizontal direction, and the other to plunge into the ſhips; ſo that if the troops are placed on the lower, being well protected in the front by a high parapet, and covered above with arches or planks, it will not be in the power of ſhips to deſtroy them, as has been done heretofore.

If

If there are any flats of ſand, or rocks, near or within the entrance of a harbour, it will be very proper to build ſome tower or fort there of ſeveral ſtories well arched, ſo as to be bomb proof, in order to place ſeveral ranges of guns in them; but as the ſmoak might be troubleſome in the lower ſtories, I would make it open in the middle, that is, I would make two concentric walls, ſo that the arches of the roofs of the lower ſtories might be quite open behind; and in caſe the enemy ſhould throw ſhells, and hit the upper battery, it might be ſo contrived, that the ſhells may roll down the opening in the middle without doing any damage.

Fort *St. Louis*, in the road before the harbour of *Toulon*, is ſuch a work, of a round form, built upon a rock within the water; and the towers called *Egillette* and *Vignette*, are places of the ſame nature in a ſquare form, built upon the necks of land on both ſides of the mouth of the road.

It is the cuſtom of ſome modern engineers, when they build any fort or battery near the ſea or navigable rivers, to make a parapet of three feet high only, in order to fire the guns en barbet: the reaſon they give for this practice is, that they may point the guns which

way they pleaſe, either down the river, to prevent the ſhips from approaching, deſtroy them when they are oppoſite, or firing after them in caſe they ſhould paſs. However ſpecious theſe reaſons appear at firſt, yet when it is rightly conſidered, it will be found that this practice is not ſo advantageous as they imagine. For if they fire at the ſhips when they are yet far off, they can do them but very little damage; and the advantage gained thereby will not by far be equivalent to the danger they will themſelves be expoſed to, when the ſhips come near; ſince one broad ſide, together with the fire of the ſmall arms, will be ſufficient to kill or diſable all thoſe which are on the battery. On the contrary, if the batteries are well covered in the front by a good parapet, and above by planks, or only ſail-cloth, and made in ſuch a manner, as that ſome guns may be directed down the river, and others upwards; this battery will have all the advantage which they can pretend to gain by their practice, and none of its diſadvantages.

Another method is alſo uſed in forts, much more defective than this, which is, to build the parapets of brick or ſtone only, without any earth behind it; for as ſoon as

the ſhips come once within reach of the fort or batteries, they may eaſily deſtroy this parapet, and the pieces of ſtones or bricks will be more dangerous to the defenders than the enemies ſhot itſelf. And it has been found by experience, that nothing diſheartens troops placed behind a wall ſo much as the pieces of ſtone flying about their ears, and therefore ſuch a practice ſhould be avoided as much as poſſible; beſides, the adding 10 or 12 feet of earth only to the wall will be but a trifling expence, and yet ſufficient to protect the troops from this danger.

Having explained the methods of the moſt celebrated authors, and carefully examined their conſtructions, to the beſt of our judgment, without the leaſt partiality, we hope to have done all that is neceſſary to compleat the elementary part of fortification; which being well underſtood, will, I hope, be ſufficient for underſtanding the ſubject. And to leave nothing that might any ways contribute to the reader's ſatisfaction, we ſhall ſubjoin the following Explanation of the principal terms uſed in fortification, by way of a Dictionary, to which recourſe may be had, when there is any occaſion for it.

An

An Explanation of the principal terms uſed in Fortification, digeſted in an alphabetical manner.

A.

ANGLE of the center of a polygon, is formed by two radii drawn to the extremities of the ſame ſide.

Angle of the polygon, is made by the concourſe of two adjacent ſides of a polygon.

Angle of the flank, is made by the curtain and the flank.

Angle of the ſhoulder, is made by the face and flank of the baſtion.

Approaches, are a kind of roads or paſſages ſunk in the ground by the beſiegers, whereby they approach the place under cover of the fire from the garriſon.

Arrow, is a work placed at the ſaliant angles of the glacis, and conſiſts of two parapets, each 40 toiſes long; this work has a communication with the covert-way of about 24 or 30 feet broad, called caponier, and a ditch before it of 5 or 6 toiſes.

Aſſault, is a ſudden and violent attack, made uncovered, on the part of the rampart where a breach has been made.

Attack, is the manner and diſpoſition made by an army or a great party, to drive an enemy out of a fortified place, or of any kind of ſtrong ſituation.

B.

Barbet; when the parapet of a work is but three feet high, or the breaſt-work of a battery is only that height that the guns may fire over it without being obliged to make embraſures, it is ſaid that the guns fire in barbet.

Baſtion, is a part of the inner incloſure of a fortification, making an angle towards the field, and conſiſts of two faces, two flanks, and an opening towards the center of the place called the gorge.

A baſtion is ſaid to be full, when the level ground within is even with the rampart, that is, when the inſide is quite level, the parapet being only more elevated than the reſt.

And a baſtion is ſaid to be empty, when the level ground within is much lower than the rampart, or that part next to the parapet, where the troops are placed to defend the baſtion.

Banquette, is a kind of ſtep made on the rampart of a work near the parapet, for the troops to ſtand upon in order to fire over the parapet;

parapet; it is generally three feet high, and as many broad, and 4½ feet lower than the parapet.

Battery, is a work made to place guns or mortars on it; it conſiſts of an epaulement or breaſt-work of about 8 feet high, and 18 or 20 thick: when it is made for guns, openings or embraſures are made in it, for the guns to fire through them.

Berm, is a little ſpace or path of 6 or 8 feet broad, between the ditch and the parapet, when it is only made of turf, to prevent the earth from rolling into the ditch, and ſerves likewiſe to paſs and repaſs.

Blind, is two ſticks faſtened together by two ſpars of about 4 feet aſunder; they ſerve to cover the ſaps, or to keep up the earth on the ſides, by placing faſcines behind them.

Blockade, is the encompaſſing a fortified place with an army, ſo that it muſt either be ſtarved or ſurrender.

Body of the place; although the buildings in a fortified place are properly ſaid to be the body of the place, yet the incloſure round them is generally underſtood by it: for it is ſaid, to conſtruct the body of the place, which means no more than to fortify or incloſe the place with baſtions and curtains.

Bombs,

Bombs, is the name of the ſhips which carry mortars.

Bombardment, is when a great number of ſhells are thrown into a place, to ruin and deſtroy the buildings.

Bonnet, is a ſort of work placed before the ſaliant angle of the ravelin to cover it.

Barracks, are thoſe piles of buildings made on purpoſe to lodge the ſoldiers in them.

Breach, is an opening made in a wall or rampart, with cannon or mines, ſufficiently wide for a body of troops to enter the works, and drive the beſieged out of it.

C.

Capital of a work is an imaginary line which divides that work into two equal and ſimilar parts.

Capitulation, is the agreement made by the beſieged with the beſiegers, on what conditions the place is to ſurrender.

Camp, is the ſpot of ground occupied by an army for a night or more, and where they pitch their tents.

Caponier, is a paſſage made from one work to another, of 10 or 12 feet wide, covered on each ſide by a parapet, terminating in a ſlope or glacis.

Thus

Thus when the ditch is dry, the paſſage from the curtain to the ravelin, or that from the covert-way to the arrows or detached redoubts, are called caponiers.

There are often ſingle parapets raiſed at the entrance of the ditch, before the ravelin, to place ſmall cannons and men behind them, to diſpute the paſſage over that ditch, which are likewiſe called capcniers.

Cavalier, is a work raiſed generally within the body of the place, ten or twelve feet higher than the reſt of the works. Their moſt common ſituation is within the baſtion, and made much in the ſame form; ſometimes they are alſo placed in their gorges, or on the middle of the curtain; they are then made in the form of a horſe-ſhoe, only ſomewhat flatter.

The uſe of cavaliers is to command all the adjacent works and country about it; they are ſeldom or never made but when there is a hill or riſing ground which overlooks ſome of the works.

Caſemat, is a work made under the rampart, like a cellar or cave, with loop-holes, to place guns in it.

Chamade; when the governor of a place beſieged wants to capitulate, then the drums beat

beat on the rampart next the attack, which is called chamade.

Chevaux de Frize, are large joiſts or beams ſtuck full of wooden pins armed with iron, to ſtop breaches, or to ſecure the paſſages of a camp againſt the enemy's cavalry.

Covert-way, is a ſpace five or ſix toiſes broad, going quite round the works of a fortification, and is adjoining to the counterſcarp of the ditches, covered by a parapet 7 ½ feet high, terminating in an eaſy ſlope towards the field, at a diſtance of 20 toiſes.

Center of the baſtion, is the point within where the two adjacent curtains produced interſect each other.

Citadel, is a kind of fort or ſmall fortification of four, five, or ſix ſides, joined to towns, when the inhabitants are ſuſpected to be diſaffected to the government.

Command; when a hill or riſing ground overlooks any work of a fortification, and is within the reach of cannon-ſhot; this hill is ſaid to command that work.

Chamber, is that place of a mine where the powder is lodged.

Countermines, are the mines made within the fortification, either at the ſame time the place is fortified, or afterwards in the time of a ſiege.

Coun-

Counterſcarp, is the outſide of a ditch, oppoſite to the parapet of the work behind the ditch: it is often ſaid, that the beſiegers have carried their lodgments upon the counterſcarp; which means, they are lodged on the covert-way.

Counterguard, is a work placed before the baſtions to cover the oppoſite flanks from being ſeen from the covert-way: they are likewiſe made before the ravelins.

When they are placed before the baſtions, they are eſteemed to be of a very good defence.

Crown-work, is a kind of work not unlike a crown; it has two fronts and two branches; the fronts are compoſed of two half baſtions and one whole one; they are made before the curtain or the baſtion, and generally ſerve to incloſe ſome buildings which cannot be brought within the body of the place, or to cover the town-gates, or elſe to occupy a ſpot of ground which might be advantageous to an enemy.

Cordon, is a round projection made of ſtone, circular form, whoſe diameter is , which reigns quite round four feet from the upper

Curtain,

Curtain, is the part of the body of the place, which joins the flank of one baſtion to that of the next.

Cuvette, or rather *Cunette*, is a ſmall ditch of 10 or 12 feet broad, made in the middle of a large dry ditch, ſerving as a retrenchment to defend the ditch, or elſe to let water in it, when it can be had in the time of a ſiege.

Counte forts, or *Buttreſſes*, are ſolids of maſonry, built behind walls, and joined to them, at 18 feet diſtance from center to center, in order to ſtrengthen it, eſpecially when it ſuſtains a rampart or terras.

Communication, is a paſſage from one work to another, covered by a parapet on each ſide. See *Caponiers*.

D.

Decagon, is a polygon or fortification ten ſides.

Demi-lune, or *Ravelin*, is a work placed before the curtain to cover it, and prevent the flanks from being diſcovered ſideways; it is made of two faces meeting in an outward angle.

Detached Baſtion, is that which is ſeparated from the reſt of the body of the place,

and is made in the ſame manner as thoſe which are joined to the body. Counter-guards with flanks are alſo called detached baſtions, as in M. *Vauban*'s ſecond and third methods.

Detached redoubt, is a work made at ſome diſtance from the covert-way, much in the ſame manner as a ravelin with flanks.

Ditch, is a large deep trench made round each work, and the earth dug out of it, ſerves to raiſe the rampart and parapet.

Dodecagon, is a figure or fortification of twelve ſides.

E.

Eſcarp, is properly any thing high and ſteep, and is uſed in fortification to expreſs the outſide of the rampart of any work next to the ditch, as being high and ſteep.

Embraſures, are openings made in the flanks of a fortification, or in the breaſt work of a battery, of about $2\frac{1}{2}$ feet within, 8 or 9 without, and three from the bottom, for the guns to enter partly, and to fire through.

Enfilade, a work is ſaid to be enfiladed, when a gun may fire into it, ſo that the ſhot may go all along the inſide of the parapet.

Epaule-

Epaulement, is a kind of breaſt-work to cover the troops in front, and ſometimes in flank.

In a ſiege, the beſiegers raiſe generally an epaulement of 9 or 10 feet high, near the entrance of the approaches, to cover the cavalry, which is placed there to ſupport the guard of the trenches.

Eſplanade, is an open ſpace between the citadel and town, to prevent an enemy from making approaches under cover, after he is maſter of the place.

Enneagon, is a nine-ſided figure or fortification.

Eptagon, a ſeven-ſided one.

Exagon, a ſix-ſided one.

Exterior ſide of a fortification, is the diſtance or imaginary line drawn from one point of the baſtion to that of the next.

F.

Faces, of the baſtion, are the two ſides which meet in an angle projecting towards the field.

Faces, of any work, are thoſe parts where the rampart is made, making an angle pointing outwards.

Faſcine, a kind of faggot made of branches tied in two or more places of about 6 or 8 inches diameter.

They ſerve to keep up the earth in trenches as likewiſe in batteries, inſtead of ſtone or brick walls.

When they are uſed in raiſing batteries, they are generally 16 feet long; and are then called *Sauciſſons*.

Fauſſe-bray, is a low rampart going quite round the body of the place; their height is about 3 feet at moſt above the level ground; and its parapet is about 4 or 5 toiſes diſtance from that of the body of the place.

Theſe works have been entirely rejected by the modern engineers, excepting M. *Vauban*, who makes them only before the curtains, and then they are called tenailles.

Flank, in general, is a part of a work, which defends another work along the outſide of its parapet.

Flank of the baſtion, is the part between the face and curtain; the flank of one baſtion ſerves to defend the ditch before the curtain, and face of the oppoſite baſtion.

Flank (concave) is that which is made in an arc of a circle.

Flank,

Flank, (retired) is that which is made behind the line, which joins the extremity of the face and the curtain, towards the capital of the baſtion. M. *Vauban* makes his 5 toiſes from that line; others more or leſs, as it happens.

Flanking, is the ſame thing in fortification as defending.

Flank (direct or graſing) is that which is perpendicular to the oppoſite face produced; and oblique or fiſhant, when it makes an acute angle with that face.

Flank (ſecond) when the face of a baſtion produced, does not meet the curtain at its extremity, but in ſome other point; then that part of the curtain between that point and the flank, is called ſecond flank. The modern engineers have rejected this way of fortifying.

Fort, is a ſmall fortification, made in a paſs, near a river, or at ſome diſtance from a fortified town; to guard the paſs, or to prevent the approach of ſhips, or an enemy by land.

Fortification, is a general name for any work made to oppoſe a ſmall number of troops againſt a greater.

Fourneau, is the place of a mine, where the powder is lodged, and is the ſame thing as the chamber of a mine.

Fougaſs,

Fougaſs, is a ſmall mine, from 6 to 8 feet under ground; they are generally placed under the glacis or dry ditches.

Fraiſe, a kind of ſtakes or paliſades placed horizontally on the outward ſlope of a rampart made of turf, to prevent the work being taken by ſurpriſe.

When an army retrenches itſelf, they often fraiſe the parapets of their retrenchments in the parts moſt expoſed to being attacked.

Fuſee, is the piece of wood drove into grenades or ſhells, being hollow, and filled with mealed powder, by which the grenade or ſhell is fired.

G.

Gabion, is a cylindric baſket open at both ends, of about 3 feet wide, and as much in height, they ſerve in ſieges to carry on the approaches under cover, when they come pretty near the fortification.

Gabion, (ſtuft) is made in the ſame manner as the former, they are only filled with all ſorts of branches and ſmall wood, and are 5 or 6 fe[illegible] they ſerve to roll before the work[illegible]nches, to cover them in fr[illegible] hot.

Gallery,

Gallery, is the paſſage made under ground leading to the mines; they are from 4½ to 5 feet high, and about 4 feet broad; the earth above is ſupported by wooden frames with boards over them.

Garriſon, a body of troops compoſed of horſe and foot, placed in a fortification to guard it in time of peace, and to defend it in time of war in caſe an enemy ſhould attack it.

Glacis, is that part of a fortification beyond the covert-way, to which it ſerves as a parapet, and terminates towards the field in an eaſy ſlope at about 20 toiſes diſtance.

Gorge, of a baſtion, is the interval between the extremity of one flank to that of the other.

Gorge, of any work, is that part next to the body of the place, where there is no rampart or parapet; that is, at the counter-ſcarp of the ditch.

Grenade, is an iron ball of about 3 inches diameter hollow within; which is filled with powder, to be thrown by the grenadiers amongſt the enemy in an attack, after having ſet fire to the fuſee, that it may burſt.

H.

Hornwork, is compoſed of a front and two

two branches; the front is made into two half baſtions and a curtain; this work is of the nature of a crown-work, only ſmaller, and ſerves for the ſame purpoſes.

Half-moon; ſee *Demi-lune*.

Hurtor, is a piece of timber about 6 inches ſquare, placed before the wheels of a carriage, againſt the parapet of a battery, to prevent the wheels from doing damage to the parapets,

I.

Inſult, a work is ſaid to be inſulted when it is attacked ſuddenly and openly.

Inveſting a place, is to ſurround it with troops, ſo as to prevent any thing to enter the place, or to be carried out of it: it is the firſt operation of a ſiege.

Interior ſide of a fortification, is the imaginary line drawn from the center of one baſtion to that of the next, or rather the curtain produced to the center of the baſtions.

L.

Line of defence, is the diſtance between the ſaliant angle of the baſtion, and the oppoſite flank; that is, it is the face produced to the flank.

Line

Line of circumvallation, is the work or retrenchment made about an army which beſieges a place, to ſecure it againſt any inſult from without; it is made of a parapet with a ditch before it, and at every 120 toiſes, or thereabout, the parapet projects outwards in an angle; this projection is called a *Redan*, and ſerves to flank or defend the other parts.

Line of countervallation, is the work made by an army which beſieges a place between their camp and the town, to cover it againſt any enterpriſe of the garriſon; it is made much after the ſame manner as the line of circumvallation, only in a contrary diſpoſition.

Line, is alſo the name of the works made by an army from one town or ſtrong poſt to another, behind which it is encamped, to guard a part of the country.

Line of counter-approach, is a kind of trench made by the garriſon when beſieged, going from the covert-way in a right line, ſo as part of the enemy's approaches may be enfiladed from thence.

Lodgment, is the work made by the beſiegers in ſome parts of a fortification, after the beſiegers have been drove out, to maintain it.

Loop-

Loop-holes, are ſquare or oblong holes made in the wall, to fire through with muſkets.

Lunettes, are works made on both ſides of a ravelin; one of their faces is perpendicular to half or two thirds of the faces of the ravelin, and the other nearly ſo to thoſe of the baſtions.

Lunettes, are alſo works made beyond the ſecond ditch, oppoſite to the places of arms; they differ from the ravelins only in their ſituation.

M.

Mantlet, is a kind of moving parapet made of ſtrong planks, about 4 feet long and 3 high, mounted upon two wheels, with a long pole fixed to it; they ſerve to cover the ſappers in the front againſt muſket-ſhot.

Mine, is a kind of lodgment made under ground to place powder in it, which is ſet on fire, in order to blow up the works above it; the difference between mines and countermines is, that the firſt are made by the beſiegers, and the latter by the beſieged.

Octo-

O.

Octogon, is an eight-ſided figure of fortification.

Ondecagon, an eleven-ſided one.

Orillon, is a part of the baſtion near the ſhoulder, which ſerves to cover the retired flank from being ſeen obliquely.

Orgues, many harquebuſſes linked together, or divers muſket-barrels laid in a row, ſo that they may be diſcharged either all at once or ſeparately; alſo long and thick pieces of wood with iron plates at the end, hung over a gate, to ſtop it up inſtead of a port-cullice.

P.

Paliſades, are a kind of ſtakes made of ſtrong ſplit wood of about 9 feet long, fixed 3 feet deep in the ground in rows about 6 inches aſunder; they are placed in the covert-way at 3 feet from, and parallel to the parapet or ridge of the glacis, to ſecure it from being ſurpriſed.

Parapet, is a part of the rampart of a work, of 18 or 20 feet broad, and raiſed 6 or 7 feet above the reſt of the rampart; it ſerves to cover the troops, placed there to defend the work, againſt the fire of the enemy.

Parallels,

Parallels, or places of arms, are deep trenches 15 or 18 feet wide, joining the ſeveral attacks together; they ſerve to place the guard of the trenches in, to be at hand to ſupport the workmen when attacked. There are generally three in an attack; the firſt is about 300 toiſes from the covert-way, the ſecond 190, and the third near or on the glacis. They were firſt invented or uſed by M. *Vauban*.

Petard, is a kind of a braſs pot fixed upon a ſtrong ſquare plank, which has an iron hook to fix it againſt a gate or paliſades; this pot is filled with powder, which when fired, breaks every thing about it, and thereby makes an opening for an enemy to enter the place.

Port-cullice, is a falling gate or door like a harrow, hung over the gates of fortified places, and let down to keep out the enemy.

Place, is comonly uſed in fortification, inſtead of a fortified town.

Place of arms, of the covert-way, is a part of it, oppoſite to the re-entring angle of the counterſcarp, projecting outwards in an angle.

Places of arms, in an attack; ſee *Parallels*.

Plat-

Plat-form, is a floor made of ſtrong planks, laid upon joiſts, on a battery, to place the guns or mortars upon, in order to prevent the wheels or mortar-bed from ſinking in the ground.

R.

Rampart, is an elevation of earth raiſed along the faces of any work, of 10 or 15 feet high, to cover the inner part of that work againſt the fire of an enemy.

Rams-horns, are a kind of low work made in the ditch of a circular arc; they were invented by M. *Belidor*, and ſerve inſtead of tenailles.

Re-entring angle, is that which turns its point towards the center of the place.

Ravelin. See *Demi-lune*.

Redans. See *Line of circumvallation*.

Redoubt, is a kind of work placed beyond the glacis, of various forms.

Redoubt, is alſo the name of a ſmall work made in a ravelin, of the ſame form.

Redoubt, is likewiſe a ſquare work without any baſtions, placed at ſome diſtance from a fortification, to guard a paſs, or to prevent an enemy from approaching that way.

Revete-

Revetement, is a ſtrong wall built on the outſide of the rampart and parapet, to ſupport the earth, and prevent its rolling into the ditch.

Ricochet, when guns are loaded with ſmall charges, and are elevated from 10 to 12 degrees, ſo as to fire over the parapet, and the ſhot rolls along the oppoſite rampart, it is called ricochet firing; and the batteries are likewiſe called ricochet batteries.

S.

Sally, is when a party of a garriſon goes out privately, and falls ſuddenly on the beſiegers in their trenches, endeavouring to drive them out and deſtroy their works.

Saliant angle, is that whoſe point turns from the center of the place.

Second ditch, is that which is made on the outſide of the glacis, when the ground is low, and water to be had.

Second covert-way, is that which is made beyond the ſecond ditch.

Sap, is a trench or an approach made under cover of 10 or 12 feet broad, when the beſiegers come near the place, and their fire grows ſo dangerous, as not to be approached uncovered.

Sauciſſon, is a long pipe or bag, made of cloth or leather, of about an inch and a half diameter, filled with powder, going from the chamber of a mine to the entrance of the gallery; it ſerves to give fire to the mine.

Sauciſſon, is likewiſe a faſcine much longer than the common ones; they ſerve to raiſe batteries, and to repair breaches.

Siege, is when an army approaches a fortified place, and ſurrounds it on all ſides, endeavouring to oblige the garriſon to ſurrender, either by deſtroying the works of the fortification, or thoſe which defend them.

T.

Talud, or ſlope, is made to the works of a fortification, both on the outſide and inſide to prevent the earth from rolling down.

Traverſe, is a parapet made croſs the covert-way, oppoſite to the ſaliant angles of the works, and near the places of arms, to prevent enfilades; they are 18 feet thick, and as high as the ridge of the glacis. There are alſo traverſes made in the caponiers, but then they are called *tambours*.

Traverſes, are likewiſe made within other works, when there are any hills or riſing grounds, which may ſee the inſide of theſe works.

Tenailles,